










Position	Code	description
000A	5513211891	SCRAPER BRUSH WITH BRISTLES
000B	5313233141	FLOAT
000C	5013254401	WIRING FOR FLOWMETER (L180)
000D	5313232501	RIGHT FRAME
000E	5313232511	LEFT FRAME
000F	5313235441	PUMP SUPPORT
000G	5313233021	DRAIN TRAY
000H	5313256701	GENERATOR COVER
000I	5313241391	ADJUSTMENT KNOB
000J	5313240141	AESTHETIC BOARD COVER
000K	5313232881	DOOR HINGE HOUSING
000L	5313232641	MICRO SUPPORT
000M	5313246001	TANK COVER
000N	5313236311	WATER TANK FILTER
000O	5013257341	CABLING WITH FUSE FOR GRINDER (1.25A L=270mm)
000P	AS00000378	ECOMULTICLEAN 10ML VIAL
001	7313254591	WATER TANK
002	5513229801	AROMA SEAL COVER
003	5313247681	LEFT SIDE
004	5013212061	POWER SUPPLY CORD WITH PLUG (INT)
005	7313238751	UPPER COVER
006	5313240321	FINGER STOP COVER CAP
007	5313245391	COVER
008	5913214771	GRIND REGULATION KNOB
009	5313232561	GROUND COFFEE FUNNEL
010	5313247691	RIGHT SIDE
011	5313240121	REAR PANEL
012	6113211861	FINGER STOP INSERT
013	5313240351	COFFEE BEANS TANK
014	7313238831	COFFEE GROUNDS CONTAINER
015	5313240021	CUP HOLDER TRAY
016	5913270401	GROUND COFFEE COVER
017	5513222661	STEAM KNOB
018	7313238721	CONTROL PANEL ASSEMBLY WITH BOARD
019	7313238761	FRONT PANEL
020	7313238701	FROTHER

021	53132D0730	O RING
022	5313245401	TUBE (IFD)
023	AS13200283	FROTHER TUBE
025	7313245021	COFFEE DISPENSER
026	7313228691	DOOR ASSEMBLY
027	53132C8134	MEASURING SPOON
028	6013213661	CUP HOLDER
031	7313234141	GRINDER ASSEMBLY (3D-DL 230V)
032	AS00006298	TROLLEY
033	5313213591	TROLLEY SLEWING RING
034	5113211381	SWITCH (16A 125/250V)
035A	5213217901	POWER BOARD (SW1.0 230V)
035B	5213221091	POWER BOARD (SW2.1 DG 230V)
036	7313295821	COMPENSATION SYSTEM
037	5313240511	ON-OFF KEY
038	5213270906	BOARD
039	53132C7925	MOBILE FUNNEL
040	5313213371	PISTON LOWERING FLAP
041	AS00006012	TROLLEY SUPPORT
042	5313224721	RUBBER FOOT PAD
044	5313240501	BOARD SUPPORT
045	9812631250	SCREW (3.5X12)
046	6013213181	FILTER (D.40X2.3 TAI-FENG)
047	5313238581	GASKET
048	7313251451	INFUSER
049	5313213431	GASKET
050	5313213391	EXPULSION ARM
051	5313240491	BOARD COVER
052	5313240531	KEY GASKET
054	5513230831	FLOW REGULATOR
055	5313239061	WATER TANK CONNECTOR
056	6113213191	CLIP (WIRE 1,2 AISI302)
057	5313236031	RIGHT ANGLE CONNECTOR
058	7313228701	TRANSMISSION ASSEMBLY (ECM 230V)
059	7313217261	MOTOR WITH PULLEY (ECM 230V)
060	5313243071	TOOTHED BELT
061	5213216051	HALL SENSOR (L460)
062	5132110500	MICROSWITCH (250V 85°)

063	5213212381	MOTOR BOARD (ECM 230V)
064	5113270613	PUMP (230V)
065	5313217741	O-RING (D=6.75 T=1.78)
066	5313217701	O-RING (D=3.85 T=2)
070	5213213321	PUMP PROTECTOR
071	5313217871	TUBE (DI=3 DE=6 L200)
072	5513220521	IMPURITY FILTER
073	5013255141	WIRING FOR FLOWMETER (L220)
074	5313233181	A L TUBE
075A	AS00006030	FLOWMETER
075B	5213225251	FLOWMETER
076	5213217891	REED SENSOR (L230)
077	5513214661	CAM SLIDER
078	5313240311	DRAIN HOSE (L=110)
079	5113210211	MICROSWITCH
080	5513213501	TUBE WITH 2 BUSHES (L150)
081	7313219401	SAFETY VALVE
082	5513212901	TUBE WITH 2 BUSHES (L290)
083	5313244791	TUBE (DI=4 DE=8 L400)
084	5313228791	GENERATOR GASKET
085	5513212881	TUBE WITH 2 BUSHES (L270)
086	5332239200	CONNECTOR
087	5332239300	SPACER
088	5013256801	TCO WITH WIRING (L710 - L80)
089	5213215661	NTC PROBE (L500)
090	5513236251	BOILER (230V)
091	5013256811	TCO WITH WIRING (L640 - L130)
092	5113210211	MICROSWITCH
093	5132104100	MICROSWITCH (250V 85°)
094	7313244171	MECHANICS VALVE (ETAM)
095	9812631250	SCREW (3.5X12)
096	7313236301	STEAM VALVE
097	5313217601	BLACK FILTER
098	5313238581	GASKET
099	5313213841	FROTHER STOP