










Position	Code	description
000A	5313213911	COFFEE OUTLET TANK COVER
000B	6132104700	SPRING (x micro 12 x 5)
000C	5513211891	SCRAPER BRUSH WITH BRISTLES
000D	5313213451	COFFEE HOSE CLAMP
000E	AS00006031	GRINDER FINGER STOP RING
000F	5313250631	DISPENSER SUPPORT
000G	5013257371	CABLING WITH FUSE FOR GRINDER (1.25A L=450mm)
000H	5312810921	TERMINAL COVER
000I	AS00000378	ECOMULTICLEAN 10ML VIAL
000J	6013211721	PLATE
001	5513227841	UPPER COVER
002	AS00010434	COFFEE BEANS COVER
003	7313245761	FRONT PANEL
004	5313221031	GROUND COFFEE TANK COVER
006	5913216201	GRIND REGULATION KNOB
007	55132A1346	COFFEE BEANS TANK
008	5513226341	REAR PANEL
009	5513226331	LEFT SIDE
010	5313251071	LEFT FRONT PIECE
015	5032112000	POWER SUPPLY CORD CH
016	5313248921	DRIP TRAY
017	5313248141	DRIP TRAY GRID
018	6013214651	CUP HOLDER
019	5513235551	COFFEE GROUNDS CONTAINER
020	5513226321	RIGHT SIDE
021	5313249401	FRONT PIECE
023	5332227400	REGULATOR
024	6132106200	SPRING
025	5213270906	BOARD
030	5313248181	ON/OFF KEY
031	7313245711	CONTROL PANEL ASSEMBLY WITH BOARD
032	7313241791	COFFEE DISPENSER
033	AS00009990	DLS-COVER TANK SMOKE(C8-11)(SAN) ECAM
035	5313249411	WATER TANK FRONT PIECE
036	5313213291	HOSE COUPLING COVER
037	5313235921	TANK GASKET

038	5313214981	WATER TANK FILTER
039	6113210251	SPRING
040	AS13200250	TANK
040A	AS00010091	WATER TANK
045	53132C8134	MEASURING SPOON
047	5313239981	FLOAT
060	5313219181	GRINDER BELLOW GASKET
061	7313294110	GRINDER ASSEMBLY
062	AS00006115	SWITCH HOLDER
063	5113210211	MICROSWITCH
064	5132112500	SWITCH
066	AS00009830	LEFT FRAME
067	5113210211	MICROSWITCH
068	5313229731	RUBBER FOOT PAD
070	7313217261	MOTOR WITH PULLEY (ECM 230V)
075	5313243071	TOOTHED BELT
076	5513228021	TRANSMISSION ASSEMBLY (ECM 230V)
077	5132110500	MICROSWITCH (250V 85°)
078	5213213971	HALL SENSOR (L620)
079	AS00008306	DLS-PCB FILTER MOTOR(GDS-CN)230V ECAM
080	9812631250	SCREW (3.5X12)
081	5313213411	DOOR
082	5513214661	CAM SLIDER
083	5313213551	DRAIN TRAY
084	7313251451	INFUSER
085	5313213591	TROLLEY SLEWING RING
090	AS00006298	TROLLEY
091	AS00006012	TROLLEY SUPPORT
092	5313213391	EXPULSION ARM
093	5313213431	GASKET
094	5313238581	GASKET
095	5313213371	PISTON LOWERING FLAP
096	6013213181	FILTER (D.40X2.3 TAI-FENG)
097	53132C7925	MOBILE FUNNEL
098	7313295821	COMPENSATION SYSTEM
099	5213220311	POWER BOARD
100	5513243271	RIGHT FRAME
107	5232104600	REED SENSOR

115	5313227841	RIGHT ANGLE DRAIN CONNECTION
116	AS13200285	FROTHER TUBE
117	5513213501	TUBE WITH 2 BUSHES (L150)
118	5313217701	O-RING (D=3.85 T=2)
119	6113213191	CLIP (WIRE 1,2 AISI302)
120	53132C8498	RING
121	6132101300	SPRING
122	53132D0730	O RING
123	5313247231	STEAM NOZZLE
124	5113210211	MICROSWITCH
125	5313240281	FROTHER GASKET
126	5313248171	SOLENOID VALVE SUPPORT
127	7313242081	FROTHER
128	5513213761	TUBE WITH 2 BUSHES (L190)
129	5213218471	SOLENOID VALVE
130	5313213841	FROTHER STOP
131	5132104100	MICROSWITCH (250V 85°)
132	5313217861	TUBE (DI=3 DE=5,5 L145)
133	5313217601	BLACK FILTER
134	9812631250	SCREW (3.5X12)
135	5313238581	GASKET
136	534781	TUBE (L170)
137	5513212881	TUBE WITH 2 BUSHES (L270)
138	5513212901	TUBE WITH 2 BUSHES (L290)
139	5513227961	MECHANICS VALVE (DLS ECAM)
173	5013251461	WIRING FOR FLOWMETER (L300)
174	5313250211	RIGHT ANGLE WATER OUTLET TUBE
175	5213225251	FLOWMETER
181	5313217861	TUBE (DI=3 DE=5,5 L145)
182	5213213321	PUMP PROTECTOR
183	5113270613	PUMP (230V)
184	5513230831	FLOW REGULATOR
196	5513212871	TUBE WITH 2 BUSHES (L97)
197	7313219401	SAFETY VALVE
198	5313217871	TUBE (DI=3 DE=6 L200)
199	5313256701	GENERATOR COVER
200	5313228791	GENERATOR GASKET
201	5332239300	SPACER

202	5513236251	BOILER (230V)
203	5213214061	SENSOR (NTC)
204	5013256801	TCO WITH WIRING (L710 - L80)
205	5013256811	TCO WITH WIRING (L640 - L130)
206	5332239200	CONNECTOR