


















66













85
SERIE TUBI
TUBE SERIES

86
SERIE TUBI CON BOCCOLE
TUBE SERIES WITH BUSHES

87
88
89



Position	Code	description
0	AS00006298	TROLLEY
000Z	AS00010041	FROTHER TUBE
001	AS13200344	GROUND COFFEE TANK COVER
002	5313273981	COFFEE BEANS COVER
003	AS13200342	UPPER COVER
004	5913212611	GRIND REGULATION KNOB
005	AS13200316	REAR PANEL
006	AS13200320	LEFT SIDE
007	AS13200343	COFFEE BEANS TANK
008	AS00006031	GRINDER FINGER STOP RING
009	AS00006025	MICROSWITCH SUPPORT
010	AS13200318	RIGHT SIDE
011	5313251441	COVER
012	AS13200336	WATER TANK ASSEMBLY
013	AS13200312	FRONT PIECE
014	AS13200325	COFFEE GROUNDS CONTAINER
015	AS13200321	FRONT PANEL
016	6013216191	CUP HOLDER
16A	AS00006933	CUP HOLDER
017	5513251221	DRIP TRAY
17A	AS00006934	DRIP TRAY
018	5313222641	FLOAT
18A	5313270081	FLOAT
019	AS13200338	FRONT PANEL
20A	AS00008349	DRIP TRAY GRID
021	5313213551	DRAIN TRAY
021A	AS00002596	DRAIN TRAY
22A	5313270071	SUPPORT
025	AS13200331	CONTROL PANEL ASSEMBLY WITH PCB
029	6132106200	SPRING
030	5332227400	REGULATOR
031	AS13200328	COFFEE DISPENSER
033	5313217741	O-RING (D=6.75 T=1.78)
035	AS13200086	STEAM VALVE ASSEMBLY
036	AS00008493	DLS-KNOB STEAM CHROMED+SPRING(AISI) ECAM
037	AS13200310	FRONT PIECE

038	AS00006121	TUBE WITH FROTHER
039	53132D0730	O RING
040	5313217751	O-RING BLACK (D=6.07 T=1.78)
041	5332169300	LOWER TUBE
042	5313221171	FROTHER EXTERNAL TUBE
043	AS00009830	LEFT FRAME
044	AS00006028	RIGHT FRAME
044A	AS00005730	RIGHT FRAME
045	5313213371	PISTON LOWERING FLAP
046	6113210201	SPRING
047	AS00008952	REED SENSOR
048	AS00006023	ELECTRONIC POWER BOARD
0049	5313229731	RUBBER FOOT PAD
050	5313213841	FROTHER STOP
051	AS00006012	TROLLEY SUPPORT
052	53132C7925	MOBILE FUNNEL
053	6113210181	SPRING
054	7313251451	INFUSER
055	5313213391	EXPULSION ARM
056	5313213431	GASKET
058	9812631250	SCREW (3.5X12)
059	6013213181	FILTER (D.40X2.3 TAI-FENG)
060	5313277681	STOPPER
061	53132C9532	FROTH DEVICE VALVE NATURAL(PSU)ESAM&ECAM
062	6132112200	SPRING
063	5313238581	GASKET
066	AS13200337	GRINDER ASSEMBLY
070	9812631250	SCREW (3.5X12)
071	5313213591	TROLLEY SLEWING RING
073	7313295821	COMPENSATION SYSTEM
074	5313213431	GASKET
075	AS13200335	TRANSMISSION (CHIAPHUA 230V)
076	5213226181	MOTOR BOARD (ECM 230V)
077	5132110500	MICROSWITCH (250V 85°)
078	7313249421	MOTOR ASSEMBLY (CHIAPHUA 230V)
079	5213213971	HALL SENSOR (L620)
080	5313243071	TOOTHED BELT

081	5313200874	RIGHT ANGLE WATER OUTLET TUBE
082	5132104100	MICROSWITCH (250V 85°)
083	5313238581	GASKET
084	5313217601	BLACK FILTER
0085	AS00002674	MECHANICS VALVE (ECAM)
086	5313217871	TUBE (DI=3 DE=6 L200)
086A	5313283951	TUBE
086B	5313283891	TUBE
086C	535926	TUBE (DI=4 L110)
086D	5313249311	SILICONE HOSE (DI=3 DE=5,5 L15)
086E	5313283781	TUBE
086F	5313217861	TUBE (DI=3 DE=5,5 L145)
087	5513212871	TUBE WITH 2 BUSHES (L97)
087A	5513212881	TUBE WITH 2 BUSHES (L270)
087B	5513212891	TUBE WITH 2 BUSHES (L230)
087C	5513212901	TUBE WITH 2 BUSHES (L290)
088	5313217701	O-RING (D=3.85 T=2)
089	6132101300	SPRING
090	5113270613	PUMP (230V)
091	5513230831	FLOW REGULATOR
093	5213211181	SENSOR (NTC)
094	5332239300	SPACER
095	5313228791	GENERATOR GASKET
096	6113213191	CLIP (WIRE 1,2 AISI302)
097	5513225871	SAFETY VALVE
098	5113210211	MICROSWITCH
099	5213225251	FLOWMETER
100	5332239200	CONNECTOR
101	5213211161	PUMP PROTECTOR
102	5513236251	BOILER (230V)
103	5013256801	TCO WITH WIRING (L710 - L80)
104	5013256811	TCO WITH WIRING (L640 - L130)
105	5513214661	CAM SLIDER