










Position	Code	description
000A	5313213911	COFFEE OUTLET TANK COVER
000B	6132104700	SPRING (x micro 12 x 5)
000C	5513211891	SCRAPER BRUSH WITH BRISTLES
000D	5313213451	COFFEE HOSE CLAMP
000E	5313250631	DISPENSER SUPPORT
000F	5013257371	CABLING WITH FUSE FOR GRINDER (1.25A L=450mm)
000G	5312810921	TERMINAL COVER
000H	AS00000378	ECOMULTICLEAN 10ML VIAL
000I	6013211721	PLATE
001	5513227841	UPPER COVER
002	AS00010434	COFFEE BEANS COVER
003	7313245721	FRONT PANEL
004	5313221031	GROUND COFFEE TANK COVER
006	5913216201	GRIND REGULATION KNOB
007	55132A1346	COFFEE BEANS TANK
008	5513226341	REAR PANEL
009	5513226331	LEFT SIDE
010	5513235571	LEFT FRONT PIECE
015A	5032111900	POWER SUPPLY CORD WITH PLUG (SCHUKO)
015B	5513225601	POWER CORD ASSY CN PLUG
016	5313248921	DRIP TRAY
017	5313248141	DRIP TRAY GRID
018	6013214651	CUP HOLDER
019	5313249001	COFFEE GROUNDS CONTAINER
020	5513226321	RIGHT SIDE
021	5313248821	FRONT PIECE
023	5332227400	REGULATOR
024	6132106200	SPRING
025	5213270906	BOARD
030	5313248181	ON/OFF KEY
031	7313245671	CONTROL PANEL ASSEMBLY WITH BOARD
032	7313241791	COFFEE DISPENSER
033	AS00009990	DLS-COVER TANK SMOKE(C8-11)(SAN) ECAM
035	5313248841	WATER TANK FRONT PIECE
036	5313213291	HOSE COUPLING COVER
037	5313235921	TANK GASKET

038	5313214981	WATER TANK FILTER
039	6113210251	SPRING
040	AS13200250	TANK
040A	AS00010091	WATER TANK
045	53132C8134	MEASURING SPOON
047	5313239981	FLOAT
060	5313219181	GRINDER BELLOW GASKET
061	AS00002955	GRINDER ASSEMBLY
062	AS00006115	SWITCH HOLDER
063	5113210211	MICROSWITCH
064	5132112500	SWITCH
066	AS00009830	LEFT FRAME
067	5113210211	MICROSWITCH
0068	5313229731	RUBBER FOOT PAD
070	7313249421	MOTOR ASSEMBLY (CHIAPHUA 230V)
075	5313243071	TOOTHED BELT
076	7313250221	TRANSMISSION (CHIAPHUA 230V)
077	5132110500	MICROSWITCH (250V 85°)
078	5213213971	HALL SENSOR (L620)
079	5213220511	MOTOR BOARD (CHIAPHUA 230V)
080	9812631250	SCREW (3.5X12)
081	5313213411	DOOR
082	5513214661	CAM SLIDER
083	5313213551	DRAIN TRAY
084	7313251451	INFUSER
085	5313213591	TROLLEY SLEWING RING
090	AS00006298	TROLLEY
091	AS00006012	TROLLEY SUPPORT
092	5313213391	EXPULSION ARM
093	5313213431	GASKET
094	5313238581	GASKET
095	5313213371	PISTON LOWERING FLAP
096	6013213181	FILTER (D.40X2.3 TAI-FENG)
097	53132C7925	MOBILE FUNNEL
098	7313295821	COMPENSATION SYSTEM
099	AS13200032	POWER BOARD (SW1.1.0 DG 230V)
100	5513243271	RIGHT FRAME
107	AS00008952	REED SENSOR

115	5513226361	STEAM KNOB
116	5313217741	O-RING (D=6.75 T=1.78)
117	AS00008315	STEAM VALVE
118	5313217701	O-RING (D=3.85 T=2)
119	5113211011	MICROSWITCH
120	5313213841	FROTHER STOP
121	6132101300	SPRING
123	5313245401	TUBE (IFD)
124	53132D0730	O RING
125	AS13200283	FROTHER TUBE
130	7313241821	FROTHER
131	9812631250	SCREW (3.5X12)
132	5313217601	BLACK FILTER
133	5513212891	TUBE WITH 2 BUSHES (L230)
134	AS00006027	MECHANICS VALVE (ECAM)
135	5113210211	MICROSWITCH
137	5132104100	MICROSWITCH (250V 85°)
138	5313217861	TUBE (DI=3 DE=5,5 L145)
140	5313238581	GASKET
145	534781	TUBE (L170)
146	5513212881	TUBE WITH 2 BUSHES (L270)
147	5513212901	TUBE WITH 2 BUSHES (L290)
149	5332239200	CONNECTOR
150	5313228791	GENERATOR GASKET
151	5332239300	SPACER
152	5013256801	TCO WITH WIRING (L710 - L80)
153	5013256811	TCO WITH WIRING (L640 - L130)
154	5213211181	SENSOR (NTC)
155	5513236251	BOILER (230V)
160	5313256701	GENERATOR COVER
161	5313217871	TUBE (DI=3 DE=6 L200)
164	7313219401	SAFETY VALVE
165	5513212871	TUBE WITH 2 BUSHES (L97)
166	6113213191	CLIP (WIRE 1,2 AISI302)
167	5513230831	FLOW REGULATOR
168A	5113270613	PUMP (230V)
168B	AS00006065	PUMP
169	5213213321	PUMP PROTECTOR

170	5213225251	FLOWMETER
173	5013251461	WIRING FOR FLOWMETER (L300)
175	5313236711	RIGHT ANGLE WATER OUTLET TUBE (90° L=190)
176A	5313217861	TUBE (DI=3 DE=5,5 L145)
176B	5313244791	TUBE (DI=4 DE=8 L400)
176C	AS00006066	TUBE