




Position	Code	description
000A	9811040850	SCREW (M4X8)
000B	EE1103	BOX
000C	EE1104	INSTRUCTION MANUAL
000D	7313281249	10-CUP CARAFE
000E	AS00000378	ECOMULTICLEAN 10ML VIAL
001	EE1000	STOPPER
002	EE1080	COVER
003	EE1082	STOPPER
004	EE1081	LEVER
005	EE1079	INDICATOR
006	EE1078	COVER
007	535708	FROTHER
008	EE1077	COVER
009	EE1056	TAP
010	EE1057	KNOB
011	EE1096	TUBE
013	EE1085	SUMP
014	EE1095	TUBE
016	EE1101	CONTROL PANEL
017	EE1098	CASING
018	EE1064	TUBE
019	5132100800	BIPOLAR SWITCH (16A 125/250V)
020	EE1073	PUSH BUTTON
021	5132100700	UNIPOLAR SWITCH (16A 125/250V)
023	EE1015	GASKET
024	EE1058	WARNING LIGHT
026	EE1053	BOILER
027	EE1051	DISTRIBUTOR
028	EE1022	GASKET
029	EE1055	BOILER
030	EE1023	GASKET
031	EE1052	DIFFUSER
032	EE1026	THERMOSTAT
033	EE1006	FUSE
034	EE1059	FUSE
035	EE1089	FUNNEL
036	EE1065	SUPPORT BASE

037	NOCODE01	NOT AVAILABLE
038	EE1102	BOTTOM
039	EE1066	RING
040	EE1067	PLATE
041	EE1070	FUSE
042	EE1126	HEATING ELEMENT
043	EE1069	THERMOSTAT
044	EE1071	VALVE
045	EE1091	COVER
046	SL1721920	CONTAINER
047	EE1087	CONTAINER
048	EE1088	COVER
049	EE1009	MEASURING SPOON
050	EE1169	SUMP ADAPTER
051	EE1074	PUSH BUTTON