




Position	Code	description
000A	7332122300	FILTER HOLDER PODS UNIVERSAL
000B	9811040850	SCREW (M4X8)
000C	5332173200	DUCT
000D	6032102600	FILTER
000E	9815002850	STAINLESS STEEL NUT (M10 X 1.25) BOILER/VALVE
000F	9815003750	STAINLESS STEEL NUT (M8 X 1) BOILER/CONNECTION
000G	AS00000378	ECOMULTICLEAN 10ML VIAL
001	532233	RUBBER PAD
002	5532112800	SUPPORT BASE
003	535747	WIRE CLAMP
004	5132100000	HEATING ELEMENT
005	5232100000	SAFETY THERMOSTAT (145°)
007	7332162900	TUBE
008	6132100300	SPRING
009	7032101000	HEATING SURFACE
010	5332102900	GASKET
011	5332183600	SUPPORT
013	5332128900	COVER
014	5513214551	FILTER
015	5332152300	HINGE
016	NOCODE01	NOT AVAILABLE
017	5332128200	COVER
018	5332128700	PIN
019	5332128800	KNOB
020	6132102300	SPRING
021	5332129300	DELIVERY TUBE
023	5332134100	BODY
024	5332117600	GASKET
025	6032101800	FILTER
026	5332131100	WATER INTAKE TUBE
027	5332130900	SILICON HOSE (DI=85 L40)
028	7332157100	CONNECTION
029	7313280839	WATER TANK
030	5332129200	HANDLE
031	5332134300	COVER

032	5332129000	FROTHER TUBE
033	5313217761	O-RING (D=5.28 T=1.78)
034	5332108700	GASKET
035	535692	GASKET
036	5332113800	LOWER TUBE
037	5313217741	O-RING (D=6.75 T=1.78)
038	5332117200	PRESSING DEVICE
039	5332229600	COVER
040	6132101400	SPRING
041	5332131300	CONNECTION
042	5332118000	SILICON HOSE (DI=6 L150)
043	7332151600	FUNNEL ASSEMBLY
044	5332152400	FILTER HOLDER
045	6132100000	SPRING
046	5332100100	GASKET
047	537243	LEVER
048	5332118600	INSERT
049	5332122900	FLOAT
050	7032104300	CUP HOLDER
051	5332128000	TRAY
052	5332125200	SILICON HOSE (DI=4 L110)
054	5332122800	SILICON HOSE (DI=4 L35)
055	534848	SUPPORT
056	5113270612	PUMP (230V)
057	5332129400	SPONGE
058	5232100600	SAFETY THERMOSTAT (105°C+-2K)
059	6132101300	SPRING
060	AS00009453	ANTI-DRIP VALVE
061	536321	TUBE
062	9850081500	WASHER
063	AS00000942	QUICK CONNECT CONNECTION
064	5513212881	TUBE WITH 2 BUSHES (L270)
065	511816	TCO (226°)
066	536281	TUBE
067	5232101300	SAFETY THERMOSTAT (125°C+-3.5K)
068	607529	BRACKET
069	AS00006925	STEAM REGULATION KNOB
070	534714	LEVER

071	7332144400	TANK
072	5332128300	HANDLE
073	5332111600	SILICONE O-RING (5.94X3.53)
074	6132100800	SPRING
075	5332109000	PISTON
076	7313285889	FILTER FASTENER
077	6032102400	2-DOSE FILTER
078	7313285859	FROTH DISPENSER FILTER
079	7332173100	FILTER HOLDER SUMP
080	53132C8134	MEASURING SPOON
081	5932108600	COVER
082	5132108100	CHANGE OVER SWITCH
083	5118100800	WARNING LIGHT LAMP
084	6113211791	SPRING
085	5532106200	CHANGE OVER SWITCH KNOB
088	7313277129	TAP
089	5932108400	CONTROL PANEL
090	6813210411	UPPER BOILER
091	5132100700	UNIPOLAR SWITCH (16A 125/250V)
092	5332129700	PUSH BUTTON
093	5313217701	O-RING (D=3.85 T=2)
094	533216	GASKET
095	5132109600	HEATING ELEMENT
096	6832101000	LOWER BOILER
097	6032101200	FILTER
098	533218	GASKET
099	7032101500	SUPPORT
100	5332289700	VALVE
101	621986	RING
102	6113211931	SPRING
103	6232103400	DOWEL
105	7313281249	10-CUP CARAFE