




Position	Code	description
01	CR1001	COVER
02	CR1004	HANDLE
03	NOCODE01	NOT AVAILABLE
04	CR1008	FRONT PANEL
06	CR1011	BASE
07	CR1012	TANK
08	CR1014	PIN
09	CR1016	RUNNER
10	CR1018	BLOCK
11	CR1020	GASKET
13	CR1022	TRAY
14	CR1023	SUPPORT BASE
15	CR1026	KNOB
16	CR1028	KNOB
17	CR1029	LIGHTER
19	CR1031	HEATING ELEMENT
20	CR1032	CONTAINER
21	CR1035	BURNER
22	CR1038	GLASS
24	CR1041	STOPPER
25	CR1043	TANK
26	CR1044	CONTROL ASSEMBLY
27	CR1047	GRID
28	CR1050	CONTROL PANEL
30	CR1051	THERMOSTAT
31	CR1052	MOTOR
32	CR1053	MICROSWITCH
40	CR1055	COVER
42	CR1057	PARABOLA
43	CR1060	HOUSING