







Position	Code	description
1	ILS03210	PANEL
2	ILA40606	VENTILATOR
3	ILS12812	PANEL
4	ILS2460208	SOCLE
5	ILS0480008	FRAME
6	ILS2460008	SOCLE
7	ILS14840	BOTTOM
8	ILG12010	OVEN
9	ILA09422	GASKET
10	ILS17201	PANEL
11	ILS12814	PANEL
12	ILS23692	SUPPORT
13	ILA00800	DOUBLE CONE
14	ILS14838	FILLET
15	ILA41200	CABLE GROMMET
16	ILS23690	COVER
17	ILS03624	REAR PANEL
18	ILA03408	CHANGE OVER SWITCH
19	ILA44616	TIMER
20	ILA10610	WARNING LIGHT
21	ILA49206	THERMOSTAT
22	ILA4000614	KNOB
23	218P002087	KNOB
25	ILA08000	LENS
26	ILS08221	CONTROL PANEL
27	ILS22614	SUPPORT
29	ILA5043708	GLASS
30	ILA02824	HINGE
31	ILA46800	HINGE
32	ILA60202	GLASS
33	ILS01604	STOP
34	ILA5048680	GLASS
35	ILA09428	GASKET
36	ILS11440	STOP
37	ILA60230	SCREW
38	ILS02206	INNER DOOR
40	ILA45848	HEATING ELEMENT

41	ILA45838	HEATING ELEMENT
42	ILA43802	SUPPORT
44	ILA48210	SUPPORT
45	ILA43600	LAMP HOLDER
46	ILA10602	LAMP
47	ILA09244	GRID
49	ILS23003	SUPPORT
50	ILA45872	HEATING ELEMENT
51	ILA10834	INSULATOR
52	ILS20610	SUPPORT
53	ILS17002	PANEL
54	ILS17004	PANEL
55	ILS17012	PANEL
56	ILS17016	PANEL
57	ILA48212	SUPPORT
58	ILS14604	DRIP PAN
59	ILA09240	GRID
60	ILA45836	HEATING ELEMENT
61	ILA50200	FAN
62	ILA09420	GASKET
63	ILA40600	TERMINAL BOARD
65	ILA40602	GEARMOTOR
66	ILA48002	FLAME BAFFLE