




Position	Code	description
02	7085000700	BATTERY
03	511435	THERMOSTAT
07	5285000100	KLIXON
09	7085001000	CONTROL BOX
10	5985000000	CONTROL PANEL
11	5985000100	THERMOSTAT KNOB
12	5185001200	LUMINOUS DOUBLE SWITCH
13	5385005400	Push Button Left
14	5385005300	Push Button Right
16	5385002700	CABLE HOLDER
17	7385000000	WIRE CLAMP
18	512972	HEATING ELEMENT
19	5310810031	GASKET
20	7308205300	FOOT
21	5510001000	CASTOR