




Position	Code	description
01	7085000700	BATTERY
02	511435	THERMOSTAT
04	7085001200	CONTROL BOX
05	5985000000	CONTROL PANEL
06	5985000100	THERMOSTAT KNOB
07	5185001200	LUMINOUS DOUBLE SWITCH
08	5385005400	Push Button Left
09	5385005300	Push Button Right
10	5985002000	GRID
11	5385002500	SUPPORT
12	5385002600	KEY
13	5185000400	UNIPOLAR CHANGE OVER SWITCH (16A-250V)
14	5385002700	CABLE HOLDER
15	7385000000	WIRE CLAMP
16	5385002400	SUPPORT
17	5185000100	HEATING ELEMENT (750/230V A70-85°)
18	512972	HEATING ELEMENT
19	5310810031	GASKET
20	7308205300	FOOT
21	5510001000	CASTOR
22	5285000500	KLIXON
23	5114007900	MOTOR (220/240V 50HZ)
24	5385000500	FAN
25	611916	SPRING