




Position	Code	description
01	7086000200	BATTERY
02	5186000900	HEATING ELEMENT
03	511435	THERMOSTAT
04	5285000500	KLIXON
06	7086000500	CONTROL BOX
07	5986000000	CONTROL PANEL
08	5985000100	THERMOSTAT KNOB
09	5185001200	LUMINOUS DOUBLE SWITCH
10	5385005300	Push Button Right
11	5385005400	Push Button Left
12	5313009100	LENS
14	5385002500	SUPPORT
15	5385002600	KEY
16	5185000400	UNIPOLAR CHANGE OVER SWITCH (16A-250V)
17	5386000000	CABLE HOLDER
18	7385000000	WIRE CLAMP
19	5286000100	KLIXON
20	512357	WARNING LIGHT (220V)
22	5186003700	HEATING ELEMENT (2000W/230V)
23	5310810031	GASKET
24	5510001000	CASTOR
25	5586000100	FOOT
26	5386002900	SUPPORT
27	5386000500	REAR CASTOR
28	7086000400	REAR PANEL
29	6186000000	PIN