




| Position | Code       | description                         |
|----------|------------|-------------------------------------|
| 000A     | EH1120     | GASKET                              |
| 000B     | 5520410111 | CLEANING SPONGE FOR ICE CREAM MAKER |
| 01       | EH1097     | BLADE MIXER                         |
| 02       | EH1098     | CONTAINER                           |
| 04       | EH1100     | COMPRESSOR WITH KLISON              |
| 06       | EH1102     | COVER                               |
| 07       | EH1103     | EVAPORATOR                          |
| 09       | EH1105     | SUPPORT                             |
| 10       | EH1106     | MOTOR                               |
| 14       | EH1108     | FAN                                 |
| 16       | EH1110     | FILTER                              |
| 17       | EH1111     | CAPACITOR                           |
| 18       | EH1112     | WIRE CLAMP                          |
| 20       | EH1113     | SUPPORT                             |
| 21       | EH1114     | PCB                                 |
| 22       | EH1115     | SPRING                              |
| 23       | EH1116     | INSULATOR                           |
| 26       | 5320410101 | SUPPORT BASE                        |
| 27       | EH1353     | MOTOR                               |
| 28       | EH1119     | FOOT                                |
| 29       | EH1124     | SHAFT                               |
| 30       | SC1050301  | WASHER (121X21X08)                  |
| 31       | 9824600001 | RING                                |
| 32       | EH1129     | PULLEY                              |
| 33       | SC1052010  | TOOTHED BELT                        |
| 34       | EH1132     | WASHER                              |
| 35       | EH1131     | RING                                |
| 36       | 5320410059 | PULLEY                              |
| 37       | EH1130     | PIN                                 |
| 38       | EH1354     | GEAR                                |
| 42       | EH1133     | CASING                              |
| 43       | EH1454     | POWER SUPPLY CORD PLUG (NZ/AU)      |
| 45       | EH1134     | CHANGE OVER SWITCH                  |
| 46       | 5920410041 | CASING                              |
| 47       | EH1136     | SPRING                              |
| 50       | EH1139     | KNOB                                |
| 51       | EH1140     | BASKET                              |

|    |            |             |
|----|------------|-------------|
| 53 | EH1142     | BLADE MIXER |
| 54 | 5320410171 | STOPPER     |
| 55 | EH1144     | COVER       |