










INT KVC5000T

KVC5000T KITCHEN MACHINE

Position	Code	description
000A	KW630879	FOOD GRADE GREASE (100G)
000B	KW649973	BUSHES (10 PIECES)
000C	KW675013	SPIGOT SCREW 10PC
000D	KW710658	SPANNER
000E	KW711986	SHAFT ASSY CHEF CIRCLIP
000F	KW712212	WHISK 9 WIRE ALUMINIUM
000G	AW20010011	KWSK001 SOFT-SPATULA KW
000I	KW716134	STALL PLUG
000J	KW716839	WHISK CHEF 5 WIRES - STAMPED EU
000K	AW20011057	KAT51.000SS ATT KW CHEF WHISK SS INT
000L	KW717244	HEAD RELEASE LATCH PLATE MIM KIT
000M	KW717447	FOOT GREY GY43 - PACK 5
000N	AS00001021	SSO SEAL x5
000O	AS00002915	GEARBOX ASSY
01	AW20010011	KWSK001 SOFT-SPATULA KW
02	KW715830	SPLASHGUARD ASSY
03	AW20011064	KAT50.000CA KW CHEF K BEATER ALU INT
05	KW712210	DOUGH HOOK ALUMINIUM
06	AW20011019	CHEF BOWL ASSEMBLY - STAINLESS STEEL
007A	KW716647	SLOW SPEED OUTLET COVER ASSEMBLY
007B	KW716647	SLOW SPEED OUTLET COVER ASSEMBLY
08	KW715798	HSO COVER ASSY
09	KW715797	SPIGOT SCREW 3PC
10	KW715857	HSO SPIGOT HSO GY34
11	KW715796	SPIGOT SEAT PLATE
12	KW715802	TOP COVER ASSY
13	KW715815	GEARBOX BOLT & WASHER SET 6PC
14	KW715809	GEARBOX MOUNT 4PC
15	KW715789	MOTOR RETAINING SCREW & BUSH SET (3PCS)
16	KW715858	GEARBOX PULLEY & M8 NUT 2PC
17	KW715787	TIMING BELT
18	KW674746	GEARBOX TOP MOUNT
19	KW715818	SLOW SPEED OUTLET O RING 3PC
20	KW715814	SSO ASSY O RING & SCREW
21	KW715817	PANET HUB ASSY CHEF COVER & HUB NUT
22	KW715819	HUB NUT 3PC
023A	KW715813	GEARBOX ASSEMBLY COMPLETE - CHEF

INT KVC5000T

KVC5000T KITCHEN MACHINE

023B	KW716959	GEARBOX ASSEMBLY WITHOUT PLANET HUB
24	KW715810	PANET HUB SEAL SET
25	KW715812	CHASSIS
26	KW715791	HINGE PIN & E CLIP
27	KW715792	HEADLIFT SPRING
28	KW715816	CHASSIS DOWL 4PC
29	KW715788	HEAD UNDERCOVER MOULDING
30	KW715794	WASHER PLASTIC 3PC
31	KW715793	SHEDDER RING
32	KW715804	PULLEY ASSY
33	KW715803	MOTOR ASSEMBLY INCLUDING FOAM PAD (220/240V)
34	KW717244	HEAD RELEASE LATCH PLATE MIM KIT
35	KW715784	BODY COVER PRINTED
36	KW715790	LOCATION PIN
37	KW715827	BOWL MOUNT SET CHEF SS 4PC NUT & 4PC WASHER
38	KW715829	BOWL MOUNT SET 4PC NUT&WASHER
39	KW715828	BOWL LATCH KIT 4PC
40	KW715799	SPEED CONTROL ASSY
41	KW715825	PEDESTAL PRINTED
42	KW715800	HEADLIFT MICROSWITCH ASSY
43	KW715801	MICROSWITCH SEAT MOULDING
44	KW715806	CORD ENTRY MOULDING PRINTED
45	KW715805	POWER SUPPLY CORD WITH PLUG (EU)
46	KW715783	HEADLIFT LEVER ASSY
47	KW650300	FOOT GREY 5PC
48	KW715795	SPEED CONTROL RETAINING SPRING
49	KW715782	HEADLIFT LATCH ASSY
50	KW715807	PCB & CORD HOUSING
51	KW715808	PCB ASSY POWER
52	KW715831	PCB & CORD HOUSING MOULDING