

































Position	Code	description
000A	KW412095	BOWL MAJOR
000B	KW675013	SPIGOT SCREW 10PC
000C	KW710658	SPANNER
000D	KW710743	MAGNET
000E	KW716842	POWER WHISK MAJOR
000F	KW712874	WORKSURFACE PROTECTION MAT
000G	KW712876	SCRAPER
000H	KW716134	STALL PLUG
000I	AW20011028	KAT911SS COOKING CHEF SS BOWL
000J	AW20011051	KAT71.000SS KW WHISK SS INT
000K	KW716591	MOTOR ASSEMBLY
000L	KW717308	DISPLAY PCB
000M	AS00000401	INPUT PULLEY
01	KW716573	HIGH SPEED OUTLET COVER ASSEMBLY
02	KW715857	HSO SPIGOT HSO GY34
03	KW716592	SPIGOT PLATE
04	KW716596	TOP COVER
05	KW716594	SLOW SPEED OUTLET COVER INSERT
06	KW716593	SLOW SPEED OUTLET COVER
07	KW716597	REED SWITCH TOP COVER
08	KW716558	BELT
09	KW716583	MOTOR MOUNT MOLDING
10	KW674655	BOLT & WASHER KIT
11	KW712943	EARTH LEAD ASSY
12	KW715814	SSO ASSY O RING & SCREW
13	AS00004384	GEARBOX ASSY
14	KW716589	PLANET HUB ASSEMBLY
15	KW716595	SOCKET
16	KW716572	HEAT GUARD REED SWITCH ASSEMBLY
17	KW716603	HEAD UNDERSIDE
18	KW716574	PLANET HUB ASSEMBLY
19	KW716580	WIRING HEAT GUARD AND INTERLOCKS TO MAIN PCB
20	KW712898	HINGE PIN
21	KW712893	REAR SPACER
22	KW716582	BODY
24	KW716564	DISPLAY PCB

25	KW715794	WASHER PLASTIC 3PC
26	KW716584	MOTOR PULLEY AND TENSION PIN
27	KW716579	LCD CONTROL KNOB
28	KW716591	MOTOR ASSEMBLY
29	KW716559	BODY COVER
30	KW712897	BODY COVER INSERT
31	KW716560	PCB COVER
32	KW716571	HEADLIFT SPRING
33	KW712902	QUADRANT & BRACKET
34	KW675037	PIN
35	KW716561	PEDESTAL
36	KW716568	GROMMET SET (3x)
37	KW716715	GRILL SPRING
38	KW712905	EXHAUST GRILLE
39	KW716563	ASSIEME DI CONTROLLO DELLA VELOCITÀ
40	KW716565	EARTH LEAD ASSEMBLY
41	KW716566	EARTH PIN
42	KW716570	HEADLIFT REED SWITCH ASSY
43	KW716562	BOWL REED SWITCH ASSEMBLY
44	KW712901	CIRCLIP
45	KW716569	HEADLIFT LEVER ASSEMBLY
46	KW710366	HEADLIFT ASSY SPRING & LATCH PLATE
47	KW716586	NTC ASSEMBLY
48	KW712907	HIGH TEMPERATURE SEAT PAD
49	KW712908	SUPPORT CASTING
50	KW716576	INDUCTION COIL ASSEMBLY
51	KW716588	MOUNT PCB
52	KW716587	MAIN PCB
53	KW712945	LEAD ASSY INDUCTION PCB/POWER PCB
54	KW712944	EARTH LEAD ASSY
55	KW716590	WIRING FROM INDUCTION PCB TO MAIN PCB
56	KW716604	POWER SUPPLY CORD WITH PLUG (EU)
57	KW716598	INDUCTION FAN ASSEMBLY
58	KW716578	INDUCTION PCB
59	KW716557	BASE
60	KW712911	FOOT 6PC
61	KW716601	HEAT SHIELD ASSEMBLY
62	KW716602	SPLASHGUARD ASSEMBLY

63	KW716599	BOWL ASSEMBLY WITH HANDLES - PRINTED
64	AW20010020	KAT91.000CL KW COOKING CHEF STEAMER INT
65	KW716575	STIR ASSIST CLIP
66	KW716605	STIRRING TOOL
68	AW20011050	SPIRAL DOUGH HOOK
69	AWAT502002	AT502 CREAMING BEATER
70	AW20011049	KAT70.000SS KW CHEF XL K BEATER SS INT