












GB KVC5100S

KVC5100S KITCHEN MACHINE -
CHEF ELITE

Position	Code	description
000A	KW649973	BUSHES (10 PIECES)
000B	KW675013	SPIGOT SCREW 10PC
000C	KW710658	SPANNER
000D	KW712210	DOUGH HOOK ALUMINIUM
000E	KW712212	WHISK 9 WIRE ALUMINIUM
000F	AW20010011	KWSK001 SOFT-SPATULA KW
000H	KW715830	SPLASHGUARD ASSY
000I	KW716134	STALL PLUG
000J	AW20011024	KAT521SS ELITE CHEF SS BOWL
000K	KW716959	GEARBOX ASSEMBLY WITHOUT PLANET HUB
000L	AW20011057	KAT51.000SS ATT KW CHEF WHISK SS INT
000M	KW717244	HEAD RELEASE LATCH PLATE MIM KIT
000N	KW717447	FOOT GREY GY43 - PACK 5
000O	AS00001021	SSO SEAL x5
000P	AS00002915	GEARBOX ASSY
01	KW716647	SLOW SPEED OUTLET COVER ASSEMBLY
02	KW716641	HIGH SPEED OUTLET COVER ASSEMBLY
003	KW715797	SPIGOT SCREW 3PC
004	KW715857	HSO SPIGOT HSO GY34
005	KW715796	SPIGOT SEAT PLATE
06	KW716646	TOP COVER ASSEMBLY
07	KW716640	HEAD UNDERSIDE
008	KW711986	SHAFT ASSY CHEF CIRCLIP
08	KW716639	SEPARATOR
09	KW716644	PEDESTAL
010	KW650300	FOOT GREY 5PC
11	KW711918	BOWL SEAT PAD CHEF (14cm)
14	KW716648	HEADLIFT LEVER ASSEMBLY
15	KW716649	HEADLIFT LATCH ASSEMBLY
016	KW715790	LOCATION PIN
017	KW715791	HINGE PIN & E CLIP
018	KW715792	HEADLIFT SPRING
019	KW717244	HEAD RELEASE LATCH PLATE MIM KIT
020	KW715812	CHASSIS
021	KW715816	CHASSIS DOWL 4PC
022	KW674746	GEARBOX TOP MOUNT
023	KW715813	GEARBOX ASSEMBLY COMPLETE - CHEF

GB KVC5100S

KVC5100S KITCHEN MACHINE -
CHEF ELITE

024	KW715817	PANET HUB ASSY CHEF COVER & HUB NUT
025	KW715819	HUB NUT 3PC
026	KW715810	PANET HUB SEAL SET
027	KW715814	SSO ASSY O RING & SCREW
028	KW715818	SLOW SPEED OUTLET O RING 3PC
029	KW715809	GEARBOX MOUNT 4PC
030	KW715815	GEARBOX BOLT & WASHER SET 6PC
031	KW715858	GEARBOX PULLEY & M8 NUT 2PC
032	KW715787	TIMING BELT
033	KW715794	WASHER PLASTIC 3PC
35	KW716650	MOTOR RETAINING SCREW AND BUSH SET
36	KW716642	MOTOR ASSEMBLY
38	KW716645	SPEED CONTROL ASSEMBLY
039	KW715795	SPEED CONTROL RETAINING SPRING
40	KW715800	HEADLIFT MICROSWITCH ASSY
42	KW716643	PCB
043	KW715831	PCB & CORD HOUSING MOULDING
044	KW715807	PCB & CORD HOUSING
045	KW715806	CORD ENTRY MOULDING PRINTED
46	KW715820	POWER CORD ASSY (GB) PLUG