













INT KVL4120S

KVL4120S KITCHEN MACHINE - XL

Position	Code	description
000A	KW672839	SPIGOT SCREWS (PACK 3) 3PC
000B	KW675025	MOTOR PULLEY & PIN
000C	KW710658	SPANNER
000D	KW716840	WHISK MAJOR 12 WIRES - STAMPED EU
000E	KW712208	WHISK 12 WIRE
000F	KW715814	SSO ASSY O RING & SCREW
000G	KW716134	STALL PLUG
000H	KW716336	PROTECTIVE CASE FOR MAJOR
000I	AW20011051	KAT71.000SS KW WHISK SS INT
000J	KW717447	FOOT GREY GY43 - PACK 5
000K	AW20011062	KAT70.000CA KW CHEF XL K BEATER ALU INT
000L	AS00001021	SSO SEAL x5
01	KW716661	HIGH SPEED OUTLET COVER ASSEMBLY
02	KW696201	SPIGOT LIGHT GREY
03	KW696213	SPIGOT SEAT PLATE
04	KW716662	TOP COVER
05	KW716660	SLOW SPEED OUTLET COVER ASSEMBLY
06	KW716558	BELT
07	KW696380	BOLT
008A	KW716668	GEARBOX ASSEMBLY
008B	AS00004377	GEARBOX ASSY
09	KW715823	PLANET HUB ASSY
10	KW650099	DOWEL TUBE
11	AS00006835	FELT GEARBOX COVER LOWER
12	KW716657	HEAD UNDERSIDE
13	KW649973	BUSHES (10 PIECES)
14	KW716658	BODY
15	KW716653	SEPARATOR
16	KW716659	MOTOR ASSEMBLY
17	KW716656	ASSIEME DI CONTROLLO DELLA VELOCITÀ
18	KW696354	QUADRANT AND BRACKET
19	KW716652	COVER
20	KW710224	TERMINAL COVER 3 CORE LEAD
21	KW715468	COUNTER BALANCE PIN KIT
22	KW696366	SPRING
23	KW716654	PEDESTAL (CHEF XL)
24	KW716663	POWER SUPPLY CORD WITH PLUG (EU)

INT KVL4120S

KVL4120S KITCHEN MACHINE - XL

25	KW716667	HEADLIFT LEVER ASSEMBLY
26	KW650300	FOOT GREY 5PC
27	KW711919	BOWL SEAT PAD MAJOR 15cm
29	KW712204	DOUGH HOOK
31	KW716119	SPLASHGUARD ASSY
32	AW20010012	HIGH-TEMPERATURE SPATULA KW
33	AW20011029	KAT400SS - CHEF XL STAINLESS STEEL BOWL