

























## CH KVC5350S

KVC5350S KITCHEN MACHINE -  
CHEF ELITE

| Position | Code       | description                          |
|----------|------------|--------------------------------------|
| 000A     | KW649973   | BUSHES (10 PIECES)                   |
| 000B     | KW675013   | SPIGOT SCREW 10PC                    |
| 000C     | KW710658   | SPANNER                              |
| 000D     | KW711986   | SHAFT ASSY CHEF CIRCLIP              |
| 000E     | KW712210   | DOUGH HOOK ALUMINIUM                 |
| 000F     | KW712212   | WHISK 9 WIRE ALUMINIUM               |
| 000G     | AW20010011 | KWSK001 SOFT-SPATULA KW              |
| 000H     | KW716134   | STALL PLUG                           |
| 000I     | KW716725   | BOWL ASSEMBLY                        |
| 000J     | KW716959   | GEARBOX ASSEMBLY WITHOUT PLANET HUB  |
| 000K     | AW20011057 | KAT51.000SS ATT KW CHEF WHISK SS INT |
| 000L     | KW717244   | HEAD RELEASE LATCH PLATE MIM KIT     |
| 000M     | KW717447   | FOOT GREY GY43 - PACK 5              |
| 000N     | AS00001021 | SSO SEAL x5                          |
| 000O     | AS00002915 | GEARBOX ASSY                         |
| 01       | KW716647   | SLOW SPEED OUTLET COVER ASSEMBLY     |
| 02       | KW716641   | HIGH SPEED OUTLET COVER ASSEMBLY     |
| 003      | KW715797   | SPIGOT SCREW 3PC                     |
| 004      | KW715857   | HSO SPIGOT HSO GY34                  |
| 005      | KW715796   | SPIGOT SEAT PLATE                    |
| 06       | KW716646   | TOP COVER ASSEMBLY                   |
| 07       | KW716640   | HEAD UNDERSIDE                       |
| 08       | KW716639   | SEPARATOR                            |
| 09       | KW716644   | PEDESTAL                             |
| 010      | KW650300   | FOOT GREY 5PC                        |
| 11       | KW711918   | BOWL SEAT PAD CHEF (14cm)            |
| 14       | KW716648   | HEADLIFT LEVER ASSEMBLY              |
| 15       | KW716649   | HEADLIFT LATCH ASSEMBLY              |
| 016      | KW715790   | LOCATION PIN                         |
| 017      | KW715791   | HINGE PIN & E CLIP                   |
| 018      | KW715792   | HEADLIFT SPRING                      |
| 019      | KW717244   | HEAD RELEASE LATCH PLATE MIM KIT     |
| 020      | KW715812   | CHASSIS                              |
| 021      | KW715816   | CHASSIS DOWL 4PC                     |
| 022      | KW674746   | GEARBOX TOP MOUNT                    |
| 023      | KW715813   | GEARBOX ASSEMBLY COMPLETE - CHEF     |
| 024      | KW715817   | PANET HUB ASSY CHEF COVER & HUB NUT  |

## CH KVC5350S

KVC5350S KITCHEN MACHINE -  
CHEF ELITE

|     |            |                                                                                 |
|-----|------------|---------------------------------------------------------------------------------|
| 025 | KW715819   | HUB NUT 3PC                                                                     |
| 026 | KW715810   | PANET HUB SEAL SET                                                              |
| 027 | KW715814   | SSO ASSY O RING & SCREW                                                         |
| 028 | KW715818   | SLOW SPEED OUTLET O RING 3PC                                                    |
| 029 | KW715809   | GEARBOX MOUNT 4PC                                                               |
| 030 | KW715815   | GEARBOX BOLT & WASHER SET 6PC                                                   |
| 031 | KW715858   | GEARBOX PULLEY & M8 NUT 2PC                                                     |
| 032 | KW715787   | TIMING BELT                                                                     |
| 033 | KW715794   | WASHER PLASTIC 3PC                                                              |
| 35  | KW716650   | MOTOR RETAINING SCREW AND BUSH SET                                              |
| 36  | KW716642   | MOTOR ASSEMBLY                                                                  |
| 38  | KW716645   | SPEED CONTROL ASSEMBLY                                                          |
| 039 | KW715795   | SPEED CONTROL RETAINING SPRING                                                  |
| 40  | KW715800   | HEADLIFT MICROSWITCH ASSY                                                       |
| 42  | KW716643   | PCB                                                                             |
| 043 | KW715831   | PCB & CORD HOUSING MOULDING                                                     |
| 044 | KW715807   | PCB & CORD HOUSING                                                              |
| 045 | KW715806   | CORD ENTRY MOULDING PRINTED                                                     |
| 47  | AW20011024 | KAT521SS ELITE CHEF SS BOWL                                                     |
| 48  | KW715830   | SPLASHGUARD ASSY                                                                |
| 49  | KW716547   | CHEF SPIRAL ASSY                                                                |
| 51  | KW711984   | K BEATER ASSEMBLY - STAINLESS STEEL - Chef -<br>bayonet hub & non-circlip shaft |