




































| Position | Code       | description                                  |
|----------|------------|----------------------------------------------|
| 000A     | KW412095   | BOWL MAJOR                                   |
| 000B     | KW675013   | SPIGOT SCREW 10PC                            |
| 000C     | KW710658   | SPANNER                                      |
| 000D     | KW710743   | MAGNET                                       |
| 000E     | KW716842   | POWER WHISK MAJOR                            |
| 000F     | KW712874   | WORKSURFACE PROTECTION MAT                   |
| 000G     | KW712876   | SCRAPER                                      |
| 000H     | KW716134   | STALL PLUG                                   |
| 000I     | AW20011028 | KAT911SS COOKING CHEF SS BOWL                |
| 000J     | AW20011051 | KAT71.000SS KW WHISK SS INT                  |
| 000K     | KW716591   | MOTOR ASSEMBLY                               |
| 000L     | KW717308   | DISPLAY PCB                                  |
| 000M     | AS00000401 | INPUT PULLEY                                 |
| 01       | KW716573   | HIGH SPEED OUTLET COVER ASSEMBLY             |
| 02       | KW715857   | HSO SPIGOT HSO GY34                          |
| 03       | KW716592   | SPIGOT PLATE                                 |
| 04       | KW716596   | TOP COVER                                    |
| 05       | KW716594   | SLOW SPEED OUTLET COVER INSERT               |
| 06       | KW716593   | SLOW SPEED OUTLET COVER                      |
| 07       | KW716597   | REED SWITCH TOP COVER                        |
| 08       | KW716558   | BELT                                         |
| 09       | KW716583   | MOTOR MOUNT MOLDING                          |
| 10       | KW674655   | BOLT & WASHER KIT                            |
| 11       | KW712943   | EARTH LEAD ASSY                              |
| 12       | KW715814   | SSO ASSY O RING & SCREW                      |
| 13       | AS00004384 | GEARBOX ASSY                                 |
| 14       | KW716589   | PLANET HUB ASSEMBLY                          |
| 15       | KW716595   | SOCKET                                       |
| 16       | KW716572   | HEAT GUARD REED SWITCH ASSEMBLY              |
| 17       | KW716603   | HEAD UNDERSIDE                               |
| 18       | KW716574   | PLANET HUB ASSEMBLY                          |
| 19       | KW716580   | WIRING HEAT GUARD AND INTERLOCKS TO MAIN PCB |
| 20       | KW712898   | HINGE PIN                                    |
| 21       | KW712893   | REAR SPACER                                  |
| 22       | KW716582   | BODY                                         |
| 24       | KW716564   | DISPLAY PCB                                  |

|    |          |                                       |
|----|----------|---------------------------------------|
| 25 | KW715794 | WASHER PLASTIC 3PC                    |
| 26 | KW716584 | MOTOR PULLEY AND TENSION PIN          |
| 27 | KW716579 | LCD CONTROL KNOB                      |
| 28 | KW716591 | MOTOR ASSEMBLY                        |
| 29 | KW716559 | BODY COVER                            |
| 30 | KW712897 | BODY COVER INSERT                     |
| 31 | KW716560 | PCB COVER                             |
| 32 | KW716571 | HEADLIFT SPRING                       |
| 33 | KW712902 | QUADRANT & BRACKET                    |
| 34 | KW675037 | PIN                                   |
| 35 | KW716561 | PEDESTAL                              |
| 36 | KW716568 | GROMMET SET (3x)                      |
| 37 | KW716715 | GRILL SPRING                          |
| 38 | KW712905 | EXHAUST GRILLE                        |
| 39 | KW716563 | ASSIEME DI CONTROLLO DELLA VELOCITÀ   |
| 40 | KW716565 | EARTH LEAD ASSEMBLY                   |
| 41 | KW716566 | EARTH PIN                             |
| 42 | KW716570 | HEADLIFT REED SWITCH ASSY             |
| 43 | KW716562 | BOWL REED SWITCH ASSEMBLY             |
| 44 | KW712901 | CIRCLIP                               |
| 45 | KW716569 | HEADLIFT LEVER ASSEMBLY               |
| 46 | KW710366 | HEADLIFT ASSY SPRING & LATCH PLATE    |
| 47 | KW716586 | NTC ASSEMBLY                          |
| 48 | KW712907 | HIGH TEMPERATURE SEAT PAD             |
| 49 | KW712908 | SUPPORT CASTING                       |
| 50 | KW716576 | INDUCTION COIL ASSEMBLY               |
| 51 | KW716588 | MOUNT PCB                             |
| 52 | KW716587 | MAIN PCB                              |
| 53 | KW712945 | LEAD ASSY INDUCTION PCB/POWER PCB     |
| 54 | KW712944 | EARTH LEAD ASSY                       |
| 55 | KW716590 | WIRING FROM INDUCTION PCB TO MAIN PCB |
| 57 | KW716598 | INDUCTION FAN ASSEMBLY                |
| 58 | KW716578 | INDUCTION PCB                         |
| 59 | KW716557 | BASE                                  |
| 60 | KW712911 | FOOT 6PC                              |
| 61 | KW716601 | HEAT SHIELD ASSEMBLY                  |
| 62 | KW716602 | SPLASHGUARD ASSEMBLY                  |
| 63 | KW716599 | BOWL ASSEMBLY WITH HANDLES - PRINTED  |

|    |            |                                         |
|----|------------|-----------------------------------------|
| 64 | AW20010020 | KAT91.000CL KW COOKING CHEF STEAMER INT |
| 65 | KW716575   | STIR ASSIST CLIP                        |
| 66 | KW716605   | STIRRING TOOL                           |
| 68 | AW20011050 | SPIRAL DOUGH HOOK                       |
| 69 | AWAT502002 | AT502 CREAMING BEATER                   |
| 70 | AW20011049 | KAT70.000SS KW CHEF XL K BEATER SS INT  |