



2




4





6



7







JP KPL9000S

KPL9000S KITCHEN MACHINE - XL
PRO

Position	Code	description
000A	KW630879	FOOD GRADE GREASE (100G)
000B	KW716842	POWER WHISK MAJOR
000C	KW716134	STALL PLUG
000D	KW716807	HUB SPRING
000E	AW20011051	KAT71.000SS KW WHISK SS INT
000F	KW717203	FINGER GUARD ASSEMBLY
000G	AW20011062	KAT70.000CA KW CHEF XL K BEATER ALU INT
000H	AS00001021	SSO SEAL x5
000I	AS00002919	GEARBOX ASSY
02	KW712204	DOUGH HOOK
06	KW710658	SPANNER
07	KW711919	BOWL SEAT PAD MAJOR 15cm
08	KW717032	HSO COVER ASSEMBLY - SR24
09	KW672839	SPIGOT SCREWS (PACK 3) 3PC
10	KW715857	HSO SPIGOT HSO GY34
11	KW715796	SPIGOT SEAT PLATE
12	KW717033	TOP COVER
13	KW717024	SSO COVER inc MAGNET & FOAM PAD ASSEMBLY
14	KW696380	BOLT
15	KW650099	DOWEL TUBE
16	KW650374	PLASTIC WASHER
17	KW716558	BELT
18	KW717014	PULLEY ASSEMBLY
19	KW717020	SLOW SPEED OUTLET SPIGOT SEAL
20	KW715814	SSO ASSY O RING & SCREW
21	KW715818	SLOW SPEED OUTLET O RING 3PC
22	KW717005	GEARBOX ASSEMBLY
23	KW717006	PLANET HUB ASSEMBLY
24	KW650142	GEARBOX PLUG
25	AS00006835	FELT GEARBOX COVER LOWER
26	KW716657	HEAD UNDERSIDE
27	KW649973	BUSHES (10 PIECES)
28	KW717023	BODY
29	KW717016	WIRE GUARD
30	KW717017	WIRE GUARD SCREW SET
31	KW675025	MOTOR PULLEY & PIN
32	KW717021	MOTOR

JP KPL9000S

KPL9000S KITCHEN MACHINE - XL
PRO

33	KW717022	CONTROL MODULE & KNOB ASSEMBLY 100-120V
34	KW717009	COVER PLATE
35	KW712447	BRACKET
36	KW712460	QUADRANT
37	KW717007	CORD WRAP MOULDING
38	KW712450	TERMINAL BLOCK COVER
39	KW712448	INSULATION CARD
40	KW712452	SCREW, NUT AND WASHER SET
41	KW717018	MICROSWITCH ASSEMBLY
42	KW715468	COUNTER BALANCE PIN KIT
43	KW712901	CIRCLIP
45	KW712456	INTERLOCK PIN & NUT (14mm SHAFT)
46	KW717031	PEDESTAL
47	KW717011	HEADLIFT LEVER ASSEMBLY
48	KW717025	ON/OFF PCB ASSEMBLY 100-120V
49	KW650491	ON OFF BUTON SET RED & GREEN BUTTONS
50	KW717019	PCB HOUSING
51	KW650300	FOOT GREY 5PC
52	KW717041	POWER SUPPLY CORD
53	KW717043	MOTOR MOUNT