




| Position | Code     | description               |
|----------|----------|---------------------------|
| 001      | KW713808 | COVER                     |
| 002      | KW713810 | THERMAL FUSE (240°C)      |
| 004      | KW713806 | TOP COVER MOULDING        |
| 005      | KW713807 | HANDLE                    |
| 007      | KW713815 | PLATE CATCH MECHANISM     |
| 007A     | KW714880 | PLATE CATCH MECHANISM     |
| 011B     | KW692714 | TOASTING PLATE - GRIDDLE  |
| 11AA     | KW692712 | TOASTING PLATE - SANDWICH |
| 11AB     | KW714877 | TOASTING PLATE            |
| 11AC     | KW714878 | TOASTING PLATE            |
| 015B     | KW713812 | INDICATOR                 |
| 15AA     | KW713811 | POWER ON INDICATOR        |
| 15AB     | KW714881 | LENS POWER ON             |
| 15AC     | KW714882 | LENS                      |
| 016      | KW713805 | BASE                      |
| 019      | KW713813 | FOOT (2PC)                |
| 030      | KW713804 | THERMOSTAT KIT (170°C)    |
| 036      | KW713809 | ELEMENT ASSY (350W)       |
| 043      | KW713814 | MICA SHEET                |