























Position	Code	description
001	3215811	COVER
002	040033003	BUMPER
003	040020003	RUBBER PAD
004	040017003	RUBBER PAD
005	217420	GRID
006	001003	SCREW
007	085015	BUSH
008	330584221	WORK TOP
009	3415840C11	FEED ASSY
010	027015	Inlet pipe plug
012	214021	NUT
013	003015	WASHER
014	001040	SCREW
015	46H5005	CLOSURE
016	4115007	REAR PANEL
017	094063	HOOK
018	037177035	HANDLE
019	36C50063	SIDE
020	001007	Vis
021	371A58013	DOOR
022	373A5804M	INNER DOOR
023	217224	GRID
024	063034	HINGE
025	035009	SPRING
026	063033	HINGE
027	071042003	PEG
028	063010	HINGE
029	373V5001M	INNER DOOR
030	371V50023	DOOR
031	053063	GASKET
032	035097	Rotisserie hole plug
036	001083	SCREW
037	103205.1	WASHER
038	373F50101	INNER DOOR
039	083123035	PROFILE
040	037176035	HANDLE
041	0312394	GLASS

042	094100	BRACKET
043	040011	BUFFER
044	083100035	PROFILE
045	063081	HINGE
046	063066	Top oven hinge (female) works with male hinge 063096
047	0312484TH	GLASS
048B	215173	SR burner
048C	215174	BURNER R
048D	215175	UR burner
049	001017	SCREW
050A	101075	Injector - diameter 0.47
050B	101076	INJECTOR d. 0,62
050C	101077	INJECTOR d. 0,78
050D	101078	INJECTOR d. 0,86
050E	101066	Injector - diameter 0.70
050F	101128	INJECTOR d. 0,88
050G	101129	Injector - diameter 1.15
050H	101090	INJECTOR d. 1,25
051A	024019	A-SR air regulation tube
051B	024020	REGULATOR R
051C	024021	UR air regulation tube
052	001282	Tap fixing screw
053	027018P	HOSE COUPLING
054	094654	Tap bracket
055A	106260	TAP
055B	106261	TAP
055C	106262	TAP
055D	106263	TAP
056	218H646303	KNOB
058	029405	PIPING
059	029466	TUBE UR
060	029406	PIPING
061	053024.1	Sealing washer
062A	216087611	FLAME BAFFLE A
062B	216088620	FLAME BAFFLE SR
062C	216089624	FLAME BAFFLE R
062D	216090622S	FLAME BAFFLE UR

063A	068050002	GLASS
063B	068051002	GLASS
063C	068052002	GLASS
063D	068053002S	GLASS
064	107009	Thermocouple L=450 mm
065	R00550280	BRASS NUT FOR THERMOCOUPLE
067	062034004	HEATING ELEMENT
068	103097	BAFFLE
069	217222	GRID
070	48B5001G	DRIP PAN
071	47E5001G	BOTTOM
072	4215001Z	CLOSURE
074	062037004	HEATING ELEMENT
075	050050	CHANGE OVER SWITCH
076	066049	THERMOSTAT
077	218H026302	KNOB
080	35C58423D3	FRONT PIECE
081	213007	CLIP
082	035065	SPRING
083	217275	Small grate
084	050017/E	CHANGE OVER SWITCH
085A	04706230	PLATE
085B	04703230	PLATE
086	218H926302	KNOB
087A	103084R	Normal/rapid plate protection diam 145
087B	103081R	Normal/rapid plate protection diam 180
088	214055	NUT
089	073038.2	Control lamp L=200
090	073034	Control lamp cover (Orange)
091	052008	Cable clamp - rear cooker
092	073013001	LAMP
093	072033	LAMP HOLDER
094	103230.1A	Terminal block protection
098	113807	WIRING