






























66





Position	Code	description
000A	NOCODE04	SEE TECHNICAL BULLETIN
000B	NOCODE04	SEE TECHNICAL BULLETIN
000C	5032111900	POWER SUPPLY CORD WITH PLUG (SCHUKO)
000D	5313256701	GENERATOR COVER
000E	5313225171	A Y CONNECTION
000F	5332224100	MOTOR BELT
000G	5513211891	SCRAPER BRUSH WITH BRISTLES
000H	6113210111	FIXING BRACKET (TCO)
000I	6113210121	SENSOR BRACKET
000J	5313219181	GRINDER BELLOW GASKET
000K	5313213451	COFFEE HOSE CLAMP
000L	AS00006031	GRINDER FINGER STOP RING
000M	AS00000378	ECOMULTICLEAN 10ML VIAL
000N	6013211721	PLATE
001	5313221031	GROUND COFFEE TANK COVER
002	AS00010434	COFFEE BEANS COVER
003	7313223841	UPPER COVER
004	5913212611	GRIND REGULATION KNOB
005	5313223661	REAR PANEL
006	5313226851	LEFT SIDE
007	AS00001792	COFFEE BEANS TANK
008	5313223081	CUP HOLDER INSULATION
009	AS00006115	SWITCH HOLDER
010	5313223641	RIGHT SIDE
011	AS00009990	DLS-COVER TANK SMOKE(C8-11)(SAN) ECAM
012	AS13200250	TANK
012A	AS00010091	WATER TANK
013	5313223631	WATER TANK FRONT PIECE
014	AS00008460	DLS-CONT COF.GROUNDS BK(ABS)+BAG ECAM37
015	5313223611	FRONT PIECE
016	6013210511	CUP HOLDER
017	5313224851	CUP HOLDER TRAY
018	5313222641	FLOAT
019	5132112500	SWITCH
020	5313223621	COFFEE GROUNDS CONTAINER FRONT
021	5313213551	DRAIN TRAY
025	7313223861	CONTROL PANEL ASSEMBLY WITHOUT BOARD

026	5513220041	DISPLAY BOARD
027	5313213911	COFFEE OUTLET TANK COVER
028	5313213901	COFFEE OUTLET TANK
029	6132106200	SPRING
030	5332227400	REGULATOR
031	5313213881	GUIDE DISPENSER COVER
032	5313215321	DISPENSER HANDLE
033	5313215311	CONVEYOR EXTERNAL PART
034	9812631250	SCREW (3.5X12)
035	7313221801	COVER
036	5332177000	WATER INTAKE TUBE
037	5513213511	HOT WATER SPOUT
038	5313231231	CARAFE
039	6132101300	SPRING
040	53132D0730	O RING
041	5313221011	O-RING (D6.07 T1.78)
042	9813421316	SCREW (2.9X13)
043	5313218821	COUPLING MICRO SUPPORT (IFD)
044	5132104100	MICROSWITCH (250V 85°)
047	5232104600	REED SENSOR
048	5213213921	POWER BOARD (SW1.0 230V)
049	5313224721	RUBBER FOOT PAD
050	5313220131	COUPLING RUBBER PAD SEAL
051	7313244781	CARAFE COUPLING
054	7313251451	INFUSER
055	6113210131	SPRING
056	5313213241	EXPULSION LEVER RUBBER PAD
057	5313213191	EXPULSION LEVER
058	9812631250	SCREW (3.5X12)
059	6013213181	FILTER (D.40X2.3 TAI-FENG)
060	5313277681	STOPPER
061	53132C9532	FROTH DEVICE VALVE NATURAL(PSU)ESAM&ECAM
062	6132112200	SPRING
063	5313238581	GASKET
064	5313213211	BOTTOM PISTON
065	5313227651	FINGER STOP COVER
066	7313294110	GRINDER ASSEMBLY

067	5313236711	RIGHT ANGLE WATER OUTLET TUBE (90° L=190)
068	5213218421	SOLENOID VALVE (3VB 230V)
069	5313217701	O-RING (D=3.85 T=2)
070	9812631250	SCREW (3.5X12)
071	5313213591	TROLLEY SLEWING RING
072	AS00006298	TROLLEY
073	7313295821	COMPENSATION SYSTEM
074	5313213431	GASKET
075	AS13200017	TRANSMISSION ASSEMBLY (ECM 230V)
076	AS00008306	DLS-PCB FILTER MOTOR(GDS-CN)230V ECAM
077	5132110500	MICROSWITCH (250V 85°)
078	7313217261	MOTOR WITH PULLEY (ECM 230V)
079	5213213981	HALL SENSOR (L780)
080	5313243071	TOOTHED BELT
082	5132104100	MICROSWITCH (250V 85°)
083	5313238581	GASKET
084	5313217601	BLACK FILTER
085	5513227961	MECHANICS VALVE (DLS ECAM)
086A	5313217861	TUBE (DI=3 DE=5,5 L145)
086B	5313217871	TUBE (DI=3 DE=6 L200)
086C	5332199500	SILICONE HOSE (DI=4 DE=8 L=150)
087A	5513212871	TUBE WITH 2 BUSHES (L97)
087B	5513212881	TUBE WITH 2 BUSHES (L270)
087C	5513212901	TUBE WITH 2 BUSHES (L290)
087D	5513213901	TUBE WITH 2 BUSHES (L320)
087E	5513219871	TUBE WITH NUT AND 1 BUSH (L460)
088	5313217701	O-RING (D=3.85 T=2)
089	6132101300	SPRING
090	5113270613	PUMP (230V)
091	5513230831	FLOW REGULATOR
092	5313230671	PUMP SUPPORT
093	5213214061	SENSOR (NTC)
094	5332239300	SPACER
095	5313228791	GENERATOR GASKET
096	6113213191	CLIP (WIRE 1,2 AISI302)
097	7313219401	SAFETY VALVE
098	5113210211	MICROSWITCH
099	5213225251	FLOWMETER

100	5332239200	CONNECTOR
101	5213211161	PUMP PROTECTOR
102	5513236251	BOILER (230V)
103	5013256811	TCO WITH WIRING (L640 - L130)
104	5013256851	TCO WITH WIRING (L820 - L80)
105	5513214661	CAM SLIDER
108	6113213191	CLIP (WIRE 1,2 AISI302)
109	5313224491	SOLENOID VALVE SUPPORT
110	NOCODE04	SEE TECHNICAL BULLETIN
111	6213210351	NUT
112	6213211521	BRASS BUSH
113	6113211331	CONNECTION
114	6113210741	RING
115	5213216261	TCO (13.5A 318°)
116	5213218311	SOLENOID VALVE (2VB 230V)