










Position	Code	description
000A	5313213911	COFFEE OUTLET TANK COVER
000B	5313224561	INNER COVER
000C	5332224100	MOTOR BELT
000D	9828300000	PUSH-PUSH
000E	5513211891	SCRAPER BRUSH WITH BRISTLES
000F	6113210111	FIXING BRACKET (TCO)
000G	6113210121	SENSOR BRACKET
000H	5313219181	GRINDER BELLOW GASKET
000I	5313225641	DUCT SUPPORT
000J	5313213451	COFFEE HOSE CLAMP
000K	AS00000378	ECOMULTICLEAN 10ML VIAL
000L	6013211721	PLATE
001	5513216231	REAR PANEL
002	7313220771	COFFEE BEANS COVER
003	5313248331	GROUND COFFEE COVER
004	5513216841	AROMA SEAL COVER
005	NOCODE04	SEE TECHNICAL BULLETIN
006	5313233411	UPPER COVER
007	7313226531	CONTROL PANEL ASSEMBLY
009	7313220791	COVER ASSEMBLY
010	5332177000	WATER INTAKE TUBE
013	5313231231	CARAFE
014	53132C8134	MEASURING SPOON
015	5313225791	WATER TANK COVER
016	5513216211	RIGHT SIDE
017	5513216221	LEFT SIDE
018	5313213291	HOSE COUPLING COVER
019	5313235921	TANK GASKET
020	5313214981	WATER TANK FILTER
023	6113210251	SPRING
024	AS13200257	WATER TANK
025	NOCODE04	SEE TECHNICAL BULLETIN
026	5513216181	WATER TANK FRONT PIECE
027	7313226521	COFFEE DISPENSER
028	7013213121	CUP HOLDER
029	5513232341	COFFEE GROUNDS CONTAINER
030	5313213551	DRAIN TRAY

032	NOCODE04	SEE TECHNICAL BULLETIN
033	5313222641	FLOAT
034	5313226961	CUP HOLDER TRAY
035	5332177500	O-RING
036	5313217751	O-RING BLACK (D=6.07 T=1.78)
037	5332169300	LOWER TUBE
038	AS00008426	TUBE
039	5913212631	GRIND REGULATION KNOB
040	5313225891	SCREW COVER
041	5513227111	LED BOARD
042	9812631250	SCREW (3.5X12)
043	5313227651	FINGER STOP COVER
044	7313251451	INFUSER
045	5313213191	EXPULSION LEVER
046	6013213181	FILTER (D.40X2.3 TAI-FENG)
047	53132C9532	FROTH DEVICE VALVE NATURAL(PSU)ESAM&ECAM
048	5313238581	GASKET
049	6113210131	SPRING
050	5313277681	STOPPER
053	6132112200	SPRING
054	5313213211	BOTTOM PISTON
055	5313213241	EXPULSION LEVER RUBBER PAD
056	5313213591	TROLLEY SLEWING RING
057	AS00006298	TROLLEY
058	5313224471	VAPORIZER PROTECTION
059	7313295821	COMPENSATION SYSTEM
060	6113210161	PIN
061	9820000480	WASHER (D.4 4.3X10X1)
062	9813431616	SCREW (3.5X16)
063	5513243271	RIGHT FRAME
064	7313294110	GRINDER ASSEMBLY
065	5113210211	MICROSWITCH
066	5313231031	SWITCH HOLDER
067	5113211621	SWITCH (16A 125/250V)
068	5232114100	CONNECTOR
069	53132C7925	MOBILE FUNNEL
070	5313213371	PISTON LOWERING FLAP

071	5113270613	PUMP (230V)
072	NOCODE04	SEE TECHNICAL BULLETIN
073	6113210201	SPRING
074	AS00006012	TROLLEY SUPPORT
075	5313213391	EXPULSION ARM
076	6113210181	SPRING
077	5313213431	GASKET
078	AS00009830	LEFT FRAME
079	5313229731	RUBBER FOOT PAD
080	5513219881	TUBE WITH NUT AND 1 BUSH (L270)
081	9813433816	SCREW (3.5X38)
082	5013211551	POWER SUPPLY CORD WITH PLUG (AU)
083	5513219871	TUBE WITH NUT AND 1 BUSH (L460)
084	5313217701	O-RING (D=3.85 T=2)
085	5513212871	TUBE WITH 2 BUSHES (L97)
086	5213216261	TCO (13.5A 318°)
087	5213211161	PUMP PROTECTOR
088	6132101300	SPRING
089	5513230831	FLOW REGULATOR
090	5313230671	PUMP SUPPORT
091	5332199500	SILICONE HOSE (DI=4 DE=8 L=150)
093	5213214061	SENSOR (NTC)
094	5213225251	FLOWMETER
095	5313236711	RIGHT ANGLE WATER OUTLET TUBE (90° L=190)
096	AS13200017	TRANSMISSION ASSEMBLY (ECM 230V)
097	7313217261	MOTOR WITH PULLEY (ECM 230V)
098	5313228791	GENERATOR GASKET
099	5213218311	SOLENOID VALVE (2VB 230V)
101	5313243071	TOOTHED BELT
102	5213213981	HALL SENSOR (L780)
103	5213226181	MOTOR BOARD (ECM 230V)
104	5132110500	MICROSWITCH (250V 85°)
105	5513213101	TUBE WITH 2 BUSHES (L380)
106	5313227841	RIGHT ANGLE DRAIN CONNECTION
107	5513212901	TUBE WITH 2 BUSHES (L290)
108	5332239200	CONNECTOR
109	5313225171	A Y CONNECTION
110	5313224491	SOLENOID VALVE SUPPORT

111	5213218421	SOLENOID VALVE (3VB 230V)
112	5313225161	SOLENOID VALVE CAP
113	5513213761	TUBE WITH 2 BUSHES (L190)
114	5513212881	TUBE WITH 2 BUSHES (L270)
116	7313219401	SAFETY VALVE
117	5313217871	TUBE (DI=3 DE=6 L200)
118A	5313256701	GENERATOR COVER
118B	5313256701	GENERATOR COVER
119	5113210211	MICROSWITCH
120	5513236251	BOILER (230V)
121	5313218351	DOUBLE CONNECTION
123	5013256851	TCO WITH WIRING (L820 - L80)
124	5013256811	TCO WITH WIRING (L640 - L130)
125	5332239300	SPACER
126	6113213191	CLIP (WIRE 1,2 AISI302)
127	5513213901	TUBE WITH 2 BUSHES (L320)
128	5213218321	SOLENOID VALVE (2VA 230V)
129	5132104100	MICROSWITCH (250V 85°)
130	5313218821	COUPLING MICRO SUPPORT (IFD)
133	7313253171	MECHANICS VALVE (ECAM)
135	5313238581	GASKET
136	5313217601	BLACK FILTER
137	9812631250	SCREW (3.5X12)
138	5313220131	COUPLING RUBBER PAD SEAL
139	7313244361	CARAFE COUPLING
140	53132D0730	O RING
143	5313221011	O-RING (D6.07 T1.78)
144	6132101300	SPRING
145	5132104100	MICROSWITCH (250V 85°)
146	5232104600	REED SENSOR
147	6213210351	NUT
148	6213211521	BRASS BUSH
149	6113211331	CONNECTION
150	6113210741	RING
151	5213215201	POWER BOARD (SW1.1 230V)