










Position	Code	description
00YY	AS00010390	CAPSULE HOLDER
01	AS00001036	PUSH BUTTON
02	AS00001038	FUNNEL
03	AS00001039	MOTOR
04	AS00001040	SUPPORT
05	AS00001041	MOTOR ASSEMBLY
006A	AS00001042	ELECTRONIC BOARD
006B	AS00004416	ELECTRONIC BOARD
07	AS00001043	INTERNAL BODY
08	AS00001044	SENSOR
009A	AS00001045	DOOR
009B	AS00004415	DOOR
10	AS00001046	BASE WITH RUBBER PADS
11	AS00001047	WATER TANK ASSEMBLY
012A	AS00004892	HEAD
012B	AS00004892	HEAD
13	AS00004407	UPPER COVER
15	AS00004410	RING
18	AS00001057	CUP HOLDER
19	AS00001060	DRIP TRAY
23	AS00001061	PUMP ASSEMBLY
28	AS00001062	WIRING
30	AS00001063	WIRING
31	AS00001064	FLOWMETER
33	NOCODE01	NOT AVAILABLE
41	AS00001067	DISC
42	AS00001068	SPRING
44	AS00001069	BELT
47	AS00001070	WIRING
048A	AS00001071	CONNECTOR
048B	AS00004414	CONNECTOR
49	AS00001074	SUPPORT
55	AS00001075	PIN
57	AS00001076	LEFT SIDE
58	AS00001077	RIGHT SIDE
59	AS00001078	REAR COVER
60	AS00001079	UPPER COVER

63	AS00001080	DRIP TRAY
64	AS00001081	CAPSULE CONTAINER
68	AS00001082	DAMPER