





















Position	Code	description
1= 1.1	103630063	Rear trim
2= 1.2	355VC9E02	Glass with frame
3= 1.3	4219E03Z	Module induction support
4= 1.5	040041001	PLUG
5= 1.6	001285	Stainless steel screw
6= 1.7	094763	Control PCB support
7= 1.8	103672	WIRE CLAMP
8= 1.9	074117	PCB
9= 1.10	074116	CONTROL PCB
10= 1.11	1031512	Module induction left
11= 1.12	1031513	Module induction right
12= 1.13	531533	TUBE RETAINER
13= 1.14	071068	Standoff
14= 1.15	094762	Module support bracket
15= 1.21	1132063	Module wiring
16= 1.22	1132064	PCB- PCB control connection
17= 1.23	1132065	PCB control - module induction connection
18= 1.24	1132066	PCB- encoders connection
19= 1.25	052007	Wire ring
20= 1.26	094725	Rear bracket
21= 1.27	094417DX	Rear hob support right
22= 1.28	094417SX	Rear hob support left
23= 3.1	0329E029	CONTROL PANEL
24= 3.2	35M9E006A	Interior control panel
25= 3.3	213007	CLIP
26= 3.5	1031191	Control panel trim
27= 3.6	2183009464	KNOB
28= 3.7	050028.1	Oven switch
29= 3.8	066183	THERMOSTAT
30= 3.9	050095	Encoder
31= 4.1	450F91EM42	Oven frame
32= 4.2	211016	RIVET
33= 4.3	053146	SEAL
34= 4.4	066182	Oven thermostat
35= 4.5	001174	SCREW
36= 4.6	4119E01	REAR PANEL
37= 4.7	4219E01Z	Upper shelter

38= 4.8	030219	Oven insulation
39= 4.9	030242	Rear insulation
40= 4.10	45B9E001G	Body front panel
41= 4.11	51B9E01	PROFILE
42= 4.12	45K96004Z	Lower element cover
43= 4.13	51B9E02	Profile posterior gauche
44= 4.14	51B9E03	Profile posterior right
45= 4.15	51B9E04	Posterior lower panel
46= 4.16	103672	WIRE CLAMP
47= 4.17	1031411	BRACKET
48= 4.19	085113	Douille
49= 4.20	079056	Tangential fan
50= 4.21	4219E02Z	rconveyorsupport
51= 4.22	51B9E12	Shield
52= 4.23	094153	Anti tilt bracket
53= 4.24	001112	SCREW
54= 4.25	1031207	Lock pin
55= 4.26	36C96D1S	Side panel right
56= 4.27	36C96S1S	Side panel left
57= 4.28	001069	SCREW
58= 4.29	001007	Vis
59= 4.30	081083/NS	Right stopper
60= 4.31	081084/NS	Left stopper
61= 4.32	063130	Door hinge (female)
62= 4.33	040076	BUFFER
63= 4.34	040086	BUFFER
64= 4.35	001270	SCREW
65= 4.36	003085	WASHER
66= 4.37	040085/DX	Spacer right
67= 4.38	040085/SX	Spacer left
68= 4.39	1031295.1	SHIM L.150-180
69= 4.40	001009	SCREW
70= 4.44	001007	Vis
71= 4.45	001172	SCREW
72= 4.46	51B9604	REINFORCEMENT
73= 4.48	1031283	Element support
74= 4.47	094671	Equerre
75= 4.49	421F908Z	LOWER PROTECTION

76= 4.23	371V9601L	FRONT PANEL
77= 4.24	373V9601A	Inside panel
78= 4.25	063075	HINGE
79= 4.42	040056	Rubber
80= 4.43	001089	SCREW
81= 4.44	001007	Vis
82= 5.1	032C2918DL	DOOR GLASS
83= 5.2	001288	SCREW
84= 5.3	037284009	HANDLE
85= 5.4	001266	SCREW
86= 5.5	001311	SCREW
87= 5.6	0312893	Inner glass
88= 5.7	001292	SCREW
89= 5.8	001270	SCREW
90= 5.9	040082	Rubber
91= 5.10	053157	SEAL
92= 5.11a	063131	Oven door hinge
93= 5.11b	063132	Oven door hinge
94= 5.12	069095	Corner door lower right
95= 5.13	069096	Corner door lower left
96= 5.14	069097	Retainer door glass
97= 5.15	069098	Support door glass
98= 5.16	069103	Corner door upper right
99= 5.17	069104	Corner door upper left
100= 5.18	069105	Right bracket
101= 5.19	069106	Left bracket
102= 5.20	094714	Right bracket
103= 5.21	094715	Left bracket
104= 5.23	085108	Plaque
105= 5.24	1031413	Botton spacer central
106= 5.25	51B9E07A	Lower bar
107= 5.26	51B9E08A	Top door bar
108= 5.27	51BF901A	Right door trim
109= 5.28	51BF902A	Left door trim
110= 8.1	2183009464	KNOB
111= 8.4	001256	SCREW
112= 8.5	213026	CLIP
113= 8.15	050028.1	Oven switch

114= 8.16	066182	Oven thermostat
115= 8.17	062157004	Top + grill element
116= 8.18	062146004	Bottom element
117= 8.19	51B9E09	Bottom element support
118= 8.20	079008001F	Fan motor - 230 V
119= 8.21	001245	SCREW
120= 8.22	062135004	Fan element 2.5 kw
121= 8.23	001081	SCREW
122= 8.24	47AF9020	Fan diffuser
123= 7.1	217659	Shelf support
124= 7.2	001142	Shelf support screw
125= 7.4	217650	OVEN SHELF
126= 7.5	48BF902G	Oven tray
127= 7.6	085109	Rotisserie screw
128= 7.7	085110	Rotisserie bush
129= 7.10	080037	Rotisserie spear (including handle)
130= 7.11	079053	Rotisserie motor
131= 7.12	217652	Rotisserie support
132= 7.13	217651	Grill pan grid
133= 7.14	037144	Grill pan grid handle
134= 9.1	074105	Electronic timer
135=11.1	072026	LAMP HOLDER
136=11.3	073092	Control lamp cover
137=11.4	073091	Control lamp L = 230
138=11.6	066145	Cut-off thermostat 80 degrees
139=11.14	051068	Terminal block
140=11.16	1132164	WIRING
141=11.12	050058	Knob switch
142=11.13	2183009464	KNOB