















Position	Code	description
0= 1.1	103630063	Rear trim
1= 1.5	040041001	PLUG
2= 1.6	001007	Vis
3= 2.1	3429S50001	Manifold
4= 2.2	3319S502S	Cooktop
5= 2.5	51B9S01	Burners support
6= 2.6	027015	Inlet pipe plug
7= 2.12	053024.1	Sealing washer
8= 2.13	103615	PIN
9= 2.14	035100	SPRING
10= 2.15	217530	Pan-support
11= 2.16	217534	Central pan support
12= 2.17	214062	NUT
13= 2.18	094473	Fixing plate
14= 2.19	217303	Grate for small pans
15= 2.20	51B9S05	Cross-piece
16= 2.23	001234.1	Stainless steel screw V
17= 2.26	001167	SCREW
18= 2.27	217498	Grid for woks
19= 3.1	35N9184LDA	CONTROL PANEL
20= 3.2	103760	Control panel trim
21= 3.8	213007	CLIP
22= 4.4	030267	Oven insulation
23= 4.5	030213	Rear insulation
24= 4.6	094417DX	Rear hob support right
25= 4.7	094417SX	Rear hob support left
26= 4.8	4119602	REAR PANEL
27= 4.9	4219T06Z	Upper shelter
28= 4.13	053101	SEAL
29= 4.18	6308504	SHIM
30= 4.20	040061	BUFFER
31= 4.21	063075	HINGE
32= 4.23	371V9601L	FRONT PANEL
33= 4.24	373V9601A	Inside panel
34= 4.25	36C96D1S	Side panel right
35= 4.26	36C96S1S	Side panel left
36= 4.31	094412	BRACKET

37= 4.32	4219604Z	Rear insulation support
38= 4.33	4216108Z	Hinge protection
39= 4.34	035097	Rotisserie hole plug
40= 4.36	081084/NS	Left stopper
41= 4.37	081083/NS	Right stopper
42= 4.38	46A9S02Z	Air conveyor
43= 4.39	46A9S01Z	FUNNEL
44= 4.40	079025	Tangential fan
45= 4.42	040056	Rubber
47= 4.48	6300040	Anti tilt bracket
48= 4.50	4419S1EM102	Oven frame
55= 5.1	0312662	DOOR GLASS
56= 5.2	083240061	Lower door trim
57= 5.3	037195062	Door handle
58= 5.4	103713	Door handle plaque
59= 5.5	51B9605	Handle trim
60= 5.6	001030	SCREW
61= 5.8	063146	Door hinge (male)
62= 5.9	063148	Door hinge (female)
63= 5.10	373F9606G	Door panel
64= 5.11	053058	GASKET
65= 5.12	0311292/TH	Inner glass
66= 5.14	214021	NUT
67= 5.15	001143	SCREW
68= 5.16	003035	WASHER
69= 5.17	103205.1	WASHER
71= 5.23	003030	WASHER
72= 6.1	2183009462	Burner knob
73= 6.4a	106266	Tap diam 0.28 A
74= 6.4b	106267	Tap diam 0.33 SR
75= 6.4c	106268	Tap diam 0.43 R
76= 6.4d	106269	Tap diam 0.63
77= 6.5	001282	Tap fixing screw
78= 6.6	094653	Tap bracket
79= 6.8A	215465	Burner-cupA
80= 6.8SR	215466	Burner-cupSR
81= 6.8R	215467	Burner-cupTR
82= 6.9R	068111001	Burner head A

83= 6.9SR	068110001	Burner-head SR
84= 6.9A	068109001	Burner-head A
85= 6.10A	216129005A	Burner-capA
86= 6.10SR	216130005A	Burner-capSR
87= 6.10R	216131005A	Burner-cap R
88= 6.12a	101182	Injector NATURAL GAS Ø 0.85 - A
89= 6.12b	101273	Injector Rapid diam 1.45 - NG
90= 6.12c	101260	Injector NATURAL GAS Ø 1.12 - SR
91= 6.12d	101244	Injector Rapid diam 0.91 - LPG
92= 6.12e	101262	Injector ULPG Ø 0.53 - A
93= 6.12f	101263	Injector ULPG Ø 0.70 - SR
94= 6.14	053024.1	Sealing washer
95= 6.15	215469	Burner-cup Triple-ring
96= 6.16	103347	Gas pressure regulator 1/2
97= 6.17a	101335	Injector NATURAL GAS Ø 1.60 - TR
98= 6.17b	101233	Injector ULPG Ø 0.95 - TR
99= 6.19	029633	Inlet pipe - front right A
100= 6.20	029632	Inlet pipe - rear right SR
101= 6.21	029649	Inlet pipe - central TR
102= 6.22	029650	Inlet pipe - front left R
103= 6.23	029630	Inlet pipe - rear left SR
104= 6.25	068112001	TR burner head
105= 6.29	067026	Conical adaptor
106= 6.30	103468	Test point adaptor
107= 6.36	216132005A	Burner-cap inside TR
108= 6.37	216133005A	Burner-cap outside TR
109= 6.38	053078	Triple-ring burner-cup gasket
110= 6.39	040064	STOPPER
115= 7.1	217291	Shelf support
116= 7.2	217497	Oven tray support
117= 7.3	48B8501G	Oven tray
118= 7.4	217626	OVEN SHELF
119= 7.6	47E9603G	Oven floor
120= 7.7	037208	Grill-pan grid handle
121= 7.8	217523	Grill-pan grid
122= 8.1	2183009461	Knob hi-light cooking zone
123= 8.3	085081	Knob sleeve
124= 8.15	050030	Oven switch

125= 8.16	066072	Oven thermostat
126= 8.17	062100004	Top element
127= 8.18	062101004	Bottom element
128= 8.19	030076.1	Bottom element insulation
129= 8.20	4219602Z	Bottom insulation support
130= 8.21	4219605Z	Bottom element support
131= 8.22	103085	FILTER
132= 8.23	47A9603G	Fan diffuser
133= 8.24	079008001F	Fan motor - 230 V
134= 8.28	094660	Plaque
135= 8.27	213025	CLIP
136= 9.1	074069	Electronic programmer
137= 9.2	094363	Electronic timer seal
138= 9.3	1031057007	Button
139= 9.4	040056	Rubber
140= 11.1	072025	Lamp holder assembly
141= 11.2	073013001	LAMP
142= 11.3	051054	Terminal block
143= 11.5	082095	Electronic Ignition
144= 11.7	035094	Igniter spring
145= 11.8a	084029	Spark plug L=630mm (semirapid &
146= 11.8b	084033	Igniter TR - L = 500
147= 11.8c	084036	Igniter L = 900
148= 11.15	054094	Cord 3x2.5
149= 11.16	1131791	WIRING
150= 11.18	1031237	Ignition switches
151= 11.20	003077	RETAINING RING
152= 11.33	073090	Control lamp cover (Blue)
153= 11.34	073091	Control lamp L = 230
154= 11.36	066123	Cut-out thermostat 160 degree C