



Product code:


C9S0DA107X

Product: **Cooker**



Model: **DEF905GW1X1**

Product code	Serial No.	Product remark	Issue No.	Issue Date
C9S0DA107X				March 2016



Key part information	
A	Auxiliary burner
SR	Semirapid burner
R	Rapid burner
TR	Triple ring burner




Ref.	Part description	Product code	
		C9S0DA107X	
		Feature	Part code
1.5	Plug		040041001
1.6	Stainless steel screw		001007
2.1	Manifold		3429S50001
2.2	Cooktop		3319L505S
2.5	Burners support		51B9S01
2.6	Inlet pipe plug		027015
2.7	Spacer		1031639
2.12	Gasket		053024.1
2.13	Pin		103615
2.14	Spring		035100
2.15	Pan-support		217530
2.16	Central pan-support		217534
2.17	Nut		214062
2.18	Fixing plate		094793
2.19	Auxiliary grate for small pans		217303
2.20	Cross-piece		51B9S05
2.23	Screw 7Px16		001234.1
2.26	Screw		001167
2.27	Wok grid		217498
3.1	Control panel		35M9102LD1
3.2	Control panel trim		103760
3.8	Clips		213007




Ref.	Part description	Product code	
		C9S0DA107X	
		Feature	Part code
4.4	Oven insulation		030267
4.5	Rear insulation		030213
4.6	Rear right coupler		094417DX
4.7	Rear left coupler		094417SX
4.8	Rear panel		4119602
4.9	Upper shelter		4219T06Z
4.11	Spacer		1031588
4.13	Seal		053101
4.18	Shim		6309608
4.20	Buffer		040061
4.21	Hinge		063075
4.23	Front panel		371V9601L
4.24	Inside panel		373V9601A
4.25	Side panel right		36C96D1H
4.26	Side panel left		36C96S1H
4.31	Bracket		094412
4.32	Rear insulation support		4219604Z
4.33	Hinge protection		4216108Z
4.34	Rotisserie hole plug		035097
4.36	Left stopper		081084080
4.37	Right stopper		081083080
4.38	Air conveyor		46A9S02Z
4.39	Funnel		46A9S01Z
4.40	Tangential fan		079025
4.42	Buffer vibration-damper		040056
4.48	Anti-tilt bracket		6300040
4.50	Oven frame		4419S1EM100




Ref.	Part description	Product code	
		C9S0DA107X	
		Feature	Part code
5.1	Door glass		0312662
5.2	Lower door trim		083240061
5.3	Door handle		037195062
5.4	Washer		103713
5.5	Handle trim		51B9605
5.6	Screw 8Px16		001030
5.8	Door hinge (male)		063146
5.9	Door hinge (female)		063148
5.10	Door panel		373F9606G
5.11	Gasket		053058
5.12	Inner glass		0311292/TH
5.14	Nut		214021
5.15	Screw		001143
5.16	Washer		003035
5.17	Washer		103205.1
5.23	Washer		003030
7.1	Shelf support		217291
7.2	Oven tray support		217497
7.3	Oven tray		48B8501G
7.4	Oven shelf		217626
7.6	Oven floor		47E9603G
7.7	Grill-pan grid handle		037208
7.8	Grill-pan grid		217523



Ref.	Part description	Product code	
		C9S0DA107X	
		Feature	Part code
6.1	Burner knob		2183009462
6.4	Tap	Ø 0.28	106270GN
		Ø 0.33	106271GN
		Ø 0.43	106272GN
		Ø 0.63	106273GN
6.5	Tap fixing screw		001282
6.6	Tap bracket		094654
6.8A	Burner-cup	A	215465
6.8SR	Burner-cup	SR	215466
6.8R	Burner-cup	R	215467
6.9R	Burner head	R	068111003
6.9SR	Burner head	SR	068110003
6.9A	Burner head	A	068109003
6.10A	Burner-cap	A	216129005A
6.10SR	Burner-cap	SR	216130005A
6.10R	Burner-cap	R	216131005A
6.12	Injector	Ø 0.85	101182
		Ø 1.45	101273
		Ø 1.12	101260
		Ø 0.91	101244
		Ø 0.53	101262
		Ø 0.70	101263
6.14	Elbow gasket		053024.1
6.15	Burner-cup	TR	215469
6.16	Gas pressure regulator 1/2" NG		103347
6.17	Injector	TR - Ø 1.60	101335
		TR - Ø 0.95	101233
6.19	Inlet pipe - front right	A	029633
6.20	Inlet pipe - rear right	SR	029632
6.21	Inlet pipe - central	TR	029649
6.22	Inlet pipe - front left	R	029650
6.23	Inlet pipe - rear left	SR	029630
6.25	Burner head	TR	068112003
6.26	Burner thermocouple	L = 500	107039
		L = 500	107039
		L = 350	107042
6.27	Thermocouple nut		214057
6.29	Connection		067026
6.30	Test point adaptor		103468
6.36	Burner-cap inside	TR	216132005A
6.37	Burner-cap outside	TR	216133005A
6.38	Burner-cup gasket		053078



Ref.	Part description	Product code	
		C9S0DA107X	
		Feature	Part code
8.1	Oven knob		2183009464
8.3	Oven knob spacer		103948
8.15	Oven switch		050030
8.16	Oven thermostat		066072
8.17	Top element	230V	062100004
8.18	Bottom element	230V	062101004
8.19	Bottom element insulation		030076.1
8.20	Bottom insulation support		4219602Z
8.21	Bottom element support		4219605Z
8.23	Fan diffuser		47A9603G
8.24	Fan motor		079008001F
8.28	Plaque		094660
8.27	Clip		213025



Ref.	Part description	Product code	
		C9S0DA107X	
		Feature	Part code
9.1	Electronic timer		074069
9.2	Electronic timer seal		094363
9.3	Button		1031057007
9.4	Protection		040056
11.1	Lamp holder		072025
11.2	Lamp - 15 W		073103
11.3	Terminal block		051054
11.5	Burners ignition coil		082083
11.7	Igniter spring		035094
11.8	Igniter	L = 630	084029
		TR - L = 500	084033
		L = 900	084036
11.15	Cord	3x1,5	054094
11.16	Wiring		1131791
11.18	Ignition switches		1031237
11.20	Retaining ring		003077
11.33	Control lamp cover - Blue		073090
11.34	Control lamp	L=230 mm	073091
11.36	Cut-off thermostat	160°	066123
-	Instruction booklet		1105189

Position	Code	description
----------	------	-------------