





























Position	Code	description
101	DAU1591222	Left button
102	DAU1591223	Right button
103	DAU1591224	HANDLE COVER
105	DAU1591225	CONTROL PANEL
106	DAU1591226	Control panel cover sticker
107	DAU1591227	Display window
108	DAU1591188	Out door
109	DAU1591153	Baseboard
110	DAU1591213	Display pcb board
201	DAU1591214	Door swicth assembly
202	DAU1591187	Inner door assembly
204	DAU1590900	12176000003629-Friction strip hooking clamping
205	DAU1590984	12276000001731-Left hinge assembly
208	DAU1590116	Dispenser bracket
209	DAU1590902	DISPENSER
210	DAU1590983	12276000001778-Right hinge assembly
211	DAU1591183	Hinge join board
301	DAU1591146	Top panel assembly
302	DAU1590985	Left side panel
303	DAU1590986	Right side panel
304	DAU1591151	Upper back support
306	DAU1591156	12176000008517-Cutlery shelf guider link stopper(back)
307	DAU1591179	12276000001341-Sword fork frame guider(left)
307-a	DAU1591180	12276000001344-Sword fork frame guider(right)
309	DAU1591126	12176000010336-Cutlery shelf rail support assembly
311	DAU1590912	12176000008444-Cutlery shelf guider supporting holder
313	DAU1591043	12176000010412-Rail support assembly
314	DAU1591157	12176000008573-Basket guider supporting holder
315	DAU1591185	Anti-noise borad
316	DAU1591155	12176000008496-Basket guider link stopper(back)
317	DAU1591181	12276000001357-Upper basket guider(left)
317-a	DAU1591182	12276000001360-Upper basket guider(right)
318	DAU1591195	TANK GASKET
320	DAU1591166	Door lock hook
321	DAU1591168	Back cover board

401	DAU1591005	Power cord
404	DAU1591165	12176000009490-Power cord clasper
406	DAU1591199	Counterweight
407	DAU1591167	FOOT
408	DAU1591205	Door rope
411	DAU1591202	Door spring assembly
412	DAU1590936	12976000001001-Adjust screw of door spring
413	DAU1591144	Tray assembly
414	DAU1591145	BASE COVER
415	DAU1590941	12676000000138-Drain hose assembly
416	DAU1591152	12176000003911-Air breather assembly
417	DAU1591194	12676000000713-Air breather seal
418	DAU1590922	12176000013663-Air breaker nut
419	DAU1591217	17476000001222-Pressure switch
420	DAU1591189	Pump support assembly
424	DAU1590940	17476000001137-Overflow switch
426	DAU1590938	12176000003125-Overflow switch seat
427	DAU1590937	12876000000050-Float
428	DAU1591211	Main pcb board
429	DAU1591148	Pcb seat
430	DAU1591149	Pcb box cover
501	DAU1591164	12176000009472-Inner pipe
510	DAU1591161	Lower sprayer assembly
511	DAU1591158	12176000008645-Sprayer seat
513	DAU1591147	Plane filter
601	DAU1591198	12676000001461-Sump seal
604	DAU1590955	Filter handle
605	DAU1591204	396 clamp
606	DAU1590956	12176000003676-Cylinder filter
607	DAU1591191	Washing pump outlet pipe
610	DAU1591138	11001011000449-Permanent magnet synchronous pump
611	DAU1591171	12176000016225-Sumpassembly
612	DAU1591193	12676000000651-Pvc pipe
613	DAU1591192	12676000000644-Outlet hose of softener
614	DAU1591220	Induction pump assembly
618	DAU1591219	Heating elements
624	DAU1591190	Washing pump inlet pipe

625	DAU1591203	12976000000308-Clamp
628	DAU1591197	Inner drain pipe
629	DAU1590965	17176000012008-Thermostat
630	DAU1591104	17176000000306-Turbidity transducer
631	DAU1591215	Wiring harness
701	DAU1591142	Cutlery assembly
702	DAU1591208	UPPER BASKET
703	DAU1591206	Lower basket assembly
704	DAU1591162	Spray arm
705	DAU1591169	CUP HOLDER
710	DAU1591218	17476000001307-Inlet hose assembly
712	DAU1591216	Wiring harness