
















316	挡块	cutlery shelf guider link stopper(back)	2
315	隔音板	anti-noise borad	1
314	上碗篮导轨支撑安装块	basket guider supporting holder	4
313	上碗篮导轨支撑组件	rail support assembly	4


321	后板	back cover board	1	306	挡块	cutlery shelf guider link stopper(back)	2
320	门锁扣	door lock hook	1	304	上后横档	upper back support	1
318	内胆发泡密封条	tank gasket	1	303	右侧板	right side panel	1
317-a	上碗篮导轨组件 右	upper basket guider(right)	1	302	左侧板组件	left side panel assembly	1
317	上碗篮导轨组件 左	upper basket guider(left)	1				
No.	物料名称	Description	Qty.	No.	物料名称	Description	Qty.



				419	压力开关	PRESSURE SWITCH	1
				418	呼吸器螺母	AIR BREAKER NUT	1
				417	呼吸器平垫圈	AIR BREAKDR GASKET	1
				416	呼吸器组件	AIR BREAKER ASSEMBLY	1
				415	外排水管组件	DRAIN pipe ASSEMBLY	1
				414	底盘盖	base cover	1
				413	独立底盘组件	base tray	1
				412	门拉簧调节杆	adjust screw OF DOOR SPRING	2
				411	门拉簧组件	DOOR SPRING	2
				408	门拉绳	DIGGING ROPE	2
				407	调节脚	foot	4
				406	配重块	weight block	1
				404	电源线扣	power cord clasper	1
				401	电源线	Power cord	1
430	主控制器保护盒盖	pcb seat cover	1				
429	主控制器保护盒	pcb seat	1				
428	控制板	pcb	1				
427	浮标	FLOAT	1				
426	溢流开关座	overflow switch seat	1				
424	微动开关	overflow switch	1				
420	挂钩组件	pump support ASSEMBLY	1				
No.	物料名称	Description	Qty.	No.	物料名称	Description	Qty.


WQP12-7635B





				625	单耳无级卡箍	Clamp	2
				624	进水管	inlet pipe	1
				618	加热管组件	heating elements	1
				614	电机电泵总成	induction pump	1
				613	出水管	outlet hose of softener	1
				612	压力开关PVC管	pvc pipe	1
				611	水杯组件	sump assembly	1
				610	永磁同步泵	Permanent magnet synchronous pump	1
				607	洗涤泵进水管	inlet pipe	1
				606	柱面过滤器	cylinder filter	1
				605	单耳无级卡箍	396 Clamp	2
629	温度传感器组件	thermostat	1	604	提杯	filter handle	1
628	内排水管	inner drain pipe	1	601	水杯密封圈	sump gasket	1
No.	物料名称	Description	Qty.	No.	物料名称	Description	Qty.

WQP12-7635B



705	杯托	cup rack	1
704	中喷臂组件	MIDDLE SPAYER ASSEMBLY	1

Position	Code	description
101	DAU1591228	CONTROL PANEL
102	DAU1591143	Light guide
103	DAU1591178	Handlecover
105	DAU1591229	Control panel cover sticker
106	DAU1590731	Button spring
107	DAU1591139	Button
108	DAU1591140	KEY
109	DAU1590895	Out door
110	DAU1590996	Baseboard
111	DAU1591212	Dashboard
201	DAU1591214	Door swicth assembly
202	DAU1590988	Inner door assembly
204	DAU1590900	12176000003629-Friction strip hooking clamping
205	DAU1590984	12276000001731-Left hinge assembly
208	DAU1590116	Dispenser bracket
209	DAU1590902	DISPENSER
210	DAU1590983	12276000001778-Right hinge assembly
211	DAU1591186	Hinge join board
301	DAU1591176	Top panel
302	DAU1590985	Left side panel
303	DAU1590986	Right side panel
304	DAU1591150	12176000003869-Upper back support
313	DAU1591043	121760000010412-Rail support assembly
314	DAU1591157	12176000008573-Basket guider supporting holder
315	DAU1591184	Anti-noise borad
316	DAU1591155	12176000008496-Basket guider link stopper(back)
317	DAU1591181	12276000001357-Upper basket guider(left)
317-a	DAU1591182	12276000001360-Upper basket guider(right)
318	DAU1590918	TANK GASKET
320	DAU1591166	Door lock hook
321	DAU1590920	Back cover board
401	DAU1591005	Power cord
404	DAU1591165	12176000009490-Power cord clasper
406	DAU1591200	Counterweight
407	DAU1591167	FOOT
408	DAU1591205	Door rope
411	DAU1591201	Door spring assembly

412	DAU1590936	12976000001001-Adjust screw of door spring
413	DAU1591177	Tray assembly
414	DAU1591170	BASE COVER
415	DAU1590941	12676000000138-Drain hose assembly
416	DAU1591152	12176000003911-Air breather assembly
417	DAU1591194	12676000000713-Air breather seal
418	DAU1590922	12176000013663-Air breaker nut
419	DAU1591217	17476000001222-Pressure switch
420	DAU1591189	Pump support assembly
424	DAU1590940	17476000001137-Overflow switch
426	DAU1590938	12176000003125-Overflow switch seat
427	DAU1590937	12876000000050-Float
428	DAU1591210	Main pcb board
429	DAU1591174	12176000016897-PCB Box cover
430	DAU1591173	12176000016896-PCB Box
501	DAU1591163	Inner pipe
510	DAU1591159	12176000009161-Lower sprayer
511	DAU1591158	12176000008645-Sprayer seat
513	DAU1591026	main filter
601	DAU1591198	12676000001461-Sump seal
604	DAU1590955	Filter handle
605	DAU1591204	396 clamp
606	DAU1590956	12176000003676-Cylinder filter
607	DAU1591191	Washing pump outlet pipe
610	DAU1591138	11001011000449-Permanent magnet synchronous pump
611	DAU1591172	Sumpassembly
612	DAU1591193	12676000000651-Pvc pipe
613	DAU1591192	12676000000644-Outlet hose of softener
614	DAU1591220	Induction pump assembly
618	DAU1591219	Heating elements
624	DAU1591190	Washing pump inlet pipe
625	DAU1591203	12976000000308-Clamp
628	DAU1591196	12676000000947-Inner drain pipe
629	DAU1590965	17176000012008-Thermostat
701	DAU1591141	CUTLERY BASKET
702	DAU1591209	Upper basket assembly
703	DAU1591207	Lower basket assembly

704	DAU1591160	12176000009173-Middle spayer assembly
705	DAU1591169	CUP HOLDER
710	DAU1591218	17476000001307-Inlet hose assembly
712	DAU1591221	Wiring harness