




Position	Code	description
0001	AS00007612	SPARE SIDE WALL 1004 CPL V2
0002	AS00007623	SPARE SIDE WALL 1004 CPL V2
0003	AS00009679	UPPER COVER
0005	AS00009680	HEAD
0006	AS00006280	PLATE WITH NEEDLE
0008	AS00001169	CAPSULE HOLDER
0009	AS00001195	CUP HOLDER
0010	AS00008357	DRIP TRAY
0011	AS00008358	COVER
0014	AS00007614	SPARE COVER 1004 CPL V2
0015	AS00001173	WATER TANK
0016	AS00001174	SUPPORT
0017	AS00001175	NEEDLE - DIAMETER 0.6 MM
0019	AS00009681	PUMP (230V)
0020	AS00001177	TUBE
0021	AS00001178	FLOWMETER-PUMP TUBE
0022	AS00001179	FLOWMETER
0025	AS00009682	CONTROL PCB
0027	AS00009683	THERMOBLOCK (230V)
0028	AS00009684	NTC PROBE
0030	AS00009685	POWER SUPPLY CORD
0031	AS00006286	DESCALER ADAPTER
0032	AS00009686	MICROSWITCH