



Position	Code	description
1	BR64041621	BR64041621
2	BR64041622	Crushing blade
3	BR64041623	CONTAINER
4	BR64041624	PROTECTION
5	BR64041628	Switching element
6	BR64041629	MOTOR
7	BR67002609	CARBON BRUSH
8	BR67000670	SPRING
9	BR67002604	Upper/lower damper
10	BR64041631	Base, white
11	BR67000242	Screw 3,9x16
12	BR67002607	Mains lead
13	BR81284837	SCREW (3.9x13)
14	BR81284829	STOP
15	BR67000665	CENTRING BUSH
16	BR67002603	CAPACITOR
18	BR67002398	WASHER (6X11X03)
19	BR67002399	WASHER (6X11X15)