




Position	Code	description
1.1	336D041SD2	Hob top
1.11	094345	BRACKET
1.12	094786	Terminal block protection
1.16	10348100X	PLUG
1.2	4116D03	Burner casing
1.22	58B6303	Bar
1.3	053065	SEAL
1.5	001221	SCREW
1.7	094338	Fixing bracket
4.1	218000E568	KNOB
4.11a	04727230	Rapid electric plate diam 145 - 1500 W - 230 V
4.11b	04763230	Rapid electric plate diam 180 - 2000 W - 230 V
4.2	050086	Normal/rapid electric plate switch
4.3a	04725230	Normal electric plate diam 145 - 1000 W- 230 V
4.3b	04726230	Normal electric plate diam 180 - 1500 W - 230 V
4.4a	103084R	Normal/rapid plate protection diam 145
4.4b	103081R	Normal/rapid plate protection diam 180
4.6	053055	Switch gasket
4.8	214055	NUT
5.1	1132257	WIRING
5.2	051068	Terminal block
5.3	073058	Control lamp L 230
5.4	073057	Control lamp cover