



























Position	Code	description
1= 1.1	103670063	Rear trim
2= 1.5	040041001	PLUG
3= 1.6	001007	Vis
4= 2.1	3421060001	Manifold
5= 2.2	33110602S	Cooktop
6= 2.4	51B1003	Burners support TR
7= 2.5	51B1002	Burners support
8= 2.6	027015	Inlet pipe plug
10= 2.13	103615	PIN
11= 2.14	035100	SPRING
12= 2.15	217547	Pan-support
13= 2.16	217555	Wok grid
14= 2.17	214062	NUT
15= 2.18	094473	Fixing plate
16= 2.23	001234.1	Stainless steel screw V
17= 2.26	001167	SCREW
18= 3.1	35C1006UD2	CONTROL PANEL
19= 3.8	213007	CLIP
20= 4.2	030127.1	Oven insulation
21= 4.3	030128.1	Rear insulation
22= 4.4	030113.1	Oven insulation
23= 4.5	030098.1	Rear insulation
24= 4.6	094417DX	Rear hob support right
25= 4.7	094417SX	Rear hob support left
26= 4.8	4119S01	REAR PANEL
27= 4.9	4219S01Z	Upper shelter
28= 4.10	053074	Upper seal
29= 4.11	053095	Top seal
30= 4.12	094646	Side panel bracket
31= 4.13	053199	Bottom oven seal
32= 4.16	053094	Bottom seal
33= 4.18	103410080	SHIM
34= 4.19	214056	Shim nut
35= 4.20	040061	BUFFER
36= 4.21	063075	HINGE
37= 4.22	053093	SEAL
38= 4.23	371V9606U	FRONT PANEL

39= 4.24	373V9601Y	Inside panel
40= 4.25	3611TD1S	Side panel right
41= 4.26	3611TS1S	Side panel left
42= 4.27	094136	BRACKET
43= 4.29	531533	TUBE RETAINER
44= 4.31	094419	BRACKET
45= 4.32	4219604Z	Rear insulation support
46= 4.38	46A9S02Z	Air conveyor
47= 4.39	46A9S01Z	FUNNEL
48= 4.40	079025	Tangential fan
49= 4.44	040056	Rubber
50= 4.48	094153	Anti tilt bracket
51= 4.50	45EN6106P	Left oven side panel (Left)
52= 4.51	45EN6101P	Left top oven panel
53= 4.52	45EN6107P	Left oven side panel (Right)
54= 4.53	45H9S001P	BODY REAR PANEL
55= 4.54	47E6102P	Left oven floor
56= 4.55	45B9S001P	Body front panel
57= 4.56	45K96001Z	Lower element cover
58= 4.59	211012	RIVET
59= 4.60	45E65104P	Right oven side panel (Left)
60= 4.61	45E65105P	Right oven side panel (Right)
61= 4.62	47E9S001P	Right oven floor
62= 4.63	45E9S001P	Right top oven panel
63= 4.64	45H9S002P	BODY REAR PANEL
64= 4.65	4219S02Z	Right oven rear spacer channel
65= 4.66	4219S03Z	Right oven lower rear panel spacer
66= 4.68	51B9S03	Rear insulation support
67= 5.1	032912196A	DOOR GLASS
68= 5.3	037221062	Door handle
69= 5.4	51B9102	Fixing bar
70= 5.5	001056	SCREW
71= 5.6	001083	SCREW
73= 5.10	373F9104G	INNER DOOR
74= 5.11	053084	Bottom oven glass seal
75= 5.12	0311000.1T	Inner glass
76= 5.14	214021	NUT
77= 5.15	001143	SCREW

78= 5.16	003035	WASHER
79= 5.17	103205.1	WASHER
80= 5.18	063059/ZA	Left door hinge (male)
81= 5.19	063058/ZA	Right door hinge (male)
82= 5.21	003030	WASHER
83= 5.22	003041	WASHER
84= 5.30	0329T2197A	DOOR GLASS
85= 5.31	037222062	Door handle
86= 5.32	51B9S04	Fixing bar
87= 5.34	0312159T	Inner glass
88= 5.35	053096	GASKET
89= 5.36	063109	Door hinge (female)
90= 5.37	063111	Left door hinge (male)
91= 5.38	063110	Right door hinge (male)
92= 5.39	373F9S01P	Door panel
93= 6.1	218P25A344	Burner knob
94= 6.4a	106270GN	Tap diam 0.28 A
95= 6.4b	106271	Tap diameter 0.33
96= 6.4c	106272	Tap - Griddle diameter 0.43 R
97= 6.4d	106273	Tap diameter 0.63 TR
98= 6.5	001282	Tap fixing screw
99= 6.6	094654	Tap bracket
100= 6.8A	215465	Burner-cupA
101= 6.8SR	215466	Burner-cupSR
102= 6.8R	215467	Burner-cupTR
103= 6.9R	068111003	Burner-head Rapid
104= 6.9SR	068110003	Burner-head Semi-rapid
105= 6.9A	068109003	Burner-head Auxiliary
106= 6.10A	216129005A	Burner-capA
107= 6.10S	216130005A	Burner-capSR
108= 6.10R	216131005A	Burner-cap R
109= 6.12a	101182	Injector NATURAL GAS Ø 0.85 - A
110= 6.12b	101273	Injector Rapid diam 1.45 - NG
111= 6.12c	101260	Injector NATURAL GAS Ø 1.12 - SR
112= 6.12d	101262	Injector ULPG Ø 0.53 - A
113= 6.12e	101263	Injector ULPG Ø 0.70 - SR
114= 6.12f	101244	Injector Rapid diam 0.91 - LPG
115= 6.14	053024.1	Sealing washer

116= 6.15	215469	Burner-cup Triple-ring
117= 6.16	103347	Gas pressure regulator 1/2
118= 6.17a	101335	Injector NATURAL GAS Ø 1.60 - TR
119= 6.17b	101233	Injector ULPG Ø 0.95 - TR
120= 6.19	029759	Inlet pipe - front right TR
121= 6.20	029646	Inlet pipe - rear right SR
122= 6.21	029645	Inlet pipe - rear central R
123= 6.22	029644	Inlet pipe - front central A
124= 6.23	029643	Inlet pipe - rear left SR
125= 6.24	029642	Inlet pipe - front left TR
126= 6.25	068112003	TR burner head
127= 6.26a	107039	Burner thermocouple L=500 mm
128= 6.26b	107039	Burner thermocouple L=500 mm
129= 6.26c	107043	Burner thermocouple L=500mm (triple-ring burner)
130= 6.26d	107044	Burner thermocouple L=250 mm - TR
131= 6.27	214057	NUT
132= 6.28	027013	NG connection
133= 6.29	067026	Conical adaptor
134= 6.30	103468	Test point adaptor
135= 6.36	216132005A	Burner-cap inside TR
136= 6.37	216133005A	Burner-cap outside TR
137= 6.38	053078	Triple-ring burner-cup gasket
140= 7.3	48EF601	Pastry plate
141= 7.4	48B6101P	Oven tray
142= 7.5	217559	WIRE SHELF
143= 7.6	217546	Grill-pan grid
144= 7.7	037224.1	GRILL-PAN GRID HANDLE
145= 7.11	079014	Rotisserie motor
147= 7.13	217539	Rotisserie support
148= 7.16	103406	Kit pizza stone
149= 7.30	217307	Shelf support
150= 7.31	48B9S001P	Oven tray
151= 7.32	217538	Oven dish rack
152= 7.33	217537	Grill-pan grid
153= 8.1	218P06A345	Multifunction oven thermostat knob
154= 8.2	218P41A345	Multifunction oven switch knob
155= 8.4	085081	Knob sleeve
156= 8.5	218P79A345	Conventional oven thermostat knob

157= 8.6	218P77A345	Conventional oven switch knob 230V
158= 8.15	050028.1	Oven switch
159= 8.16	066072	Oven thermostat
160= 8.17	062158004	Top + grill element 230V
161= 8.18	062066004	Bottom element 230V
162= 8.19	030083.1	Bottom element insulation
163= 8.20	4216102Z	Bottom element support
164= 8.22	103085	FILTER
165= 8.23	47AN601P	Fan diffuser
166= 8.24	079008001F	Fan motor - 230 V
167= 8.26	062057004	Fan element - 230 V
168= 8.27	213023	CLIP
169= 8.30	050030	Oven switch
170= 8.31	062102004	HEATING ELEMENT
171= 8.32	062096004	Bottom element
172= 8.33	030129.1	Bottom element insulation
173= 8.34	4219S04Z	Bottom element support
174= 8.35	4219S05Z	Bottom element protection
175= 8.36	213025	CLIP
176= 9.1	074069	Electronic programmer
177= 9.2	094363	Electronic timer seal
178= 9.3	103376080	Programmer Button
180= 11.1	072023	Lamp holder assembly
181= 11.2	073013001	LAMP
182= 11.3	094221	Earth plate
183= 11.5	082095	Electronic Ignition
184= 11.7	035094	Igniter spring
185= 11.8a	084029	Spark plug L=630mm (semirapid &
186= 11.8b	084033	Igniter TR - L = 500
187= 11.8c	084035	Igniter TR - L = 900
188= 11.8d	084036	Igniter L = 900
189= 11.11	103230.1A	Terminal block protection
190= 11.14	052008	Cable clamp - rear cooker
191= 11.15	054056	Cord
192= 11.16	1131313	WIRING
193= 11.18	1031236	Ignition switches
194= 11.20	030077	RETAINING RING
195= 11.31	051049	Terminal block 25A-3P

196= 11.33	07306202.2	Control lamp cover (Red)
197= 11.34	073039.2	Control lamp L 230
198= 11.36	066123	Cut-out thermostat 160 degree C
199= 11.36	066145	Cut-off thermostat 80 degrees
200= 11.36	066073	Cut-off thermostat 150 degrees