





























Position	Code	description
1.1	103670063	Rear trim
1.5	040041001	PLUG
2.1	3421060001	Manifold
2.12	053024.1	Sealing washer
2.13	103615	PIN
2.14	035100	SPRING
2.15	217547	Pan-support
2.16	217555	Wok grid
2.17	214062	NUT
2.18	094473	Fixing plate
2.21	217303	Grate for small pans
2.23	001234.1	Stainless steel screw V
2.26	001008	SCREW
2.5	51B1002	Burners support
2.6	027015	Inlet pipe plug
3.8	213007	CLIP
4.12	094429	Side panel bracket
4.13	053057	Seal (3 sided)
4.18	103410080	SHIM
4.19	214056	Shim nut
4.20	040061	BUFFER
4.21	063075	HINGE
4.25	36110D1S	Side panel right
4.26	36110S1S	Side panel left
4.27	094226	BRACKET
4.31	094419	BRACKET
4.32	4219604Z	Rear insulation support
4.35	103505A	Rotisserie motor support
4.38	46A9S02Z	Air conveyor
4.39	46A9S01Z	FUNNEL
4.4	030074.1	Oven insulation
4.40	079025	Tangential fan
4.41	053092	Funnel gasket
4.48	094153	Anti tilt bracket
4.5	030106.1	Rear insulation
4.50	45EN6106P	Left oven side panel (Left)
4.52	45EN6107P	Left oven side panel (Right)

4.56	45K96001Z	Lower element cover
4.57	211012	RIVET
4.6	094417DX	Rear hob support right
4.7	094417SX	Rear hob support left
4.8	4119602	REAR PANEL
4.9	4219S01Z	Upper shelter
5.10	373F9604G	INNER DOOR
5.12	0311292/TH	Inner glass
5.14	214021	NUT
5.15	001143	SCREW
5.16	003035	WASHER
5.17	103205.1	WASHER
5.22	003041	WASHER
5.23	053083	GASKET
5.24	213029	CLIP
5.26	001089	SCREW
5.27	001007	Vis
5.3	037220062	Door handle
5.4	103686.1	WASHER
5.5	003057	WASHER
5.6	001083	SCREW
5.8	063100	Door hinge (male)
5.9	063066	Top oven hinge (female) works with male hinge 063096
6.1	218P25A344	Burner knob
6.15	215469	Burner-cup Triple-ring
6.16	103347	Gas pressure regulator 1/2
6.20	029646	Inlet pipe - rear right SR
6.21	029645	Inlet pipe - rear central R
6.22	029644	Inlet pipe - front central A
6.23	029643	Inlet pipe - rear left SR
6.24	029642	Inlet pipe - front left TR
6.25	068112003	TR burner head
6.27	214057	NUT
6.28	027013	NG connection
6.29	067026	Conical adaptor
6.30	103468	Test point adaptor
6.36	216132005A	Burner-cap inside TR

6.37	216133005A	Burner-cap outside TR
6.38	053078	Triple-ring burner-cup gasket
6.4A	106236	Tap diam 0.27 A
6.4B	106237	Tap diameter 0.32
6.4C	106238	Tap - diameter 0.42 R
6.4D	106239	Tap diameter 0.65 TR
6.5	001233	Tap fixing screw
6.6	094382	Tap bracket
6.8A	215465	Burner-cupA
6.8R	215467	Burner-cupTR
6.9A	068109003	Burner-head Auxiliary
6.9R	068111003	Burner-head Rapid
7.11	079014	Rotisserie motor
7.16	103406	Kit pizza stone
7.6	47E9604G	Oven floor
7.7	037224.1	GRILL-PAN GRID HANDLE
7.8	217523	Grill-pan grid
8.1	218P75A345	Oven knob thermostat
8.15	050028.1	Oven switch
8.16	066072	Oven thermostat
8.18	062073004	Bottom element 230V
8.19	030076.1	Bottom element insulation
8.2	218P41A345	Multifunction oven switch knob
8.20	4219602Z	Bottom insulation support
8.21	4219605Z	Bottom element support
8.22	103085	FILTER
8.24	079008001F	Fan motor - 230 V
8.26	062057004	Fan element - 230 V
8.27	213023	CLIP
8.4	085081	Knob sleeve
9.1	074041	Electronic timer
9.2	094363	Electronic timer seal
9.3	103376080	Programmer Button
9.4	040056	Rubber
11.2	073013001	LAMP
11.7	035094	Igniter spring
68SR	215466	Burner-cupSR
69SR	068110003	Burner-head Semi-rapid

0118	084033	Igniter TR - L = 500
118A	084029	Spark plug L=630mm (semirapid &
118B	084036	Igniter L = 900
118C	084035	Igniter TR - L = 900
511A	053058	GASKET
511B	053101	SEAL
610A	216129005A	Burner-capA
610R	216131005A	Burner-cap R
610S	216130005A	Burner-capSR
612A	101182	Injector NATURAL GAS Ø 0.85 - A
612F	101244	Injector Rapid diam 0.91 - LPG
617B	101233	Injector ULPG Ø 0.95 - TR
626A	107039	Burner thermocouple L=500 mm
626B	107039	Burner thermocouple L=500 mm
626C	107040	Burner thermocouple - L=600 mm
626D	107043	Burner thermocouple L=500mm (triple-ring burner)
626E	107044	Burner thermocouple L=250 mm - TR
710B	037012	Spear handle
1111	103230.1A	Terminal block protection
1114	052002	Wire fastener
1115	054041	CORD
1118	103633	Ignition switches
1119	035080	Ignition switches spring
1120	003039	RETAINING RING
1121	003038	WASHER
1122	050058	Knob switch
1123	218P74A345	Switch oven knob
1132	051049	Terminal block 25A-3P
1133	07306202	Control lamp cover - Red
1134	073039.2	Control lamp L 230
1136	066123	Cut-out thermostat 160 degree C