





























Position	Code	description
1= 1.1	103670063	Rear trim
2= 1.5	040041001	PLUG
4= 2.1	3421060001	Manifold
5= 2.2	33110602S	Cooktop
6= 2.4	51B1003	Burners support TR
7= 2.5	51B1002	Burners support
8= 2.6	027015	Inlet pipe plug
10= 2.13	103615	PIN
11= 2.14	035100	SPRING
12= 2.15	217547	Pan-support
13= 2.16	217555	Wok grid
14= 2.17	214062	NUT
15= 2.18	094473	Fixing plate
16= 2.21	217303	Grate for small pans
17= 2.23	001234.1	Stainless steel screw V
18= 2.26	001167	SCREW
19= 3.1	35C1019UD1	CONTROL PANEL
20= 3.8	213007	CLIP
21= 4.4	030074.1	Oven insulation
22= 4.5	030106.1	Rear insulation
23= 4.6	094417DX	Rear hob support right
24= 4.7	094417SX	Rear hob support left
25= 4.8	4119602	REAR PANEL
26= 4.9	4219S01Z	Upper shelter
27= 4.12	094646	Side panel bracket
28= 4.13	053101	SEAL
29= 4.18	103410080	SHIM
30= 4.19	214056	Shim nut
31= 4.20	040061	BUFFER
32= 4.21	063075	HINGE
33= 4.23	371V1001U	FRONT PANEL
34= 4.24	373V9601Y	Inside panel
35= 4.25	36110D1S	Side panel right
36= 4.26	36110S1S	Side panel left
37= 4.27	094226	BRACKET
38= 4.31	094419	BRACKET
39= 4.32	4219604Z	Rear insulation support

40= 4.35	103505A	Rotisserie motor support
41= 4.38	46A9S02Z	Air conveyor
42= 4.39	46A9S01Z	FUNNEL
43= 4.40	079025	Tangential fan
45= 4.48	094153	Anti tilt bracket
46= 4.50	45EN6106P	Left oven side panel (Left)
47= 4.51	45E96001P	Top oven panel
48= 4.52	45EN6107P	Left oven side panel (Right)
49= 4.53	45H96008P	BODY REAR PANEL
50= 4.55	45B96003P	Body front panel
51= 4.56	45K96001Z	Lower element cover
52= 4.57	211012	RIVET
53= 5.1	032961882J	OVEN DOOR GLASS
54= 5.3	037220062	Door handle
55= 5.4	103686.1	WASHER
56= 5.5	003057	WASHER
57= 5.6	001083	SCREW
58= 5.8	063100	Door hinge (male)
59= 5.9	063066	Top oven hinge (female) works with male hinge 063096
60= 5.10	373F9604G	INNER DOOR
61= 5.11	053058	GASKET
62= 5.12	0311292/TH	Inner glass
63= 5.14	214021	NUT
64= 5.15	001143	SCREW
65= 5.16	003035	WASHER
66= 5.17	103205.1	WASHER
67= 5.22	003041	WASHER
68= 5.23	053083	GASKET
69= 5.24	213029	CLIP
70= 5.26	001089	SCREW
71= 5.27	001007	Vis
72= 6.1	218P25A344	Burner knob
73= 6.4a	106270GN	Tap diam 0.28 A
74= 6.4b	106271	Tap diameter 0.33
75= 6.4c	106272	Tap - Griddle diameter 0.43 R
76= 6.4d	106273	Tap diameter 0.63 TR
77= 6.5	001282	Tap fixing screw

78= 6.6	094654	Tap bracket
79= 6.8A	215465	Burner-cupA
80= 6.8SR	215466	Burner-cupSR
81= 6.8R	215467	Burner-cupTR
82= 6.9R	068111003	Burner-head Rapid
83= 6.9SR	068110003	Burner-head Semi-rapid
84= 6.9A	068109003	Burner-head Auxiliary
85= 6.10A	216129005A	Burner-capA
86= 6.10SR	216130005A	Burner-capSR
87= 6.10R	216131005A	Burner-cap R
88= 6.12	101182	Injector NATURAL GAS Ø 0.85 - A
89= 6.12	101273	Injector Rapid diam 1.45 - NG
90= 6.12	101260	Injector NATURAL GAS Ø 1.12 - SR
91= 6.12	101262	Injector ULPG Ø 0.53 - A
92= 6.12	101263	Injector ULPG Ø 0.70 - SR
93= 6.12	101244	Injector Rapid diam 0.91 - LPG
94= 6.14	053024.1	Sealing washer
95= 6.15	215469	Burner-cup Triple-ring
96= 6.16	103347	Gas pressure regulator 1/2
97= 6.17	101335	Injector NATURAL GAS Ø 1.60 - TR
98= 6.17	101233	Injector ULPG Ø 0.95 - TR
99= 6.19	029759	Inlet pipe - front right TR
100= 6.20	029646	Inlet pipe - rear right SR
101= 6.21	029645	Inlet pipe - rear central R
102= 6.22	029644	Inlet pipe - front central A
103= 6.23	029643	Inlet pipe - rear left SR
104= 6.24	029642	Inlet pipe - front left TR
105= 6.25	068112003	TR burner head
106= 6.26a	107039	Burner thermocouple L=500 mm
107= 6.26b	107039	Burner thermocouple L=500 mm
108= 6.26c	107043	Burner thermocouple L=500mm (triple-ring burner)
109= 6.26d	107044	Burner thermocouple L=250 mm - TR
110= 6.27	214057	NUT
111= 6.28	027013	NG connection
112= 6.29	067026	Conical adaptor
113= 6.30	103468	Test point adaptor
114= 6.36	216132005A	Burner-cap inside TR
115= 6.37	216133005A	Burner-cap outside TR

116= 6.38	053078	Triple-ring burner-cup gasket
117= 7.1	217590DX	Right shelf support
118= 7.2	217590SX	Left shelf support
119= 7.3	48B8501P	Oven tray
120= 7.4	217601	OVEN SHELF
121= 7.5	217600	Oven tray support
122= 7.6	47E9604G	Oven floor
123= 7.7	037224.1	GRILL-PAN GRID HANDLE
124= 7.8	217523	Grill-pan grid
125=7.10a	080035	Rotisserie spear (without handle)
125=7.10b	037012	Spear handle
126= 7.11	079014	Rotisserie motor
127= 7.12	217599	Rotisserie support
128= 7.16	103406	Kit pizza stone
129= 8.1	218P75A345	Oven knob thermostat
130= 8.2	218P41A345	Multifunction oven switch knob
131= 8.4	085081	Knob sleeve
132= 8.15	050028.1	Oven switch
133= 8.16	066072	Oven thermostat
134= 8.17	062113004	Top element 230V
135= 8.18	062073004	Bottom element 230V
136= 8.19	030076.1	Bottom element insulation
137= 8.20	4219602Z	Bottom insulation support
138= 8.21	4219605Z	Bottom element support
139= 8.22	103085	FILTER
140= 8.23	47A9601P.2	Fan diffuser
141= 8.24	079008001F	Fan motor - 230 V
142= 8.26	062057004	Fan element - 230 V
143= 8.27	213023	CLIP
144= 9.1	074069	Electronic programmer
145= 9.2	094363	Electronic timer seal
146= 9.3	103376080	Programmer Button
147= 9.4	040056	Rubber
148= 11.1	072025	Lamp holder assembly
149= 11.2	073013001	LAMP
150= 11.5	082095	Electronic Ignition
151= 11.7	035094	Igniter spring
152= 11.8a	084029	Spark plug L=630mm (semirapid & amp

153= 11.8b	084033	Igniter TR - L = 500
154= 11.8c	084035	Igniter TR - L = 900
155= 11.8d	084036	Igniter L = 900
156= 11.11	103230.1A	Terminal block protection
157= 11.14	052008	Cable clamp - rear cooker
158= 11.15	054041	CORD
159= 11.16	1131507	WIRING
160= 11.18	1031236	Ignition switches
161= 11.20	003077	RETAINING RING
162= 11.22	050058	Knob switch
163= 11.23	218P74A345	Switch oven knob
164= 11.32	051049	Terminal block 25A-3P
165= 11.33	07306202.2	Control lamp cover (Red)
166= 11.34	073039.2	Control lamp L 230
167= 11.36	066123	Cut-out thermostat 160 degree C