








Position	Code	description
01	3215518	COVER
02	040033001	BUMPER
03	040020001	RUBBER PAD
04	040017001	RUBBER PAD
05	217338	GRID
06	001003	SCREW
07	085015	BUSH
08	331554068	WORK TOP
09	3415540M1	FEED ASSY
10	027015	Inlet pipe plug
11	053024.1	Sealing washer
12	214021	NUT
13	001040	SCREW
14	003015	WASHER
16	053063	GASKET
17	36C5001T	SIDE
18	035097	Rotisserie hole plug
19	3805003M	PANEL
20	001007	Vis
21	0312484	GLASS
22	001083	SCREW
23	103205.1	WASHER
24	373F5010G	INNER DOOR
25	08312300M	PROFILE
26	03717600M	HANDLE
27	0312395	GLASS
28	094100	BRACKET
29	040011	BUFFER
30	033011	THERMOMETER
31	08310000M	PROFILE LOWER
32	063081	HINGE
34	213007	CLIP
35	35C5552BD3	FRONT PIECE
040A	216087611	FLAME BAFFLE A
040B	216088620	FLAME BAFFLE SR
040C	216089624	FLAME BAFFLE R
040D	216090622S	FLAME BAFFLE UR

041A	068050002	GLASS
041B	068051002	GLASS
041C	068052002	GLASS
041D	068053002S	GLASS
042A	215172	A burner
042B	215173	SR burner
042C	215174	BURNER R
042D	215175	UR burner
43	001017	SCREW
044A	101066	Injector - diameter 0.70
044B	101075	Injector - diameter 0.47
044C	101076	INJECTOR d. 0,62
044D	101077	INJECTOR d. 0,78
044E	101078	INJECTOR d. 0,86
044F	101090	INJECTOR d. 1,25
044G	101128	INJECTOR d. 0,88
044H	101129	Injector - diameter 1.15
045A	024019	A-SR air regulation tube
045B	024020	REGULATOR R
045C	024021	UR air regulation tube
46	342510010	EXTENSION
047A	027018P	HOSE COUPLING
047B	027018R	HOSE COUPLING
48	094151	Tap bracket
049A	106090	TAP
049B	106091	TAP
049C	106092	TAP
049D	106093	TAP
50	218364X303	KNOB
51	029463	PIPING
52	029304	PIPING
53	029307	PIPING
54	029305	PIPING
55	094155	Oven thermostat fixing bracket
56	106157	TAP
57	107015	THERMOCOUPLE
58	NOCODE01	NOT AVAILABLE
59	067024	CONNECTION

60	094279	BRACKET
061A	101081	INJECTOR d. 1,20
061B	101112	INJECTOR d. 0,80
62	R00550280	BRASS NUT FOR THERMOCOUPLE
63	215431	BURNER
64	51B5005	CROSSPIECE
65	217222	GRID
66	47E5001G	BOTTOM
67	103057	LIGHTING TUBE
68	107009	Thermocouple L=450 mm