














IT HGW854-B86

Position	Code	description
0	6205803	Kit tank compartment tray
01	3215811	COVER
02	040033003	BUMPER
03	040020003	RUBBER PAD
04	040017003	RUBBER PAD
05	217420	GRID
06	001003	SCREW
07	085015	BUSH
08	331584051	WORK TOP
09	3415840M1	FEED ASSY
10	027015	Inlet pipe plug
12	214021	NUT
13	003015	WASHER
14	001040	SCREW
15	36C50011	SIDE
16	001007	Vis
17	371A58013	DOOR
18	373A5804M	INNER DOOR
19	217224	GRID
20	063034	HINGE
21	035009	SPRING
22	063033	HINGE
23	071042003	PEG
24	38050033	PANEL
25	053063	GASKET
26	035097	Rotisserie hole plug
28	037136035	HANDLE
31	001083	SCREW
32	103205.1	WASHER
33	373F5010G	INNER DOOR
34	083123035	PROFILE
35	037135035	HANDLE
36	0312798	GLASS DOOR
37	094100	BRACKET
38	040011	BUFFER
40	083100035	PROFILE
42	063081	HINGE

IT HGW854-B86

43	0312484	GLASS
44	085040035	BUSH
45	053024.1	Sealing washer
046A	216087611	FLAME BAFFLE A
046B	216088620	FLAME BAFFLE SR
046C	216089624	FLAME BAFFLE R
046D	216090622S	FLAME BAFFLE UR
047A	068050	RING A
047B	068085	RING SR
047C	068086	RING R
047D	068087	RING UR
048A	215172	A burner
048B	215173	SR burner
048C	215174	BURNER R
048D	215175	UR burner
49	001017	SCREW
050A	101075	Injector - diameter 0.47
050B	101076	INJECTOR d. 0,62
050C	101077	INJECTOR d. 0,78
050D	101078	INJECTOR d. 0,86
051A	024019	A-SR air regulation tube
051B	024020	REGULATOR R
53	027018P	HOSE COUPLING
54	094066	BRIDLE
055A	106004	TAP A
055B	106005	TAP SR
055C	106006	TAP R
055D	106007	TAP R
57	029464	TUBE A
58	029177	TUBE SR
59	029465	TUBE UR
60	029180	TUBE R
61	094155	Oven thermostat fixing bracket
62	106157	TAP
63	107045	THERMOCOUPLE
65	067024	CONNECTION
66	094279	BRACKET
067A	101081	INJECTOR d. 1,20

067B	101112	INJECTOR d. 0,80
68	035098	SPRING
69	215431	BURNER
70	51B5005	CROSSPIECE
71	217222	GRID
72	47E5001G	BOTTOM
73	103057	LIGHTING TUBE
74	218L643112	KNOB
80	35E20223DL	FRONT PIECE
81	213012	Clips
82	NOCODE01	NOT AVAILABLE
83	069053035	HEAD
84	069054035	HEAD
85	213007	CLIP