







Position	Code	description
001	032611558S	GLASS
002	040023001	Buffer (Brown)
003	069040/NS	Right trim corner
004	069039/NS	Left trim corner
005	083205061	Right/Left trim
006	069041/NS	Left hinge bracket
007	069042/NS	Right hinge bracket
008	063105	HINGE
009	063104	HINGE
011	217471A	Pan-support
012	213007	CLIP
013	35C6509SDL	CONTROL PANEL
015	071042002	Plastic peg - (Black)
017	51B6501	Burners support
018	027015	Inlet pipe plug
019	053024.1	Sealing washer
020	3426140C01	TUBE
021	063053	Door hinge (male)
022	063025	Top oven hinge (female) works with male hinge 063089
023	373FF706G	Door Skin
024	053084	Bottom oven glass seal
025	0311000.1T	Inner glass
026	001024	SCREW
027	103205.1	WASHER
028	003035	WASHER
029	214021	NUT
030	003057	WASHER
031	411F729	Insulation support
033	103198	WASHER
034	037191062	HANDLE
035	032611738H	GLASS DOOR
036	079014	Rotisserie motor
037	217302	SUPPORT
039	51BF703	PROTECTION
040	48B6101G	DRIP PAN
041	217221	GRID

042	47EN601K	BOTTOM
043	103057	LIGHTING TUBE
045	217291	Shelf support
046	083197061	Right front trim
047	083196061	Left front trim
048	NOCODE04	SEE TECHNICAL BULLETIN
049	053199	Bottom oven seal
050	085044	SLEEVE
051	094075	Drawer rail
052	39E6601YS	Drawer front panel
053	094138	Drawer fixing bracket
054	040012	BUFFER
055	39K6101Y	DRAWER
056	103160061	Base panel
057	103028	FOOT
058	NOCODE01	NOT AVAILABLE
059	094175	Rear left coupler
060	094174	Rear right coupler
061	4119101	REAR PANEL
062	4216101Z	Upper shelter
063A	216070080	Double ring burner-cap (Black)
063B	216071005	SR burner-cap
064A	216074016	RING A
064B	216075134	SR burner-ring
065A	068072006	SR burner head
065B	068073006	A burner head
066A	215172	A burner
066B	215173	SR burner
066C	215175	UR burner
067A	024019	A-SR air regulation tube
067B	024021	UR air regulation tube
068A	101007	INJECTOR d. 1,00
068B	101071	INJECTOR d. 0,72
068C	101074	Injector - diameter 1.35
068D	101111	Injector - diameter 0.67
068E	101137	Injector - diameter 0.50
069	001017	SCREW
070	216074230	BURNER CAP RING

071	216100140	DR outside burner-ring
072	068075006	Double ring burner-head
073	218344E320	Butterfly Knob
074	074009	60 min alarm
075	103393	WIRING
076	035080	Ignition switches spring
077	003038	WASHER
078	003039	RETAINING RING
079	R00550280	BRASS NUT FOR THERMOCOUPLE
080	107009	Thermocouple L=450 mm
082	218344E322	KNOB
083A	106083	Tap - diameter 0.29
083B	106116	Tap - diameter 0.27
083C	106133	Tap - diameter 0.47
084	029334	TUBE PB
085	029333	TUBE SR
086	029332	TUBE SR
087	029331	TUBE A
088	027018P	HOSE COUPLING
090	077075002	SWITCH
091	084022	Igniter - L = 800 mm
092	035011	Igniter spring
093	082053	GENERATOR
094	073013001	LAMP
095	072023	Lamp holder assembly
097	103230.1A	Terminal block protection
099	103370	SUPPORT
100	077066	MICROSWITCH
101	103392	CAM
103	077073	MICROSWITCH
104	062067004	HEATING ELEMENT
105	066139	THERMOSTAT
106	213015	CLIP
107	215439	BURNER
108	4219106Z	SUPPORT
109	084027	ELECTRODE
110	103290	CABLE
111	107015	THERMOCOUPLE

112A	101080	Injector - diameter 0.92
112B	101091	INJECTOR d. 1,40
113	067025	CONNECTION
115	027018R	HOSE COUPLING
116	037012	Spear handle
117	040011	BUFFER