





















Position	Code	description
1= 0.0	6109S50056	ULPG conversion kit
2= 1.1	103630063	Rear trim
3= 1.5	040041001	PLUG
4= 1.6	001007	Vis
5= 2.1	3429S50004	Manifold
6= 2.2	3319L504S	Cooktop
7= 2.5	51B9S01	Burners support
8= 2.6	027015	Inlet pipe plug
9= 2.7	1031639	SPACER
10= 2.8	217498	Grid for woks
11= 2.12	053024.1	Sealing washer
12= 2.13	103615	PIN
13= 2.14	035100	SPRING
14= 2.15	217530	Pan-support
15= 2.16	217534	Central pan support
16= 2.17	214062	NUT
17= 2.18	094793	Fixing plate
18= 2.19	217303	Grate for small pans
19= 2.20	51B9S05	Cross-piece
20= 2.23	001234.1	Stainless steel screw V
21= 2.26	001175	SCREW
22= 3.1	35M9114LDA	CONTROL PANEL
23= 3.2	103760	Control panel trim
24= 3.8	213007	CLIP
25= 4.3	46A9S10Z	FUNNEL
26= 4.4	030267	Oven insulation
27= 4.5	030106.1	Rear insulation
28= 4.6	094417DX	Rear hob support right
29= 4.7	094417SX	Rear hob support left
30= 4.8	4119602	REAR PANEL
31= 4.9	4219T06Z	Upper shelter
32= 4.10	4219T05Z	Cooling fan conveyor
33= 4.11	079056	Tangential fan
34= 4.13	053057	Seal (3 sided)
35= 4.18	6308504	SHIM
36= 4.20	040061	BUFFER
37= 4.21	063075	HINGE

38= 4.23	371V9601L	FRONT PANEL
39= 4.24	373V9601A	Inside panel
40= 4.25	36C96D1S	Side panel right
41= 4.26	36C96S1S	Side panel left
42= 4.31	094412	BRACKET
43= 4.32	4219604Z	Rear insulation support
44= 4.34	035097	Rotisserie hole plug
45= 4.36	081084/NS	Left stopper
46= 4.37	081083/NS	Right stopper
47= 4.42	6300040	Anti tilt bracket
48= 4.50	4419S1GE103	Oven frame
49= 5.1	0329S025	Door outer glass
50= 5.2	037195062	Door handle
51= 5.3	030187.1	Side door insulation
52= 5.4	51B9S13A	Door handle fixing bracket
53= 5.5	001265	Door handle screw
54= 5.6	51A9S11DA	Right door trim
55= 5.7	51A9S11SA	Left door trim
56= 5.9	0313111TH	Inner glass
57= 5.10	063148	Door hinge (female)
58= 5.11	063146	Door hinge (male)
59= 5.12	103713	Door handle plaque
60= 5.14	51B9S14A	BAFFLE
61= 7.1	217291	Shelf support
62= 7.2	217497	Oven tray support
63= 7.3	48B8501G	Oven tray
64= 7.4	217626	OVEN SHELF
65= 7.6	47E9604G	Oven floor
66= 7.7	037208	Grill-pan grid handle
67= 7.8	217523	Grill-pan grid
68= 6.1	2183009380	Burner knob
69= 6.4	106270GN	Tap diam 0.28 A
70= 6.4	106271GN	Tap diam 0.33 SR
71= 6.4	106272GN	Tap diam 0.43 R
72= 6.4	106273GN	Tap diam 0.63
73= 6.5	001282	Tap fixing screw
74= 6.6	094654	Tap bracket
75= 6.8A	215465	Burner-cupA

76= 6.8SR	215466	Burner-cupSR
77= 6.8R	215467	Burner-cupTR
78= 6.9A	068109003	Burner-head Auxiliary
79= 6.9SR	068110003	Burner-head Semi-rapid
80= 6.9R	068111003	Burner-head Rapid
81=6.10A	216129005A	Burner-capA
82=6.10SR	216130005A	Burner-capSR
83=6.10R	216131005A	Burner-cap R
84= 6.12	101182	Injector NATURAL GAS Ø 0.85 - A
85= 6.12	101260	Injector NATURAL GAS Ø 1.12 - SR
86= 6.12	101273	Injector Rapid diam 1.45 - NG
87= 6.12	101262	Injector ULPG Ø 0.53 - A
88= 6.12	101263	Injector ULPG Ø 0.70 - SR
89= 6.12	101244	Injector Rapid diam 0.91 - LPG
90= 6.14	053024.1	Sealing washer
91= 6.15	215469	Burner-cup Triple-ring
92= 6.17	101233	Injector ULPG Ø 0.95 - TR
93= 6.17	101335	Injector NATURAL GAS Ø 1.60 - TR
94= 6.19	029633	Inlet pipe - front right A
95= 6.20	029632	Inlet pipe - rear right SR
96= 6.21	029649	Inlet pipe - central TR
97= 6.22	029650	Inlet pipe - front left R
98= 6.23	029630	Inlet pipe - rear left SR
99= 6.25	068136003	Burner head TR
100= 6.26	107039	Burner thermocouple L=500 mm
101= 6.26	107042	Burner thermocouple TR L=350 mm
102= 6.27	214057	NUT
103= 6.28	103347	Gas pressure regulator 1/2
104= 6.29	067026	Conical adaptor
105= 6.30	103468	Test point adaptor
106= 6.36	216132005A	Burner-cap inside TR
107= 6.37	216133005A	Burner-cap outside TR
108= 6.38	053078	Triple-ring burner-cup gasket
109= 6.39	053104	Burner-cup gasket SR
110= 6.40	053103	Burner-cup gasket A
111= 6.41	053105	Burner-cup gasket R
112= 8.1	2183009380	Burner knob
113= 8.2	1031147	Thermostat switch

114= 8.3	003040	STARLOCK WASHER
115= 8.4	103894	CAM
116= 8.5	103888	Switch support
117= 8.6	062074004	Grill element
118= 8.7	215494	Oven burner
119= 8.8	101285	Oven burner injector diam 1.90 - NG
120= 8.8	101412	Oven burner injector diam 1.13 - ULPG
121= 8.9	035119	SPRING
122= 8.11	0291151	Oven burner inlet pipe
123= 8.12	053045	Oven thermostat gasket
124= 8.13	001053	SCREW
125= 8.14	4219603Z	Burner shield
126= 8.15	084055	Burner igniter L=1700 mm
127= 8.16	067030	Oven injector housing
128= 8.17	47A9601G.2	Fan shroud
129= 8.18	079049	Fan motor 230 V
130= 8.20	094155	Oven thermostat fixing bracket
131= 8.21	066165	Oven gas thermostat
132= 8.22	213026	CLIP
133= 8.23	107074	Oven thermocouple L=1300 mm
134= 9.1	2183009464	KNOB
135= 9.3	074009	60 min alarm
136=11.1	072025	Lamp holder assembly
137=11.2	073013001	LAMP
138=11.3	051054	Terminal block
139=11.4	103451	Terminal block cover
140=11.5	082095	Electronic Ignition
141=11.7	035094	Igniter spring
142=11.8	084029	Spark plug L=630mm (semirapid &
143=11.8	084033	Igniter TR - L = 500
144=11.8	084036	Igniter L = 900
145=11.10	056034	Cable terminal
146=11.13	041210	Earth plate
147=11.15	054094	Cord 3x2.5
148=11.16	1132372	Wiring harness
149=11.17	066145	Cut-off thermostat 80 degrees
150=11.17	066057	Cut-off thermostat
151=11.18	1031241	Ignition switches (cooktop burners)

152=11.20	003077	RETAINING RING
153=11.21	073091	Control lamp L = 230
154=11.22	073090	Control lamp cover (Blue)
155=11.23	077081	Microswitch (grill exclusion with gas oven operating)
156=11.24	094556	Microswitch lever
157=11.25	050045	Electric grill switch
158=11.26	050067	Oven light/fan motorswitch
159=11.27	066078	THERMOSTAT
160=11.28	2183009464	KNOB