





















Position	Code	description
0	1031584	Right telescopic runner
1=1.1	103630063	Rear trim
2=1.5	040041001	PLUG
3=1.6	001007	Vis
4=2.1	3429S50001	Manifold
5=2.2	3319L505S	Cooktop
6=2.5	51B9S01	Burners support
7=2.6	027015	Inlet pipe plug
8=2.7	1031639	SPACER
9=2.12	053024.1	Sealing washer
10=2.13	103615	PIN
11=2.14	035100	SPRING
12=2.15	217530	Pan-support
13=2.16	217534	Central pan support
14=2.17	214062	NUT
15=2.18	094793	Fixing plate
16=2.19	217303	Grate for small pans
17=2.20	51B9S05	Cross-piece
18=2.23	001234.1	Stainless steel screw V
19=2.26	001167	SCREW
20=2.27	217498	Grid for woks
21=3.1	35M9102LD1	CONTROL PANEL
22=3.2	103760	Control panel trim
23=3.8	213007	CLIP
24=4.4	030267	Oven insulation
25=4.5	030213	Rear insulation
26=4.6	094417DX	Rear hob support right
27=4.7	094417SX	Rear hob support left
28=4.8	4119602	REAR PANEL
29=4.9	4219T06Z	Upper shelter
30=4.11	1031588	SPACER
31=4.13	053101	SEAL
32=4.18	6308504	SHIM
33=4.20	040061	BUFFER
34=4.21	063075	HINGE
35=4.23	371V9601L	FRONT PANEL
36=4.24	373V9601A	Inside panel

37=4.25	36C96D1S	Side panel right
38=4.26	36C96S1S	Side panel left
39=4.31	094412	BRACKET
40=4.32	4219604Z	Rear insulation support
41=4.33	4216108Z	Hinge protection
42=4.34	035097	Rotisserie hole plug
43=4.36	081084/NS	Left stopper
44=4.37	081083/NS	Right stopper
45=4.38	46A9S02Z	Air conveyor
46=4.39	46A9S01Z	FUNNEL
47=4.40	079025	Tangential fan
48=4.42	040056	Rubber
49=4.48	6300040	Anti tilt bracket
50=4.50	4419S1EM100	Oven frame
51=5.1	0312662	DOOR GLASS
52=5.2	083240061	Lower door trim
53=5.3	037195062	Door handle
54=5.4	103713	Door handle plaque
55=5.5	51B9605	Handle trim
56=5.6	001030	SCREW
57=5.8	063146	Door hinge (male)
58=5.9	063148	Door hinge (female)
59=5.10	373F9606G	Door panel
60=5.11	053058	GASKET
61=5.12	0311292/TH	Inner glass
62=5.14	214021	NUT
63=5.15	001143	SCREW
64=5.16	003035	WASHER
65=5.17	103205.1	WASHER
66=5.23	003030	WASHER
67=7.1	217291	Shelf support
68=7.2	217497	Oven tray support
69=7.3	48B8501G	Oven tray
70=7.4	217626	OVEN SHELF
71=7.6	47E9603G	Oven floor
72=7.7	037208	Grill-pan grid handle
73=7.8	217523	Grill-pan grid
74=6.1	2183009462	Burner knob

75=6.4	106266	Tap diam 0.28 A
76=6.4	106267	Tap diam 0.33 SR
77=6.4	106268	Tap diam 0.43 R
78=6.4	106269	Tap diam 0.63
79=6.5	001282	Tap fixing screw
80=6.6	094653	Tap bracket
81=6.8A	215465	Burner-cupA
82=6.8SR	215466	Burner-cupSR
83=6.8R	215467	Burner-cupTR
84=6.9R	068111001	Burner head A
85=6.9SR	068110001	Burner-head SR
86=6.9A	068109001	Burner-head A
87=6.10A	216129005A	Burner-capA
88=6.10SR	216130005A	Burner-capSR
89=6.10R	216131005A	Burner-cap R
90=6.12	101182	Injector NATURAL GAS Ø 0.85 - A
91=6.12	101273	Injector Rapid diam 1.45 - NG
92=6.12	101260	Injector NATURAL GAS Ø 1.12 - SR
93=6.12	101244	Injector Rapid diam 0.91 - LPG
94=6.12	101262	Injector ULPG Ø 0.53 - A
95=6.12	101263	Injector ULPG Ø 0.70 - SR
96=6.14	053024.1	Sealing washer
97=6.15	215469	Burner-cup Triple-ring
98=6.16	103347	Gas pressure regulator 1/2
99=6.17	101335	Injector NATURAL GAS Ø 1.60 - TR
100=6.17	101233	Injector ULPG Ø 0.95 - TR
101=6.19	029633	Inlet pipe - front right A
102=6.20	029632	Inlet pipe - rear right SR
103=6.21	029649	Inlet pipe - central TR
104=6.22	029650	Inlet pipe - front left R
105=6.23	029630	Inlet pipe - rear left SR
106=6.25	068112001	TR burner head
107=6.29	067026	Conical adaptor
108=6.30	103468	Test point adaptor
109=6.36	216132005A	Burner-cap inside TR
110=6.37	216133005A	Burner-cap outside TR
111=6.38	053078	Triple-ring burner-cup gasket
112=6.39	040064	STOPPER

113=8.1	2183009464	KNOB
114=8.3	103948	Switch spacer
115=8.15	050030	Oven switch
116=8.16	066072	Oven thermostat
117=8.17	062100004	Top element
118=8.18	062101004	Bottom element
119=8.19	030076.1	Bottom element insulation
120=8.20	4219602Z	Bottom insulation support
121=8.21	4219605Z	Bottom element support
122=8.23	47A9603G	Fan diffuser
123=8.24	079008001F	Fan motor - 230 V
124=8.28	094660	Plaque
125=8.27	213025	CLIP
126=9.1	074069	Electronic programmer
127=9.2	094363	Electronic timer seal
128=9.3	1031057007	Button
129=9.4	040056	Rubber
130=11.1	072025	Lamp holder assembly
131=11.2	073013001	LAMP
132=11.3	051054	Terminal block
133=11.5	082095	Electronic Ignition
134=11.7	035094	Igniter spring
135=11.8	084029	Spark plug L=630mm (semirapid &
136=11.8	084033	Igniter TR - L = 500
137=11.8	084036	Igniter L = 900
138=11.15	054094	Cord 3x2.5
139=11.16	1131791	WIRING
140=11.18	1031237	Ignition switches
141=11.20	003077	RETAINING RING
142=11.33	073090	Control lamp cover (Blue)
143=11.34	073091	Control lamp L = 230
144=11.36	066123	Cut-out thermostat 160 degree C