




Position	Code	description
1	333A20ESDA	Cooktop
2	218338X339	KNOB
3	040057	Rubber joint
7a	068111003	Burner-head Rapid
7b	068110003	Burner-head Semi-rapid
9a	216131005A	Burner-cap R
9b	216130005A	Burner-capSR
11	4113A13	CASING
12	054090	Power cord with plug 3 x 0.75 mm ²
13	051054	Terminal block
14	10348100X	PLUG
15	094271	BRACKET
16	217303	Grate for small pans
17	053037	SEAL
20	067008	Elbow
21	053024.1	Sealing washer
23	082076	Electronic ignition
25	103451	Terminal block cover
26	3423A20G07	Inlet pipe
29	001221	SCREW
30	094338	Fixing bracket
33	035094	Igniter spring
35	084028	Spark plug L=250mm (auxiliary burner)
36	217515005	Pan-support
38	106231	R tap - diameter 0.40
39	106230	SR tap - diameter 0.30
40	029595	R gas pipe
41	029594	SR gas pipe
42a	101273	Injector Rapid diam 1.45 - NG
42b	101244	Injector Rapid diam 0.91 - LPG
42c	101260	Injector NATURAL GAS Ø 1.12 - SR
42d	101263	Injector ULPG Ø 0.70 - SR
43a	215467	Burner-cupTR
43b	215466	Burner-cupSR
44	067026	Conical adaptor
45	214057	NUT
46	107039	Burner thermocouple L=500 mm

47	107039	Burner thermocouple L=500 mm
48	035095	SPRING
49	003055	WASHER
50	103494	Ignition microswitches
51	103347	Gas pressure regulator 1/2
52	103468	Test point adaptor