























Position	Code	description
1= 1.1	103507061	Rear trim
2= 1.2	069077/NS	Right spring
3= 1.3	069078/NS	Left spring
4= 1.4	069042/NS	Right hinge bracket
5= 1.5	069041/NS	Left hinge bracket
6= 1.7	069040/NS	Right trim corner
7= 1.8	069039/NS	Left trim corner
8= 1.9	083205061	Right/Left trim
9= 1.17	001111	SCREW
10= 2.1	3429650G02	Manifold
11= 2.2	33196503S	Cooktop
12= 2.3	001057	Stainless steel screw
13= 2.5	51B9601	Burners support
14= 2.6	027015	Inlet pipe plug
15= 2.7	071042002	Plastic peg - (Black)
16= 2.8	217303	Grate for small pans
17= 2.9	094129	Right hinge bracket
18= 2.10	094130	Left hinge bracket
19= 2.12	053024.1	Sealing washer
20= 2.14	217498	Grid for woks
21= 2.15	217471A	Pan-support
22= 2.16	217473A	Fish-burner pan-support
23= 2.17	085055	SLEEVE
24= 2.18	094254	CLAMP
25= 2.19	001135	SCREW
26= 2.20	4218502Z	Crusspiece
27= 2.21	094252	BRACKET
28= 2.22	213024	Clips
29= 2.23	001170	Screw 8Px9.5
31= 2.27	040011	BUFFER
32= 3.1	35C9139SDA	CONTROL PANEL
33= 3.5	213012	Clips
34= 3.8	213007	CLIP
35= 3.9	030105.1	Control panel insulation
36= 4.4	030074.1	Oven insulation
37= 4.5	030106.1	Rear insulation
38= 4.6	094174	Rear right coupler

39= 4.7	094175	Rear left coupler
40= 4.8	4119602	REAR PANEL
41= 4.9	4219602Z	Bottom insulation support
42= 4.13	053057	Seal (3 sided)
43= 4.14	094131	Front right coupler
44= 4.15	094132	Front left coupler
45= 4.18	1031295.1	SHIM L.150-180
46= 4.20	040061	BUFFER
47= 4.21	063075	HINGE
48= 4.23	371V9601L	FRONT PANEL
49= 4.24	373V9601A	Inside panel
50= 4.25	36C96D1S	Side panel right
51= 4.26	36C96S1S	Side panel left
52= 4.32	4219604Z	Rear insulation support
53= 4.35	094266	Rotisserie motor support
54= 4.36	103506	Control panel protection
55= 4.37	103505	Rotisserie motor protection
56= 4.38	094153	Anti tilt bracket
57= 4.50	45EN6106K	Oven side panel (Left)
58= 4.51	45E96001K	Top oven panel
59= 4.52	45EN6107K	Oven side panel (Right)
60= 4.53	45H96004K	BODY REAR PANEL
61= 4.55	45B96002K	Body front panel
62= 4.56	45K96003Z	Lower element cover
63= 4.57	211012	RIVET
64= 5.1	032961882J	OVEN DOOR GLASS
65= 5.3	037195062	Door handle
66= 5.4	103198	WASHER
67= 5.5	003057	WASHER
68= 5.6	001083	SCREW
69= 5.7	030108.1	Door insulation
70= 5.8	063100	Door hinge (male)
71= 5.9	063066	Top oven hinge (female) works with male hinge 063096
72= 5.10	373F9603G	INNER DOOR
73= 5.11a	053058	GASKET
73= 5.11b	053101	SEAL
74= 5.12	0311292/TH	Inner glass

75= 5.14	214021	NUT
76= 5.15	001143	SCREW
77= 5.16	003035	WASHER
78= 5.17	103205.1	WASHER
79= 5.22	003041	WASHER
80= 5.23	053083	GASKET
81= 5.24	213029	CLIP
82= 5.25	030107.1	Side insulation
83= 5.26	001089	SCREW
84= 5.27	001007	Vis
85= 6.1	218344E322	KNOB
86= 6.4a	106116	Tap - diameter 0.27
87= 6.4b	106083	Tap - diameter 0.29
88= 6.4c	106133	Tap - diameter 0.47
89= 6.5	001053	SCREW
90= 6.6	094151	Tap bracket
91= 6.7a	215172	A burner
92= 6.7b	215173	SR burner
93= 6.7c	215175	UR burner
94= 6.8a	068072006	SR burner head
95= 6.8b	068073006	A burner head
96= 6.9a	216074016	RING A
97= 6.9b	216075134	SR burner-ring
98= 6.10a	216070080	Double ring burner-cap (Black)
99= 6.10b	216071005	SR burner-cap
100= 6.11a	024019	A-SR air regulation tube
101= 6.11b	024021	UR air regulation tube
102= 6.12a	101069	Injector - diameter 0.83
103= 6.12b	101080	Injector - diameter 0.92
104= 6.12c	101137	Injector - diameter 0.50
105= 6.12d	101111	Injector - diameter 0.67
106= 6.12e	101208	Injector - diameter 1.60
107= 6.12f	101129	Injector - diameter 1.15
108= 6.12g	101167	Injector - diameter 1.45
109= 6.13	001017	SCREW
111= 6.15	067026	Conical adaptor
112= 6.16	103347	Gas pressure regulator 1/2
113= 6.17a	51B9602	Tap bracket

114= 6.17b	51B9603	Tap bracket
115= 6.19	029475	DR inlet pipe left
116= 6.20	029448	SR inlet pipe left
117= 6.21	029472	A inlet pipe right
118= 6.22	029474	SR inlet pipe right
119= 6.23	029473	FB inlet pipe central front
120= 6.24a	107009	Thermocouple L=450 mm
121= 6.24b	107012	Burner thermocouple L.600
122= 6.25	R00550280	BRASS NUT FOR THERMOCOUPLE
123= 6.29	068075006	Double ring burner-head
124= 6.30	216100140	DR outside burner-ring
125= 6.31	216074230	BURNER CAP RING
126= 6.38	027013	NG connection
127= 6.40	068084006	Fish-burner cap
128= 6.42	216116005	Fish burner-cap
129= 7.1	217291	Shelf support
130= 7.2	217497	Oven tray support
131= 7.3	48B8501G	Oven tray
132= 7.4	217626	OVEN SHELF
133= 7.6	47E9604G	Oven floor
134= 7.7	48B6101G	DRIP PAN
135= 7.8	037144	Grill pan grid handle
136= 7.9	217397	Grill-pan grid
137=7.10a	080027	Rotisserie spear (without handle)
137=7.10b	037012	Spear handle
138= 7.11	079014	Rotisserie motor
139= 7.12	217401.1	Rotisserie support
140= 7.13	103532	Cast iron griddle
141= 7.18	473000	Catalytic panels
143= 8.15	050028.1	Oven switch
144= 8.16	066072	Oven thermostat
145= 8.17	062075004	Top element 230V
146= 8.18	062073004	Bottom element 230V
147= 8.19	030076.1	Bottom element insulation
149= 8.21	4219605Z	Bottom element support
150= 8.23	47A9601K.2	Fan diffuser
151= 8.24	079008001F	Fan motor - 230 V
152= 8.26	062057004	Fan element - 230 V

153= 8.27	213025	CLIP
154= 9.1	074055	Electronic programmer
155= 9.2	094363	Electronic timer seal
156= 9.3	103376080	Programmer Button
157= 9.4	040056	Rubber
158= 11.1	072025	Lamp holder assembly
159= 11.2	073013001	LAMP
160= 11.5	082095	Electronic Ignition
161= 11.7	035011	Igniter spring
162= 11.8a	084022	Igniter - L = 800 mm
163= 11.8b	084022	Igniter - L = 800 mm
165= 11.11	103230.1A	Terminal block protection
166= 11.13	041210	Earth plate
167= 11.14	052002	Wire fastener
168= 11.15	054041	CORD
169= 11.16	1131114.SA	Wiring (new connection)
170= 11.18	103569	Ignition switches
171= 11.19	035080	Ignition switches spring
172= 11.20	003039	RETAINING RING
173= 11.21	003038	WASHER
174= 11.22	050058	Knob switch
175= 11.23	218344E320	Butterfly Knob
176= 11.32	051049	Terminal block 25A-3P
177= 11.33	073016025	Control lamp cover (Red)
178= 11.34	073038.2	Control lamp L=200
179= 11.36	066123	Cut-out thermostat 160 degree C
180= 11.37	094348	Ignition coil support