







Position	Code	description
0= 00	630F612	Oven condensation kit
1= 1.1	032F3108DA	Glass fascia panel
2= 1.2	032F3074DA	DOOR GLASS
3= 1.3	0313242TH	Inner glass
4= 1.4	063120	Hinge (male)
5= 1.5	51AF621SA	Left door trim
6= 1.6	51AF621DA	Right door trim
7= 1.7	037280061	Door handle
8= 1.8	053125	SEAL
9= 1.9a	040051	Rubber
10= 1.9b	040056	Rubber
11= 1.10	51BF623A	Handle bar
12= 1.11	35MF6009A	Interior control panel
13= 1.12	001266	SCREW
14= 1.13	51BF601DA	Right front trim
15= 1.14	51BF601SA	Left front trim
16= 1.15	411F6D1Z	Right side panel
17= 1.16	411F6S1Z	Left side panel
18= 1.17	411F602.1	Bottom panel
19= 1.18	08328400A	Lower trim
20= 1.19	094390	Door hinge (female)
21= 1.20	030191	Oven insulation
22= 1.21	030189	Rear insulation
23= 1.22	035101	Insulation spring
24= 1.23	411F607	Lower air conveyor
25= 1.24	421F602Z	Conveyor support
26= 1.25	411F605	Air conveyor
27= 1.26	079017	Tangential fan
29= 1.28	450F61EM58	Oven cube
30= 1.29	030229.1	Side lamp insulation
31= 1.30	411F603	REAR PANEL
32= 1.31	411F613	Upper shelter
33= 1.32	51BF614S.1	Deflector
34= 1.33	103672	WIRE CLAMP
35= 1.34	053074	Upper seal
36= 1.35	053087	SEAL
37= 1.36	0312570TH	Intermediate glass

38= 1.37	1031052	Top middle glass clamp
39= 1.38	1031053	Bottom middle glass clamp
40= 1.39	001208	Trim upper screw
41= 1.40	053143	SEAL
42= 1.41	411F614	Upper shelter plate
43= 2.3	094623	Display electronic card support
44= 2.4	074092	Display electronic card
45= 2.5	071060	Programmer electronic peg
46= 2.6	039063	Programmer electronic card insulator
47= 2.7	074081	Power electronic card
48= 2.8	094592	Power electronic card support
49= 2.9	039064	Power electronic card insulator
50= 2.10	072026	LAMP HOLDER
51= 2.11	073103	LAMP
52= 2.12	062090004	Bottom element - 230 V
54= 2.14	062097004	Fan element
55= 2.15	079046	Fan motor - 220/240 V
56= 2.16	47AF6020	Fan diffuser
57= 2.17	51BF603.1	Bottom element support
58= 2.18	217646	Shelf support
59= 2.19	001142	Shelf support screw
60= 2.20	48BF602G	Oven tray
61= 2.21	217551.1	WIRE SHELF
62= 2.22	217558.2	WIRE SHELF
63= 2.23	217546	Grill-pan grid
64= 2.24	037144	Grill pan grid handle
65= 2.25	1031037	Right telescopic runner
66= 2.26	1031038	Left telescopic runner
67= 2.27	051079	Terminal Block
68= 2.28	1131662	WIRING
69= 2.29	054120	Cord 3x1.5
70= 2.30	072022	Side lamp holder
71= 2.31	066056	Cut-off thermostat 120 degree
72= 2.32	211035	Stud
73= 2.33	003074	WASHER
74= 2.34	214070	NUT
75= 2.35	030136.1	Fan motor insulation
76= 2.37	107063	PROBE

77= 2.38	103978	Antijamming filter
78= 2.39a	1131578	Electronic cards wiring
79= 2.39b	1131595	Electronic cards wiring (Side lamp)
80= 2.40	103085	FILTER
81= 2.41	473070	Lateral catalytic panel
82= 2.42	473160	Left lateral catalytic panel