













Position	Code	description
0= 00	630F612	Oven condensation kit
1= 1.1	032F2759DA	CONTROL PANEL
2= 1.2	450F31ES41	Oven Cube
3= 1.3	450F61EM59	Bottom oven body
4= 1.8	53102	Top oven seal
5= 1.9	35101	Insulation spring
6= 1.1	51BF613	Oven body bar
7= 1.11	3044	SPACER
8= 1.12	51BF614S.1	Deflector
9= 1.13	51BFD01DS	Right front trim
10= 1.14	51BFD01SS	Left front trim
11= 1.15	411FDD1Z	Right side panel
12= 1.16	411FDS1Z	Left side panel
13= 1.17	411F602.1	Bottom panel
14= 1.18	08328400A	Lower trim
15= 1.19	94390	Door hinge (female)
16= 1.2	30140.1	Top oven rear insulation
17= 1.21	30200	Bottom oven rear insulation
18= 1.22	30139.1	Top oven insulation
19= 1.23	30199	Bottom oven insulation
20= 1.24	30229.1	Side lamp insulation
21= 1.25	35097	Rotisserie hole plug
22= 1.28	103672	WIRE CLAMP
24= 1.3	411FD01	REAR PANEL
25= 1.31	411F604	Upper shelter
26= 1.32	51BF609	Terminal block shield
27= 1.33	51BF612H	Top oven body panel
28= 1.34	53074	Top-bottom seal
29= 1.35	53087	SEAL
30= 1.36	94620	Terminal block support
31= 1.37	94392	Cut-off thermostat support
32= 1.4	79017	Right tangential fan
33= 1.45	40056	Rubber
34= 1.46	411FD02	Bottom air conveyor
35= 1.47	421F602Z	Conveyor support
36= 1.48	411F605	Air conveyor
38= 2.2	032F2717DA	DOOR GLASS

39= 2.3	0312578TH	Inner glass
40= 2.4	063112	Hinge (male)
41= 2.5	063117	Hinge (male)
43= 2.8	053125	SEAL
45= 2.10	51BF623A	Handle bar
47= 2.12	51AF303SH	Left door trim
48= 2.13	51AF303DH	Right door trim
49= 2.15	062115004	Top + grill element - 230V
50= 2.16	213023	CLIP
51= 2.17	062105004	Bottom element 230 V
52= 2.18	51BF603.1	Bottom element support
53= 2.21	050040.1	Oven switch
54= 2.22	066157	THERMOSTAT
55= 2.23	218900A463	CONTROL KNOB
56= 2.26	217648	Shelf support
58= 2.29	217551.1	WIRE SHELF
59= 2.31	094516	Hook support
60= 2.32	534186	HOOK
61= 3.1	032F2716DA	DOOR GLASS
62= 3.2	0313241TH	Inner glass
63= 3.3	0312570TH	Intermediate glass
64= 3.4	063120	Hinge (male)
65= 3.5	51AF621SA	Left door trim
66= 3.6	51AF621DA	Right door trim
67= 3.7	037241062	Door handle
68= 3.8	103686.1	WASHER
70= 3.10	51BF625H	Handle bar
71= 3.11	001265	Door handle screw
72= 3.12	001270	SCREW
73= 3.13	1031052	Top middle glass clamp
74= 3.14	1031053	Bottom middle glass clamp
75= 3.15	211035	Stud
76= 3.16	003093	RETAINING RING
77= 3.17	1031404	Top + grill element fixing screw
78= 3.20	103085	FILTER
79= 3.27	062144004	Top + grill element 230V
80= 3.28	062090004	Bottom element - 230 V
81= 3.29	062097004	Fan element

83= 3.31	079046	Fan motor - 220/240 V
84= 3.32	030136.1	Fan motor insulation
85= 3.35	47AF6010	Fan diffuser
86= 3.36	217646	Shelf support
87= 3.37	001142	Shelf support screw
88= 3.38	48BF601G	Oven tray
89= 3.39	103406	Kit pizza stone
91= 3.41	217558.2	WIRE SHELF
92= 3.42	217546	Grill-pan grid
93= 3.43	037144	Grill pan grid handle
94= 3.44	1031037	Right telescopic runner
95= 3.45	1031038	Left telescopic runner
96= 3.46	473070	Lateral catalytic panel
97= 3.47	473160	Left lateral catalytic panel
98= 3.48	48EF601	Pastry plate
99= 4.3	094590	Programmer electronic card support
100= 4.4	074074B	Programmer electronic card
101= 4.5	071060	Programmer electronic peg
102= 4.6	039063	Programmer electronic card insulator
103= 4.7	074081	Power electronic card
104= 4.8	094592	Power electronic card support
105= 4.9	039064	Power electronic card insulator
106= 4.10	1031217	Pivot button (please order the control panel assembly)
107= 4.11	035111	Spring Plate (please order the complete control panel)
108= 4.12	10312130A	Consolle frame (please order complete control panel)
109= 4.13	103121207	Button (please order complete control panel)
110= 4.14	035112	Spring plate (please order the control panel assembly)
111= 4.15	10312140A	Consolle frame (please order the control panel assembly)
112= 4.19	073092	Control lamp cover
113= 4.20	073095	Control lamp L 600/230
114= 4.22	107063	PROBE
115= 4.23	039038	Insulation
116= 4.24	103978	Antijamming filter
117= 4.25	066068	Cut-off thermostat 130 degree
118= 4.25	066140	Cut-off thermostat 175 degree
119= 4.25	066145	Cut-off thermostat 80 degrees
120= 4.26	072006	LAMP HOLDER

121= 4.28	073013001	LAMP
122= 4.27	072020	Side lamp holder
123= 4.29	051062	Terminal block
124= 4.30	052008	Cable clamp - rear cooker
125= 4.32	052007	Wire ring
126= 4.31	1131804	WIRING
127= 4.33	1131578	Electronic cards wiring
128= 4.33	1131595	Electronic cards wiring (Side lamp)