

























Position	Code	description
0= 00	630F612	Oven condensation kit
1= 1.1	032F3112DA	CONTROL PANEL
2= 1.2	450F31EM41	Top oven body
3= 1.3	450F61EM59	Bottom oven body
4= 1.4	35MF6011A	Interior control panel
5= 1.5	053143	SEAL
6= 1.8	053102	Top oven seal
7= 1.9	035101	Insulation spring
8= 1.10	51BF613	Oven body bar
9= 1.11	003044	SPACER
10= 1.12	51BF614S.1	Deflector
11= 1.13	51BFD01DA	Right front trim
12= 1.14	51BFD01SA	Left front trim
13= 1.15	411FDD1Z	Right side panel
14= 1.16	411FDS1Z	Left side panel
15= 1.17	411F602.1	Bottom panel
16= 1.18	08328400A	Lower trim
17= 1.19	094390	Door hinge (female)
18= 1.20	030218.1	Top oven rear insulation
19= 1.21	030189	Rear insulation
20= 1.22	030139.1	Top oven insulation
21= 1.23	030191	Oven insulation
22= 1.24	030229.1	Side lamp insulation
23= 1.28	103672	WIRE CLAMP
24= 1.29	040078	BUFFER
25= 1.30	411FD01	REAR PANEL
26= 1.31	411F604	Upper shelter
27= 1.32	51BF609	Terminal block shield
28= 1.33	51BF612A	Top oven body panel
29= 1.34	053074	Upper seal
30= 1.35	053087	SEAL
31= 1.36	094620	Terminal block support
32= 1.37	094392	Thermal overload support
33= 1.40	079017	Tangential fan
35= 1.46	411FD02	Bottom air conveyor
36= 1.47	421F602Z	Conveyor support
37= 1.48	411F605	Air conveyor

AU, NZ DE6038MD

38= 2.1	218900A477	CONTROL KNOB
39= 2.2	050028.1	Oven switch
40= 2.3	066078	THERMOSTAT
41= 2.4	062132004	Top + grill element 230 V
42= 2.5	062105004	Bottom element 230 V
44= 2.7	062097004	Fan element
45= 2.8	040056	Rubber
46= 2.9	030136.1	Fan motor insulation
47= 2.11	2180009478	KNOB GOBLET
48= 2.12	1031299	RING GOBLET
49= 2.13	094696	Control knob ring bracket
51= 2.15	211035	Stud
52= 2.16	003074	WASHER
53= 2.17	214070	NUT
54= 2.18	47AF301G	Fan diffuser
55= 2.19	062133004	Fan element 230 V
56= 2.20	079050	Fan motor 230 V
57= 2.21	085104	Diffuser bush
58= 2.22	47AF6020	Fan diffuser
59= 2.23	103085	FILTER
60= 2.24	51BF603.1	Bottom element support
61= 2.25	066157	THERMOSTAT
62= 2.26	062144004	Top + grill element 230V
63= 2.27	062090004	Bottom element - 230 V
64= 2.28	079008001F	Fan motor - 230 V
65= 2.29a	213023	CLIP
66= 2.29b	213025	CLIP
67= 3.1	217648	Shelf support
68= 3.2	001142	Shelf support screw
70= 3.8	217551.1	WIRE SHELF
71= 3.9	217558.2	WIRE SHELF
72= 3.10	48BF602G	Oven tray
73= 3.16	473070	Lateral catalytic panel
74= 3.17	473160	Left lateral catalytic panel
75= 3.22	217546	Grill-pan grid
76= 3.23	037144	Grill pan grid handle
77= 3.24	217646	Shelf support
78= 4.2	032F3113DA	DOOR GLASS

79= 4.3	0312578TH	Inner glass
80= 4.4	063112	Hinge (male)
82= 4.7	037280061	Door handle
83= 4.8	053125	SEAL
85= 4.10	51BF623A	Handle bar
86= 4.11	001266	SCREW
87= 4.12	51AF303SA	Left door trim
88= 4.13	51AF303DA	Right door trim
89= 4.21	032F3074DA	DOOR GLASS
90= 4.22	0313241TH	Inner glass
91= 4.23	0312570TH	Intermediate glass
92= 4.24	063120	Hinge (male)
93= 4.25	51AF621SA	Left door trim
94= 4.26	51AF621DA	Right door trim
95= 4.27	037280061	Door handle
97= 4.30	51BF625A	Handle bar
98= 4.31	001265	Door handle screw
99= 4.32	001270	SCREW
100= 4.33	1031052	Top middle glass clamp
101= 4.34	1031053	Bottom middle glass clamp
102= 5.1	074105	Electronic timer
103= 5.2	073103	LAMP
104= 5.3	072026	LAMP HOLDER
105= 5.5	072022	Side lamp holder
106= 5.6	051062	Terminal block
107= 5.9	073092	Control lamp cover
108= 5.10	073091	Control lamp L = 230
109= 5.12	052008	Cable clamp - rear cooker
110= 5.13	052007	Wire ring
111= 5.14	1132161	WIRING
112= 5.15	1131595	Electronic cards wiring (Side lamp)
113= 5.16a	066068	Cut-off thermostat 130 degree
114= 5.16b	066123	Cut-out thermostat 160 degree C
115= 5.16c	066080	Cut-off thermostat 55 degree