








Position	Code	description
0= 00	630F612	Oven condensation kit
1= 1.1	032F3106DA	Glass fascia panel
2= 1.2	032F3107DA	DOOR GLASS
3= 1.3	0313242TH	Inner glass
4= 1.5	51AF633DH	Right door trim
5= 1.6	51AF632SH	Left door trim
6= 1.7	037281061	FLAT HANDLE FOR DEIBWC22B
7= 1.8	053125	SEAL
9= 1.10	51BF634A	Handle bar
10= 1.12	001266	SCREW
11= 1.16	0312570TH	Intermediate glass
12= 1.17	1031052	Top middle glass clamp
13= 1.18	1031053	Bottom middle glass clamp
14= 1.19	094641ASX	Top hinge bracket
15= 1.20	001208	Trim upper screw
16= 1.30	094639ASX	Lower hinge bracket
17= 1.31	081087SX	Hinge bracket shelter
18= 1.32	51BF636SA	Door trim reinforcement
19= 1.33	085101	Hook pin bush
20= 1.34	071061	DOOR PIN
21= 1.35	214026	NUT
22= 1.36	003019	WASHER
23= 1.38	51AF635S	Hinge frame
24= 1.39	35MF6010A	Interior control panel
25= 1.40	51BF637SA	Left front trim
26= 1.41	51BF631DA	Right front trim
27= 1.42	411F615SZ	Left side panel
28= 1.43	411F616DZ	Right side panel
29= 1.44	411F602.1	Bottom panel
30= 1.45	08328400A	Lower trim
31= 1.46	094636	Door hook support
32= 1.47	030120.1	Oven insulation
33= 1.48	030200	Rear insulation
34= 1.49	035101	Insulation spring
35= 1.50	411F607	Lower air conveyor
36= 1.51	421F602Z	Conveyor support
37= 1.52	411F605	Air conveyor

NZ, AU DE608MLH

38= 1.53	079017	Tangential fan
39= 1.54	040056	Rubber
40= 1.55	450F61EM58	Oven cube
41= 1.56	411F603	REAR PANEL
42= 1.57	411F604	Upper shelter
43= 1.58	51BF630SXS	Control panel deflector
44= 1.59	103672	WIRE CLAMP
45= 1.60	053074	Upper seal
46= 1.61	053087	SEAL
47= 1.62	103782	DOOR HOOK
48= 1.63	094638	Door hook shelter plate
49= 1.64	094640SX	Top hinge bracket support
50= 1.65	030229.1	Side lamp insulation
51= 2.1	218900A477	CONTROL KNOB
52= 2.2	050028.1	Oven switch
53= 2.3	066157	THERMOSTAT
54= 2.4	073092	Control lamp cover
55= 2.5	073091	Control lamp L = 230
56= 2.6	073093	Control lamp L = 600
57= 2.7	213023	CLIP
58= 2.8	074105	Electronic timer
59= 2.12	062144004	Top + grill element 230V
60= 2.13	062090004	Bottom element - 230 V
61= 2.14	062097004	Fan element
62= 2.15	079008001F	Fan motor - 230 V
63= 2.16	47AF6020	Fan diffuser
64= 2.17	51BF603.1	Bottom element support
65= 2.18	103085	FILTER
66= 2.27	211035	Stud
67= 2.28	003074	WASHER
68= 2.29	214070	NUT
69= 2.30	030136.1	Fan motor insulation
70= 2.31a	094696	Control knob ring bracket
71= 2.31b	1031299	RING GOBLET
72= 2.32.	2180009478	KNOB GOBLET
73= 2.33	217646	Shelf support
74= 2.34	001142	Shelf support screw
75= 2.35	217551.1	WIRE SHELF

76= 2.36	217558.2	WIRE SHELF
77= 2.37	48BF602G	Oven tray
78= 2.38	473070	Lateral catalytic panel
79= 2.39	473160	Left lateral catalytic panel
80= 2.40	217546	Grill-pan grid
81= 2.41	037144	Grill pan grid handle
82= 2.42	072026	LAMP HOLDER
83= 2.43	073013001	LAMP
84= 2.44	072022	Side lamp holder
85= 2.45a	066080	Cut-off thermostat 55 degree
86= 2.45b	066056	Cut-off thermostat 120 degree
87= 2.46	051079	Terminal Block
88= 2.47	054120	Cord 3x1.5
89= 2.48	1132038	WIRING
90= 2.49	1131595	Electronic cards wiring (Side lamp)