



























Position	Code	description
0= 00	630F612	Oven condensation kit
0= 00a	040066	Rubber pad (for trivets)
1= 1.2	032F2716DA	DOOR GLASS
2= 1.3	0313242TH	Inner glass
3= 1.4	063107	Hinge (male)
4= 1.5	51AF621SA	Left door trim
5= 1.6	51AF621DA	Right door trim
6= 1.7	037191062	HANDLE
7= 1.8	053125	SEAL
8= 1.9	040056	Rubber
9= 1.10	51BF623A	Handle bar
10= 2.1	3316S410S	Cooktop
11= 2.2	3426640001	Manifold
12= 2.3	040041001	PLUG
13= 2.4	001130	SCREW
14= 2.7	51B6N01	Burners support
15= 2.8	027015	Inlet pipe plug
16= 2.9	053024.1	Sealing washer
17= 2.10	094254	CLAMP
18= 2.11	001227	SCREW
19= 2.13	103615	PIN
20= 2.14	035100	SPRING
21= 2.15	217530	Pan-support
22= 2.16	217303	Grate for small pans
23= 2.17	214062	NUT
24= 2.18	001234.1	Stainless steel screw V
25= 2.19	217498	Grid for woks
26= 3.1	6306E02	Control panel assy (3.1+3.9+9.3+9.4+9.5)
27= 3.3	51B6E01S	Deflector
28= 3.8	213007	CLIP
30= 4.8	450F61EM46	Oven cube
31= 4.10	094417DX	Rear hob support right
32= 4.11	094417SX	Rear hob support left
33= 4.13	51B6E02H	Right front trim
34= 4.14	51B6E03H	Left front trim
35= 4.15	103410080	SHIM
36= 4.16	214056	Shim nut

37= 4.17	36C6ED1S	Side panel right
38= 4.18	36C6ES1S	Side panel left
39= 4.19	094390	Door hinge (female)
40= 4.20	030191	Oven insulation
41= 4.23	411F607	Lower air conveyor
42= 4.24	421F602Z	Conveyor support
43= 4.25	411F605	Air conveyor
44= 4.26	079017	Tangential fan
45= 4.27	040056	Rubber
46= 4.30	68061008	Plinth
47= 4.34	053074	Upper seal
48= 4.35	053087	SEAL
49= 4.36	4116E01Z	REAR PANEL
50= 4.39	51B6E04Z	Lateral cross -piece support
52= 4.42	4216602Z	Bottom panel
53= 4.43	51BF603	Bottom element support
54= 4.44	51B6E06Z	Left rear trim
55= 4.45	51B6E05Z	Right rear trim
56= 4.46	037279080	Drawer handle front panel
57= 4.47	1031207	Lock pin
58= 4.48	094153	Anti tilt bracket
59= 4.49	4216E02Z	Drawer rear panel
60= 4.50	1031159	Drawer rail spacer
61= 4.51	1031160	Drawer spacer
62= 4.52	39E6E01L	Drawer front panel
63= 4.53	39K6E01Y	DRAWER
64= 4.54	421F603Z	REAR PANEL
65= 4.55	51B6107	Rail support
66= 4.56	030189	Rear insulation
67= 4.57	4216E01Z	Bottom rear panel
68= 4.58	103338DX/E	Right rail
69= 4.59	103338SX/E	Left rail
70= 4.60	103338DX/I	Right drawer rail
71= 4.61	103338SX/I	Right drawer rail
72= 6.1	2183009462	Burner knob
73= 6.4a	106236	Tap diam 0.27 A
74= 6.4b	106237	Tap diameter 0.32
75= 6.4c	106239	Tap diameter 0.65 TR

76= 6.5	001233	Tap fixing screw
77= 6.6	094382	Tap bracket
78= 6.8A	215465	Burner-cupA
79= 6.8SR	215466	Burner-cupSR
80= 6.9SR	068110003	Burner-head Semi-rapid
81= 6.9A	068109003	Burner-head Auxiliary
82= 6.10A	216129005A	Burner-capA
83= 6.10S	216130005A	Burner-capSR
84= 6.11	103468	Test point adaptor
85= 6.12a	101182	Injector NATURAL GAS Ø 0.85 - A
86= 6.12b	101261	Injector - diameter 1.65 TR - Natural gas
87= 6.12c	101260	Injector NATURAL GAS Ø 1.12 - SR
88= 6.12d	101233	Injector ULPG Ø 0.95 - TR
89= 6.12e	101262	Injector ULPG Ø 0.53 - A
90= 6.12f	101263	Injector ULPG Ø 0.70 - SR
91= 6.13	027013	NG connection
93= 6.15	215469	Burner-cup Triple-ring
94= 6.16	103347	Gas pressure regulator 1/2
95= 6.17	067026	Conical adaptor
96= 6.19	029666	Inlet pipe A
97= 6.20	029680	Inlet pipe left SR
98= 6.21	029679	Inlet pipe right SR
99= 6.22	029669	Inlet pipe TR
100= 6.24	107039	Burner thermocouple L=500 mm
101= 6.24	107044	Burner thermocouple L=250 mm - TR
102= 6.25	214057	NUT
103= 6.35	068112003	TR burner head
104= 6.36	216132005A	Burner-cap inside TR
105= 6.37	216133005A	Burner-cap outside TR
106= 6.38	053078	Triple-ring burner-cup gasket
107= 7.1	217647	Shelf support
108= 7.2	001142	Shelf support screw
109= 7.3	217558.2	WIRE SHELF
110= 7.5	48BF601G	Oven tray
111= 7.6	48EF601G	PASTRY PLATE
112= 7.12	103406	Kit pizza stone
113= 7.13	217546	Grill-pan grid
114= 7.14	037144	Grill pan grid handle

115= 7.15	1031037	Right telescopic runner
116= 7.16	1031038	Left telescopic runner
117= 7.18	473070	Lateral catalytic panel
118= 8.1	2183009464	KNOB
119= 8.14	103948	Switch spacer
120= 8.15	050028.1	Oven switch
121= 8.16	066141	THERMOSTAT
122= 8.17	062098004	Top + grill element 230V
123= 8.18	062128004	Bottom element 230V
124= 8.22	062097004	Fan element
125= 8.23	47AF6020	Fan diffuser
126= 8.24	079023	FAN MOTOR
127= 8.25	103085	FILTER
128= 8.27	213023	CLIP
129= 9.1	074069	Electronic programmer
130= 9.2	1031211	Pivot button
131= 9.3	035111	Spring Plate (please order the complete control panel)
132= 9.4	103121307	Consolle frame (please order the complete control panel)
133= 9.5	103121207	Button (please order complete control panel)
134= 9.6	094647	Electronic programmer bracket
135= 11.1	072006	LAMP HOLDER
136= 11.2	073013001	LAMP
137= 11.3	066219	oven safety temperature thermostat
138= 11.5	082082	Electronic ignition
139= 11.7	035094	Igniter spring
140= 11.8	084028	Spark plug L=250mm (auxiliary burner)
141= 11.8	084029	Spark plug L=630mm (semirapid &
142= 11.8	084033	Igniter TR - L = 500
143= 11.11	103230.1A	Terminal block protection
144= 11.13	041210	Earth plate
145= 11.14	052008	Cable clamp - rear cooker
146= 11.15	054041	CORD
147= 11.16	1131797	WIRING
148= 11.17	094221	Earth plate
149= 11.20	003039	RETAINING RING
150= 11.21	003038	WASHER
151= 11.22	035080	Ignition switches spring

152= 11.23	103702	Ignition switches
153= 11.30	066080	Cut-off thermostat 55 degree
154= 11.32	051049	Terminal block 25A-3P
155= 11.33	073090	Control lamp cover (Blue)
156= 11.34	073091	Control lamp L = 230