










Position	Code	description
0= 00	630F612	Oven condensation kit
1= 1.1	630F615	Control panel assembly (including buttons and frame)
2= 1.2	032F2716DA	DOOR GLASS
3= 1.3	0313242TH	Inner glass
4= 1.4	063120	Hinge (male)
5= 1.5	51AF621SA	Left door trim
6= 1.6	51AF621DA	Right door trim
7= 1.7	037241062	Door handle
8= 1.8	053125	SEAL
9= 1.9	040051	Rubber
10= 1.10	51BF623A	Handle bar
11= 1.12	001265	Door handle screw
12= 1.13	51BF601DH	Right front trim
13= 1.14	51BF601SH	Left front trim
14= 1.15	411F6D1Z	Right side panel
15= 1.16	411F6S1Z	Left side panel
16= 1.17	411F602.1	Bottom panel
17= 1.18	08328400A	Lower trim
18= 1.19	094390	Door hinge (female)
19= 1.20	030120.1	Oven insulation
20= 1.21	030200	Rear insulation
21= 1.22	035101	Insulation spring
22= 1.23	411F607	Lower air conveyor
23= 1.24	421F602Z	Conveyor support
24= 1.25	411F605	Air conveyor
25= 1.26	079017	Tangential fan
26= 1.27	040056	Rubber
27= 1.28	450F61EM35	Oven cube
28= 1.29	030190.1	Side lamp insulation
29= 1.30	411F603	REAR PANEL
30= 1.31	411F604	Upper shelter
31= 1.32	51BF614S.1	Deflector
32= 1.33	103672	WIRE CLAMP
33= 1.34	053074	Upper seal
34= 1.35	053087	SEAL
35= 1.36	0312570TH	Intermediate glass
36= 1.37	1031052	Top middle glass clamp

37= 1.38	1031053	Bottom middle glass clamp
38= 1.39	001270	SCREW
39= 1.40	094392	Thermal overload support
40= 2.1	218900A463	CONTROL KNOB
41= 2.2	050028.1	Oven switch
42= 2.3	066157	THERMOSTAT
43= 2.4	073092	Control lamp cover
44= 2.5a	073091	Control lamp L = 230
45= 2.5b	073093	Control lamp L = 600
46= 2.7	213023	CLIP
47= 2.12	062098004	Top + grill element 230V
48= 2.13	062090004	Bottom element - 230 V
49= 2.14	062097004	Fan element
50= 2.15	079008001F	Fan motor - 230 V
51= 2.16	47AF6010	Fan diffuser
52= 2.17	51BF603	Bottom element support
53= 2.18	103085	FILTER
54= 2.21	074069	Electronic programmer
55= 2.22	1031216	Pivot button (please order complete control panel)
56= 2.23	035111	Spring Plate (please order the complete control panel)
57= 2.24	10312130A	Console frame (please order complete control panel)
58= 2.25	103121207	Button (please order complete control panel)
59= 2.26	094648	Electronic programmer bracket
60= 3.1	217647	Shelf support
61= 3.2	1031037	Right telescopic runner
62= 3.3	1031038	Left telescopic runner
63= 3.4	001142	Shelf support screw
64= 3.5	217551.1	WIRE SHELF
65= 3.6	217558.2	WIRE SHELF
66= 3.7	48EF601	Pastry plate
67= 3.8	48BF601G	Oven tray
68= 3.10	473070	Lateral catalytic panel
69= 3.11	473100	Left lateral catalytic panel
70= 3.13	217546	Grill-pan grid
71= 3.14	037144	Grill pan grid handle
72= 3.15	072026	LAMP HOLDER
73= 3.16	073013001	LAMP
74= 3.17	072015	Side lamp holde

75= 3.18	066140	Cut-off thermostat 175 degree
76= 3.19	051079	Terminal Block
77= 3.20	054041	CORD
78= 3.21	1131796	WIRING
79= 3.22	1131595	Electronic cards wiring (Side lamp)
80= 3.23	103406	Kit pizza stone