








Position	Code	description
0= 00	630F612	Oven condensation kit
1= 1.1	35F60341DA	PANEL
2= 1.2	032F2771D1	DOOR GLASS
3= 1.3	375FF6013	Door panel with inner glass
4= 1.4	063107	Hinge (male)
5= 1.5	037276035	Door handle
6= 1.8	51BF604	Handle bar
7= 1.9	001083	SCREW
8= 1.10	450F61EM46	Oven cube
9= 1.11	51BF614S.1	Deflector
10= 1.13	51BF601DH	Right front trim
11= 1.14	51BF601SH	Left front trim
12= 1.15	411F6D1Z	Right side panel
13= 1.16	411F6S1Z	Left side panel
14= 1.17	411F602.1	Bottom panel
15= 1.18	08328400A	Lower trim
16= 1.19	094390	Door hinge (female)
17= 1.20	030120.1	Oven insulation
18= 1.21	030122.1	Rear insulation
19= 1.22	035101	Insulation spring
20= 1.23	411F607	Lower air conveyor
21= 1.24	421F602Z	Conveyor support
22= 1.25	411F605	Air conveyor
23= 1.26	079017	Tangential fan
24= 1.27	040056	Rubber
25= 1.30	411F603	REAR PANEL
26= 1.31	411F604	Upper shelter
27= 1.32	094392	Thermal overload support
28= 1.33	103672	WIRE CLAMP
29= 1.34	053074	Upper seal
30= 1.35	053087	SEAL
31= 2.1	218G006466	CONTROL KNOB
32= 2.2	050028.1	Oven switch
33= 2.3	066157	THERMOSTAT
34= 2.4	073090	Control lamp cover (Blue)
35= 2.6	073091	Control lamp L = 230
36= 2.7	073093	Control lamp L = 600

37= 2.8	074012	Timer 120 min
38= 2.10	072006	LAMP HOLDER
39= 2.11	073013001	LAMP
40= 2.12	062098004	Top + grill element 230V
41= 2.13	062090004	Bottom element - 230 V
42= 2.14	062097004	Fan element
43= 2.15	079008001F	Fan motor - 230 V
44= 2.16	47AF601GG	Fan Diffuser
45= 2.17	51BF603	Bottom element support
46= 2.19	066140	Cut-off thermostat 175 degree
47= 2.20	217647	Shelf support
48= 2.21	001142	Shelf support screw
49= 2.22	48BF601G	Oven tray
50= 2.23	48EF601	Pastry plate
51= 2.24	217551.1	WIRE SHELF
52= 2.25	217546	Grill-pan grid
53= 2.26	037144	Grill pan grid handle
54= 2.27	217558.2	WIRE SHELF
55= 2.28	1131810	WIRING
56= 2.29	054041	CORD
57= 2.30	051079	Terminal Block
58= 2.34	103085	FILTER
59= 2.38	085100	Sleeve M10
60= 2.39	1031167	SPACER
61= 2.40	214074	Nut M10