











Position	Code	description
1= 0.1	630F614	CONTROL PANEL ASSEMBLY (INCLUDING REF. 1.1+ 2.14+ 2.15+ 2.16+ 2.17)
2= 1.1	032F2756DA	Glass panel
3= 1.2	032F2411DA	DOOR GLASS
4= 1.3	037241062	Door handle
5= 1.4	063139	Hinge (male)
6= 1.10	450FP1EM42	Oven cube
7= 1.12	51BF614S.1	Deflector
8= 1.13	51BF601DH	Right front trim
9= 1.14	51BF601SH	Left front trim
10= 1.15	411F6D1Z	Right side panel
11= 1.16	411F6S1Z	Left side panel
12= 1.17	411F602.1	Bottom panel
13= 1.18	08328400A	Lower trim
14= 1.19	094433	Door hinge (female)
15= 1.20	030123	Oven insulation
16= 1.21	030137	Rear insulation
17= 1.22	103617	Fumes filter
18= 1.23	411F607	Lower air conveyor
19= 1.24	421F604Z	Air conveyor support
20= 1.25	411F606	Upper air conveyor
21= 1.26	079024	Tangential fan
22= 1.28	094435	Fumes conveyor
23= 1.30	411F603	REAR PANEL
24= 1.31	411F604	Upper shelter
25= 1.33	103672	WIRE CLAMP
26= 1.34	053074	Upper seal
27= 1.35	053099	SEAL
28= 1.36	421F603Z	REAR PANEL
29= 1.40	030132	Fumes catalyst insulation
30= 1.41	103723	Fumes catalyst
31= 1.45	51BF604	Handle bar
32= 1.46	001071	Door handle screw
33= 1.47	51BF606	Middle inner glass support
34= 1.48	0312117	Middle inner glass
35= 1.49	040056	Rubber
36= 1.50	372FF609GG	Door panel

37= 1.51	053089	Door panel gasket
38= 1.52	0312116	Inner glass
39= 1.53	372FF603GG	Door panel frame
40= 1.54	053090	Inner glass gasket
41= 1.55	103620	Door lock block
42= 1.56	030138	Rear central insulation
43= 2.1	218900A463	CONTROL KNOB
44= 2.2	050061.1	SWITCH
45= 2.3	066143	THERMOSTAT
46= 2.4	073092	Control lamp cover
47= 2.6	073091	Control lamp L = 230
48= 2.7	073093	Control lamp L = 600
49= 2.10	072007	LAMP HOLDER
50= 2.11	073013001	LAMP
51= 2.12	062155004	Top + grill element
52= 2.12	074091SG	Display electronic card
53= 2.13	062093004	Bottom element
54= 2.13	039068	Programmer electronic card insulator
55= 2.14	062097004	Fan element
56= 2.14	1031217	Pivot button (please order the control panel assembly)
57= 2.15	079023	FAN MOTOR
58= 2.15	035111	Spring Plate (please order the complete control panel)
59= 2.16	47AF601G	Fan diffuser
60= 2.16	10312130A	Console frame (please order complete control panel)
61= 2.17	51BF603 .1	Bottom element support
62= 2.17	103121207	Button (please order complete control panel)
63= 2.18	213031	CLIP
64= 2.18	094648	Electronic programmer bracket
65= 2.19	103085	FILTER
66= 2.19	066068	Cut-off thermostat 130 degree
67= 2.22	48BF601G	Oven tray
68= 2.23	217603	WIRE SHELF
69= 2.24	103406	Kit pizza stone
70= 2.25	48EF601	Pastry plate
71= 2.25	094221	Earth plate
72= 2.26	217546	Grill-pan grid
73= 2.27	037144	Grill pan grid handle
74= 2.27	051079	Terminal Block

75= 2.28	1131803	WIRING
76= 2.29	054120	Cord 3x1.5
77= 2.34	050063	POTENTIOMETER
78= 2.35	103619	Door lock
79= 2.36	094398	Door lock support
80= 2.37	107054	PROBE
81= 2.38	103829	CABLE
82= 2.40	071060	Programmer electronic peg